

[Manuals.plus](#) /

› [Intex](#) /

› Intex Zx300 Deluxe Automatic Pool Cleaner User Manual

Intex 28005

Intex Zx300 Deluxe Automatic Pool Cleaner User Manual

Model: 28005

Brand: Intex

INTRODUCTION

The Intex Zx300 Deluxe Automatic Pool Cleaner is designed to provide efficient and effortless cleaning for your swimming pool. This suction-side cleaner connects to your pool's filtration system, utilizing the water flow to move across the pool floor and collect debris. Its advanced design ensures thorough cleaning, helping to maintain a pristine swimming environment.



Figure 1: The Intex Zx300 Deluxe Automatic Pool Cleaner, showcasing its compact design and wheels.

SAFETY INFORMATION

Please read and understand all safety warnings and instructions before installing and operating this product. Failure to follow these instructions could result in property damage or serious injury.

- Always disconnect the pool cleaner from the filtration system before performing any maintenance or cleaning.
- Ensure your pool pump's flow rate is within the recommended range (1600-3500 GPH) for optimal and safe operation.
- Keep children and pets away from the pool area when the cleaner is in operation.
- Do not operate the cleaner if any parts are damaged or missing.
- Use only genuine Intex replacement parts.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- Intex Zx300 Deluxe Automatic Pool Cleaner Unit
- Hose sections (totaling 650 cm)
- Hose adapter(s)
- User Manual



Figure 2: Product packaging indicating Item No. 28005 and product details.

SETUP

The Intex Zx300 requires self-assembly. Follow these steps for proper setup.

1. **Assemble the Cleaner Unit:** Refer to the detailed diagrams in your printed manual for attaching any loose components to the main cleaner body. Ensure all brushes and wheels are securely in place.
2. **Connect Hose Sections:** Connect the provided hose sections together to achieve the necessary length for your pool. The total hose length is 650 centimeters. Ensure connections are tight to prevent air leaks.
3. **Attach Hose to Cleaner:** Securely attach one end of the assembled hose to the inlet port on the top of the cleaner unit.
4. **Connect to Pool Filtration System:**
 - Locate the suction inlet (skimmer or dedicated suction line) in your pool.
 - Attach the other end of the hose to this suction inlet using the appropriate adapter. Ensure a secure, airtight connection.
 - Make sure your pool pump is off before connecting the cleaner.
5. **Submerge the Cleaner:** Carefully lower the cleaner into the pool, allowing it to fill with water and sink to the bottom. Ensure all air is purged from the hose by holding the hose end underwater before connecting it to the suction inlet.



Figure 3: The Intex Zx300 cleaner submerged and operating in a pool.

OPERATING INSTRUCTIONS

Once the cleaner is properly set up and submerged, you can begin operation.

1. **Start the Pool Pump:** Turn on your pool's filtration pump. The cleaner will begin to move automatically across the pool floor as water is drawn through it.
2. **Monitor Performance:** Observe the cleaner's movement. It should move randomly across the pool bottom, covering all areas. If movement is sluggish or erratic, check for blockages or ensure your pump's flow rate is adequate (1600-3500 GPH).
3. **Cleaning Cycle:** Allow the cleaner to operate for a sufficient period to clean the entire pool. The duration will depend on the size of your pool and the amount of debris.
4. **End Operation:** When cleaning is complete, turn off your pool pump. Carefully remove the cleaner from the pool.

Important Note: The cleaner's efficiency is directly related to your pool pump's flow rate. Ensure it meets the specified requirements for optimal performance.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Intex Zx300 pool cleaner.

- **Empty Debris Collection Bag:** The cleaner has an internal debris collection compartment with a capacity of 1.8 liters. Regularly check and empty this compartment. A clogged filter will reduce the cleaner's movement and suction efficiency.
- **Clean Brushes:** Inspect the rotating brushes on the underside of the cleaner for tangled debris or wear. Clean them as needed to ensure they can effectively agitate and sweep the pool floor.
- **Inspect Hoses:** Check the hose sections for any cracks, kinks, or blockages. Replace damaged sections immediately.

- **Storage:** When not in use for extended periods, clean the cleaner thoroughly, allow it to dry completely, and store it in a cool, dry place away from direct sunlight.



Figure 4: Underside view of the cleaner, showing the brushes and debris collection area.




Figure 5: Close-up of the cleaner's rotating brushes, essential for scrubbing the pool surface.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Cleaner not moving or moving slowly.	<ul style="list-style-type: none"> Insufficient pump flow rate. Debris collection bag is full or clogged. Hose kinked or blocked. Air in the system. 	<ul style="list-style-type: none"> Ensure pump flow rate is between 1600-3500 GPH. Empty and clean the debris collection bag. Straighten hose, check for internal blockages. Re-submerge cleaner and hose to purge air.
Cleaner not picking up debris effectively.	<ul style="list-style-type: none"> Debris collection bag is full. Worn or damaged brushes. Low suction from pump. 	<ul style="list-style-type: none"> Empty and clean the debris collection bag. Inspect and replace brushes if necessary. Check pump and filter system for proper operation.
Cleaner gets stuck.	<ul style="list-style-type: none"> Hose too long or too short. Obstacles in the pool. 	<ul style="list-style-type: none"> Adjust hose length to suit pool dimensions. Remove toys or other large obstacles from the pool.

SPECIFICATIONS

Feature	Detail
Model Number	28005

Feature	Detail
Product Dimensions (L x W x H)	14.06 x 10.83 x 14.76 inches (35.7 x 27.5 x 37.5 cm)
Item Weight	15.4 pounds (7 kg)
Hose Length	650 Centimeters (21.3 feet)
Debris Capacity	1.8 Liters
Recommended Pump Flow Rate	1600-3500 GPH (Gallons Per Hour)
Material	Plastic
Special Feature	Portable, Automatic Operation
Assembly Required	Yes
Installation Type	Self-Assembly
Warranty Type	Limited

WARRANTY AND SUPPORT

The Intex Zx300 Deluxe Automatic Pool Cleaner comes with a limited warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Intex website.

For technical support, troubleshooting assistance beyond this manual, or to order replacement parts, please contact Intex customer service. Contact information can typically be found on the Intex website or on your product packaging.

© 2025 Intex. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.