

Manuals.plus /

› Intex /

› Intex 230V Krystal Clear Saltwater System Cg-26664

Intex 26664BS

Intex Krystal Clear Saltwater System

Model: 26664BS

PRODUCT OVERVIEW

The Intex Krystal Clear Saltwater System (Model 26664BS) is designed to provide a clear and clean swimming pool environment by converting salt into natural chlorine. This system reduces the need for traditional chemical chlorine, offering a more natural and comfortable swimming experience. It is suitable for various Intex above-ground pools.



Image: The Intex Krystal Clear Saltwater System, showing the main unit and its power supply. The main unit is white with a dark grey base and top panel, featuring the Intex logo. The power supply is a smaller, separate dark grey and white component with a power cord.

IMPORTANT SAFETY INFORMATION

Always read and follow all instructions and warnings before installing and using this product. Failure to follow these instructions can result in property damage, serious injury, or death.

- Ensure the power supply is disconnected before performing any maintenance or cleaning.
- Do not operate the system if the power cord or plug is damaged.
- Keep children away from the system during operation.
- Only use the system with the specified voltage and frequency.
- Consult a qualified electrician for any electrical installations or repairs.

SETUP AND INSTALLATION

Proper installation is crucial for the efficient operation of your saltwater system. Follow these steps carefully:

1. **Placement:** Position the saltwater system on a firm, level surface, at least 10 feet (3 meters) away from the pool. Ensure it is protected from direct sunlight and adverse weather conditions.
2. **Connection to Filter Pump:** Connect the saltwater system to your existing filter pump system. The saltwater system should be installed after the filter pump, ensuring filtered water flows through the system before returning to the pool.
3. **Hose Connections:** Securely attach all hoses using the provided clamps. Ensure there are no leaks.
4. **Adding Salt:** Use only pure, non-iodized pool salt (sodium chloride) with a purity of 99.8% or higher. Refer to the pool volume chart in your main pool manual for the correct amount of salt. Dissolve the salt in the pool water before starting the system.
5. **Electrical Connection:** Plug the system into a properly grounded electrical outlet. Ensure the outlet is protected by a Ground Fault Circuit Interrupter (GFCI) or Residual Current Device (RCD).

OPERATING INSTRUCTIONS

Once installed and salt is added, you can begin operating your Intex Krystal Clear Saltwater System.

- **Initial Start-up:** Turn on your filter pump first, then turn on the saltwater system.
- **Setting Operating Time:** The system has a timer function. Set the desired operating hours based on your pool size and usage. Refer to the manual's chlorine output chart for recommended run times.
- **Monitoring Salt Level:** The system will indicate if the salt level is too low or too high. Adjust by adding more salt or partially draining and refilling the pool, respectively.
- **Self-Cleaning Cycle:** The system features a self-cleaning cycle for the electrolytic cell. This cycle reverses polarity to reduce calcium buildup.

For optimal performance, ensure your pool's pH levels are maintained between 7.2 and 7.6.

MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your saltwater system.

- **Cell Cleaning:** Although the system has a self-cleaning function, manual cleaning of the electrolytic cell may be required periodically, especially in hard water areas. Disconnect power, remove the cell, and clean with a mixture of water and vinegar if calcium buildup is visible.
- **Filter Pump Maintenance:** Ensure your filter pump and filter cartridge/sand are clean and functioning correctly, as this directly impacts the saltwater system's performance.
- **Winterization:** Before winter, drain all water from the system and store it in a dry, frost-free location.

TROUBLESHOOTING

Problem	Possible Cause	Solution
"Low Salt" indicator	Insufficient salt in pool water.	Add more salt according to the manual's recommendations.
"High Salt" indicator	Excessive salt in pool water.	Partially drain pool and refill with fresh water.
No chlorine production	Low salt, dirty cell, or insufficient pump flow.	Check salt level, clean cell, ensure filter pump is running and clean.
System not turning on	No power, tripped GFCI/RCD.	Check power connection, reset GFCI/RCD.

If problems persist, contact Intex customer support.

SPECIFICATIONS

Model: 26664BS

Brand: Intex

Product Dimensions: 12.76 x 9.88 x 10.63 inches

Item Weight: 7.46 pounds

Voltage: 230V

ASIN: B08DJ9STWG

WARRANTY AND SUPPORT

Intex products are manufactured with the highest quality materials and workmanship. All Intex products have been inspected and found free of defects prior to leaving the factory. Intex warrants this Krystal Clear Saltwater System for a period of one (1) year from the date of retail purchase.

For warranty claims or technical support, please visit the official Intex website or contact their customer service department. Keep your proof of purchase for warranty validation.

Official Intex Website: www.intexcorp.com

