

Walker Edison BU59HAV4DREBDW

Walker Edison 59" Havana Sliding Slat Door 4 Drawer Sideboard

Model: BU59HAV4DREBDW

INTRODUCTION

Thank you for choosing the Walker Edison 59" Havana Sliding Slat Door 4 Drawer Sideboard. This urban modern sideboard is designed to provide versatile storage and enhance the aesthetic of your living space. Featuring a two-tone design, four deep drawers, and two unique sliding slat doors, it offers both style and functionality. This manual provides essential information for safe assembly, proper usage, and effective maintenance of your new furniture piece.



Image: Front view of the Walker Edison 59" Havana Sideboard in Ebony/Dark Walnut, showcasing its two-tone design, four central drawers, and two sliding slat doors.

SAFETY INFORMATION

Your safety is paramount. Please read and adhere to the following safety guidelines:

- To prevent tipping, ensure the cabinet is level and securely placed on a flat, stable surface. Consider using anti-tip hardware if available and recommended for your specific installation.
- Exercise caution when opening and closing drawers to avoid pinching fingers or injury from the cutout handles.
- Do not overload drawers or shelves. Distribute weight evenly to maintain stability and prevent damage.
- Keep small parts and assembly hardware out of reach of children and pets during assembly.
- Always follow the provided assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.

SETUP AND ASSEMBLY

Assembly of this sideboard requires patience and attention to detail. It is recommended to have at least two people for assembly due to the weight and size of the components.

Before You Begin:

- Clear a spacious area for assembly.
- Unpack all components and lay them out. Verify that all parts and hardware listed in the separate assembly instructions are present.
- Familiarize yourself with the different types of hardware and panels.

Assembly Tips:

- Follow the step-by-step assembly instructions provided in the packaging. Do not skip steps.
- Do not overtighten screws, especially when working with engineered wood, as this can strip the material.
- Ensure all connections are secure before moving to the next step.
- Pay close attention to the orientation of parts, particularly drawer slides and leg attachments, to ensure proper alignment and functionality.



Image: The sideboard integrated into a modern living room, demonstrating its functional and aesthetic appeal.



Image: Diagram showing the overall dimensions of the sideboard: approximately 59 inches wide, 19.63 inches deep, and 31.63 inches high.



Image: Close-up view of the drawers with internal dimensions indicated: each drawer is approximately 15.25 inches wide and 4 inches high.



Image: Detailed view of the top surface of the sideboard, highlighting the ebony finish and texture.

OPERATING AND USAGE

The Walker Edison Havana Sideboard is designed for versatile storage in various rooms, including the kitchen, dining room, or living room.

- **Drawers:** The four deep drawers operate on smooth telescoping metal glides, ensuring easy opening and closing. Use the integrated cutout handles for access.
- **Sliding Slat Doors:** The two unique slat doors slide horizontally to reveal or conceal storage compartments. This allows for customizable display and storage options.
- **Adjustable Shelves:** The interior features adjustable shelves, allowing you to customize the storage space to fit various items.
- **Cord Management:** The sideboard includes cord management ports, making it suitable for media components or devices requiring power access. It can accommodate TVs up to 65 inches.



Image: An angled view of the sideboard, providing a different perspective of its design and features.

MAINTENANCE

Proper care will help maintain the appearance and longevity of your sideboard.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads. Keep the sideboard away from direct sunlight and excessive moisture.
- **Moving:** When moving the sideboard, always lift it rather than dragging it to prevent damage to the legs and frame.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Drawers Not Aligning/Sliding Smoothly:**

Check that the drawer slides are installed correctly and are not bent. Ensure all screws securing the slides are tightened. Sometimes, slight adjustments to the slide placement can resolve alignment issues.

- **Sliding Doors Sticking or Falling Out:**

Verify that the tracks are clear of debris. Ensure the doors are properly seated in their top and bottom tracks. If a door comes off, carefully re-seat it by aligning the rollers with the track mechanism.

- **Sideboard Appears Unstable or Wobbly:**

Confirm that the sideboard is on a level surface. Check all leg attachments and ensure they are securely tightened. The adjustable center foot should be properly installed and adjusted to provide additional stability.

- **Missing or Damaged Parts:**

If you discover any missing or damaged parts during assembly, refer to the Warranty and Support section for

contact information.

SPECIFICATIONS

Feature	Detail
Brand	Walker Edison
Model Number	BU59HAV4DREBDW
Color	Ebony/Dark Walnut
Material	Engineered Wood
Product Dimensions	50.17 x 149.86 x 81.28 cm (19.75 x 59 x 32 inches)
Item Weight	57.15 kg (126 lbs)
Style	Modern Contemporary / Urban
Special Features	Adjustable center foot, Cord management ports, Accommodates TVs up to 65"
Room Type	Kitchen, Living Room, Dining Room

WARRANTY AND SUPPORT

For questions, support, or replacement parts, please contact Walker Edison directly.

QUESTIONS? We can help you.



1-801-433-3008
or email **service@walkeredison.com**

Replacement parts now available.
Please contact Walker Edison within 30 days of delivery.

Image: Contact information for Walker Edison customer support, including phone number and email address.


Phone: 1-801-433-3008

Email: service@walkeredison.com

Replacement parts are available. Please contact Walker Edison within 30 days of delivery for assistance with parts.



© 2023 Walker Edison. All rights reserved.

Related Documents - BU59HAV4DREBDW



[Walker Edison Bronx 6-Drawer Dresser Assembly Guide](#)

Comprehensive assembly guide for the Walker Edison Bronx 6-Drawer Dresser, featuring estimated assembly time, required tools, safety warnings, detailed step-by-step instructions, and parts lists for a successful setup.

 <p>Item # : BU59HAV4DR Assembly Instructions</p> <p>WE Please read our website for the most current instructions, assembly tips, repair damage before you begin. Assembly Instructions Copyright © 2014 by Walker Edison Furniture Co., LLC. All rights reserved. Revise 02-07-2014-2</p>	<p><u>Walker Edison BU59HAV4DR Assembly Instructions for Sideboard</u></p> <p>Comprehensive assembly guide for the Walker Edison BU59HAV4DR sideboard, detailing parts, hardware, and step-by-step instructions for a safe and correct build.</p>
 <p>Item # : W70SBD Assembly Instructions</p> <p>WE Please read our website for the most current instructions, assembly tips, repair damage before you begin. Assembly Instructions Copyright © 2014 by Walker Edison Furniture Co., LLC. All rights reserved. Revise 02-07-2014-2</p>	<p><u>Walker Edison W70SBD TV Stand Assembly Instructions</u></p> <p>Detailed assembly instructions for the Walker Edison W70SBD TV Stand, including parts list, hardware list, and step-by-step guidance for building your furniture.</p>
 <p>Item: KOAD1D Assembly Instructions</p> <p>WE Please read our website for the most current instructions, assembly tips, repair damage before you begin. Assembly Instructions Copyright © 2014 by Walker Edison Furniture Co., LLC. All rights reserved. Revise 02-07-2014-2</p>	<p><u>Walker Edison KOAD1D Round Dining Table Assembly Instructions</u></p> <p>Step-by-step assembly instructions for the Walker Edison KOAD1D round dining table. Includes parts list, hardware list, and assembly guidelines.</p>
 <p>HEAO Instruction Manual</p> <p>HEAO Rollator Walker with Seat</p> <p>Note: Before using this product, carefully read the instructions.</p>	<p><u>HEAO Rollator Walker with Seat Instruction Manual</u></p> <p>Comprehensive instruction manual for the HEAO Rollator Walker with Seat, detailing part lists, assembly, folding, braking, and height adjustment.</p>
 <p>6-Drawer Solid Wood Dresser</p> <p>For Residential Use Only</p>	<p><u>6-Drawer Solid Wood Dresser Assembly Instructions</u></p> <p>Detailed assembly guide for the Walker Edison 6-Drawer Solid Wood Dresser, including parts list, hardware, and step-by-step instructions for easy setup.</p>