

WallarGe CL6002

WallarGe Auto Set Digital Wall Clock User Manual

Model: CL6002 | Brand: WallarGe

1. INTRODUCTION

Thank you for purchasing the WallarGe Auto Set Digital Wall Clock. This versatile clock is designed to provide accurate time, date, day of the week, indoor temperature, and humidity readings. Its large display ensures easy readability, making it suitable for various environments such as bedrooms, offices, and living rooms. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance of your device.



Figure 1.1: Front view of the WallarGe Auto Set Digital Wall Clock.

2. SAFETY INFORMATION

- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the clock to strong impacts.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the clock will not be used for an extended period to prevent leakage.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Please check the package for the following items:


- 1 x WallarGe Auto Set Digital Wall Clock (Model CL6002)
- 1 x User Manual

Note: 3 x AA batteries are required and not included in the package.

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert 3 new AA batteries, ensuring correct polarity (+ and -).
4. Close the battery compartment cover securely.



Battery operated, no redundant wires.

One-year long battery life.

Large numbers display.




Figure 4.1: Battery installation in the WallarGe clock.

Upon battery insertion, the clock will automatically set the correct time and date within a few seconds due to its internal memory battery. No manual time setting is typically required for initial setup.

Your browser does not support the video tag.

Video 4.1: Demonstration of automatic time setting upon battery installation.

4.2 Time Zone Selection

The clock supports 8 time zones. To select your time zone:

1. Locate the time zone switch on the back of the clock.
2. Slide the switch to your desired time zone (e.g., PST, MST, CST, EST).

DIMENSIONS: .8.6 in(L) x 5.2 in(H) x 1.2 in(W)

No Backlight



Figure 4.2: Time zone selection switch on the back of the clock.

4.3 Placement Options

The WallarGe clock can be used as a desk clock or mounted on a wall.

- **Desk Placement:** Extend the integrated stand on the back of the clock to place it on any flat surface.
- **Wall Mounting:** Use the keyhole slot on the back of the clock to hang it securely on a wall using a screw or nail (not included).

Desk Clock or Wall Clock



Figure 4.3: Wall and desk placement options for the clock.

Your browser does not support the video tag.

Video 4.2: Overview of the WallarGe clock's features and placement options.

5. OPERATING INSTRUCTIONS

5.1 Display Overview

The large LCD display shows the following information:

- **Time:** Large digits for hours and minutes, with AM/PM indicator.
- **Date:** Month and day.
- **Day of the Week:** Full day name.
- **Temperature:** Indoor temperature in Celsius or Fahrenheit.
- **Humidity:** Indoor relative humidity percentage.

- **Auto DST:** Indicator for Daylight Saving Time status.
- **Low Battery Warning:** Icon indicates when batteries need replacement.



Figure 5.1: Detailed view of the clock's display features.

5.2 Alarm Setting and Snooze

To set the alarm:

1. Press the "ALARM SET" button on the back of the clock. The alarm time will flash.
2. Use the "UP" or "DOWN" buttons to adjust the alarm hour and minute.
3. Press "ALARM SET" again to confirm.

To activate/deactivate the alarm:

- Press the "ALARM ON/OFF" button to toggle the alarm function. An alarm icon will appear on the display when activated.

To use the snooze function:

- When the alarm sounds, press the "SNOOZE" button (usually a large button on top or front). The alarm will pause for 8 minutes and then sound again.

5.3 Temperature Unit Change

To switch between Celsius (°C) and Fahrenheit (°F) for temperature display:

- Locate the "°C/°F" button on the back of the clock and press it to toggle the unit.




Figure 5.2: Temperature and humidity display on the clock.

6. MAINTENANCE

- **Cleaning:** Wipe the clock gently with a soft, dry cloth. Do not use abrasive cleaners or chemicals.
- **Battery Replacement:** When the low battery indicator appears on the display, replace all 3 AA batteries promptly to ensure continuous and accurate operation.

- **Storage:** If storing the clock for an extended period, remove the batteries to prevent potential damage from battery leakage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Batteries are dead or incorrectly installed.	Replace batteries with new ones, ensuring correct polarity.
Time/Date is incorrect.	Incorrect time zone selected or initial auto-set failed.	Verify time zone switch setting. If issue persists, remove and reinsert batteries.
Alarm does not sound.	Alarm is not activated or volume is too low (if adjustable).	Ensure alarm is ON (alarm icon visible). Check alarm volume settings if applicable.
Temperature/Humidity readings seem inaccurate.	Clock placed near heat/cold sources or in direct sunlight.	Relocate the clock to a stable indoor environment away from direct heat, cold, or sunlight. Allow time for readings to stabilize.

8. SPECIFICATIONS

- **Model:** CL6002
- **Brand:** WallarGe
- **Display Type:** Digital LCD
- **Power Source:** 3 x AA Batteries (not included)
- **Product Dimensions:** 8.6" (W) x 5.2" (H) x 1.2" (D)
- **Weight:** 13.1 ounces
- **Special Features:** Large Display, Snooze, Temperature Display, Humidity Display, Alarm, Daylight Saving Time (DST) On/Off, Calendar Display, 8 Time Zones.
- **Mounting Type:** Wall Mount or Desktop/Table Top
- **Material:** Plastic
- **Indoor/Outdoor Usage:** Indoor



Figure 8.1: Product dimensions of the WallarGe clock.

9. WARRANTY AND SUPPORT

WallarGe products are designed for reliability and performance. For any questions, technical support, or warranty claims, please contact WallarGe customer service through the retailer's platform or visit the official WallarGe website for contact information.

Please retain your purchase receipt as proof of purchase for warranty purposes.

For more information, visit the [WallarGe Store](#).

© 2025 WallarGe. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question