

[Manuals.plus](#) /

› [GLOBO](#) /

› GLOBO 15830-4H Pendant Light User Manual

GLOBO 15830-4H

GLOBO 15830-4H Pendant Light User Manual

Model: 15830-4H

1. INTRODUCTION

Thank you for choosing the GLOBO 15830-4H Pendant Light. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

The GLOBO 15830-4H is a stylish pendant light featuring a matte black metal frame and four smoked glass shades. It is designed for indoor use and requires four E27 bulbs (not included) with a maximum wattage of 25W each.

2. SAFETY INSTRUCTIONS

WARNING: Electrical installation should only be performed by a qualified electrician in accordance with all local and national electrical codes.

- Always disconnect the main power supply before installation, maintenance, or bulb replacement to prevent electric shock.
- Ensure the voltage rating of the fixture matches your power supply.
- Do not exceed the maximum wattage of 25W per bulb.
- This fixture is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Handle glass components with care to avoid breakage.
- Keep packaging materials out of reach of children.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact your retailer.

- 1 x GLOBO 15830-4H Pendant Light Fixture (Matte Black Metal Frame with Smoked Glass Shades)
- Mounting Hardware (screws, wall plugs, ceiling bracket)
- Instruction Manual

Note: Four E27 light bulbs are **NOT** included and must be purchased separately.

4. SETUP AND INSTALLATION

Professional installation by a qualified electrician is highly recommended.

1. **Prepare for Installation:** Turn off the main power supply at the circuit breaker before starting any electrical work. Ensure the power is off by testing the circuit.
2. **Unpack the Fixture:** Carefully remove all components from the packaging. Inspect for any damage.
3. **Mount the Ceiling Bracket:** Position the ceiling bracket (part of the mounting hardware) at the desired location on the ceiling. Mark the drilling points. Drill holes and insert appropriate wall plugs (if necessary). Secure the ceiling bracket firmly to the ceiling using the provided screws.
4. **Electrical Connections:** Connect the electrical wires from the ceiling to the fixture's wires. Ensure correct polarity:
 - Live (L) wire to Live (L) terminal.
 - Neutral (N) wire to Neutral (N) terminal.
 - Ground (Earth) wire to Ground (Earth) terminal.

Ensure all connections are secure and properly insulated.

5. **Attach the Fixture:** Carefully lift the pendant light fixture and attach it to the ceiling bracket, securing it with the provided screws or fasteners. Ensure the fixture is stable and flush against the ceiling.
6. **Install Light Bulbs:** Gently screw four E27 bulbs (max 25W each) into the lamp holders. Do not overtighten.
7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Figure 1: Full view of the GLOBO 15830-4H Pendant Light. This image shows the overall design of the fixture, including the matte black metal bar, suspension cables, and four smoked glass shades.



Figure 2: Close-up view of two smoked glass shades with E27 bulbs installed. This image highlights the detail of the glass and the bulb socket area, relevant for bulb installation.

5. OPERATING INSTRUCTIONS

The GLOBO 15830-4H Pendant Light is operated via a standard wall switch connected to its electrical circuit. Simply toggle the wall switch to turn the light fixture on or off.

6. MAINTENANCE

- **Cleaning:** To clean the fixture, ensure the power is off. Use a soft, dry, lint-free cloth to wipe the metal and glass surfaces. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Always disconnect power before replacing bulbs. Allow bulbs to cool completely before handling. Replace with E27 bulbs, ensuring they do not exceed 25W.
- **Inspection:** Periodically inspect the fixture for any signs of wear, loose connections, or damage. If any issues are found, disconnect power and consult a qualified electrician.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	No power supply Faulty bulb Loose wiring connection	Check circuit breaker and wall switch Replace bulb Consult a qualified electrician to check wiring
Light flickers	Loose bulb Incompatible dimmer switch Loose wiring connection	Tighten bulb Ensure dimmer switch is compatible with LED/incandescent bulbs (if applicable) Consult a qualified electrician to check wiring
Fixture is hot to touch	Bulb wattage too high	Ensure bulbs do not exceed 25W each

8. SPECIFICATIONS

Feature	Detail
Brand	GLOBO
Model Number	15830-4H
Product Dimensions (L x W x H)	90 x 15 x 120 cm (35.4 x 5.9 x 47.2 inches)
Item Weight	1.88 Kilograms (4.14 lbs)
Color	Matte Black
Material	Metal, Glass
Shade Material	Smoked Glass
Number of Light Sources	4
Socket Type	E27
Maximum Wattage per Bulb	25 Watts
Power Source	AC
Installation Type	Ceiling Mount (Pendant)
Energy Label	A++

Feature	Detail
Batteries Required/Included	No

9. WARRANTY AND SUPPORT

This GLOBO product is covered by the manufacturer's standard warranty. Please refer to the warranty card included with your purchase or contact your retailer for specific warranty terms and conditions.

For technical support, replacement parts, or any inquiries regarding your GLOBO 15830-4H Pendant Light, please contact your point of purchase or visit the official GLOBO Lighting website for customer service information.

© 2026 GLOBO Lighting. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B08DKPZKF7>

More documents and user manuals: <https://manuals.plus/>