

[Manuals.plus](#) /

› [JONYJ](#) /

› JONYJ Handheld Rechargeable Vacuum Cleaner Instruction Manual

JONYJ 2&4

JONYJ Handheld Rechargeable Vacuum Cleaner Instruction Manual

Model: 2&4

PRODUCT OVERVIEW

The JONYJ Handheld Rechargeable Vacuum Cleaner is a versatile and portable device designed for efficient cleaning in various environments, including homes, cars, offices, and pet areas. It features strong suction, multifunctional accessories, and HEPA filters for thorough cleaning.



Image: JONYJ Handheld Rechargeable Vacuum Cleaner with various attachments including a filter, crevice tool, and brush nozzle.

KEY FEATURES

- **Easy to Clean:** Designed for hassle-free maintenance.
- **Strong Suction:** Provides powerful cleaning performance.
- **Multifunctional Accessories:** Includes various tools for different cleaning needs.
- **HEPA Filters:** Ensures efficient filtration of dust and allergens.

PACKAGE CONTENTS

The JONYJ Handheld Rechargeable Vacuum Cleaner package typically includes:

- Handheld Vacuum Unit
- Lithium Battery (rechargeable)

- Wall Charger
- Additional Filter
- Crevice Tool
- Brush Nozzle
- Other specialized attachments for detailed cleaning
- Carrying Case

SETUP

1. **Charge the Battery:** Before first use, fully charge the lithium battery using the provided wall charger. Ensure the battery is securely inserted into the charging unit.
2. **Attach Accessories:** Select the appropriate cleaning attachment (e.g., crevice tool for tight spaces, brush nozzle for upholstery) and firmly attach it to the vacuum's nozzle.
3. **Insert Filter:** Ensure the HEPA filter is correctly installed inside the dust cup.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button located on the handle to turn the vacuum cleaner on or off.
2. **Cleaning:** Guide the vacuum cleaner over the surface to be cleaned. The strong suction will pick up dust, dirt, and debris.
3. **Using Attachments:** Utilize the specialized attachments for targeted cleaning. For example, the crevice tool is ideal for narrow gaps, and the brush nozzle is effective for removing pet hair from fabric surfaces.

MAINTENANCE

1. **Emptying the Dust Cup:** Regularly empty the dust cup when it reaches its maximum capacity to maintain optimal suction. Detach the dust cup, dispose of the contents, and reattach it securely.
2. **Cleaning the Filter:** The HEPA filter should be cleaned periodically. Remove the filter from the dust cup and tap it gently to dislodge dust. For a more thorough cleaning, rinse it under running water and allow it to air dry completely before reinserting.
3. **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Store the vacuum in a cool, dry place when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Suction Power	Full dust cup, clogged filter, or blocked nozzle.	Empty dust cup, clean/replace filter, clear any blockages from the nozzle or attachments.
Vacuum Not Turning On	Battery not charged, battery not properly inserted.	Charge the battery fully, ensure battery is correctly inserted into the vacuum.
Short Battery Life	Battery not fully charged, aging battery.	Ensure full charge before use. If battery is old, consider replacing it.

SPECIFICATIONS

- **Brand:** JONYJ
- **Model Number:** 2&4
- **Item Weight:** 1 Pounds
- **Package Dimensions:** 17.6 x 6.5 x 5.6 inches
- **Color:** Blue
- **Batteries Required:** No (Rechargeable battery included)

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included in your product packaging or visit the official JONYJ website.