Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Wicked Audio /
- > Wicked Audio WITW2150 Driftr True Wireless Earbuds User Manual

Wicked Audio WITW2150

Wicked Audio WITW2150 Driftr True Wireless Earbuds User Manual

Model: WITW2150

INTRODUCTION

Thank you for choosing the Wicked Audio WITW2150 Driftr True Wireless Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.



Image: Wicked Audio Driftr True Wireless Earbuds in their charging case.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Wicked Audio WITW2150 Driftr True Wireless Earbuds
- · Charging Case
- USB Charging Cable
- · User Manual (this document)





Image: Retail packaging of the Driftr Earbuds.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case.

- 1. Place the earbuds into the charging case. Ensure they are seated correctly.
- 2. Connect the USB charging cable to the charging port on the case and to a USB power source.
- 3. The indicator light on the case will show charging status. Refer to the LED indicator section for details (if available in product documentation).
- 4. Once fully charged, disconnect the charging cable.





Image: Hand holding the Driftr charging case.

2. Pairing with a Device

The Driftr earbuds feature easy, straightforward pairing.

- 1. Open the charging case. The earbuds will automatically enter pairing mode.
- 2. On your device (smartphone, tablet, computer), go to Bluetooth settings.
- 3. Search for available devices and select "Wicked Audio Driftr" (or similar name).
- 4. Once connected, you will hear an audio prompt, and the indicator light on the earbuds will change.
- 5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.

OPERATING INSTRUCTIONS

Wearing the Earbuds

Insert the earbuds into your ears with the angled housing pointing forward for a comfortable and secure fit. Adjust as needed for optimal sound isolation.



Image: Side view of the Driftr Earbuds.

Touch Controls

The Driftr earbuds feature touch controls for easy management of audio playback and calls.

- Play/Pause: Single tap on either earbud.
- Next Track: Double tap on the right earbud.
- Previous Track: Double tap on the left earbud.
- Answer/End Call: Single tap on either earbud during an incoming call or active call.
- Reject Call: Press and hold either earbud for 2 seconds during an incoming call.
- Activate Voice Assistant: Triple tap on either earbud (e.g., Siri, Google Assistant).
- Volume Control: Volume control may be primarily managed via the connected device.

Hands-Free Calling

The built-in microphone allows for hands-free communication. Ensure the earbuds are connected to your phone via Bluetooth.

- Incoming calls will ring through the earbuds.
- Use the touch controls as described above to manage calls.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- Cleaning: Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- Storage: When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Water Resistance: The earbuds are not specified as waterproof. Avoid exposure to water, moisture, or extreme temperatures.
- Charging: Only use the provided charging cable or a certified equivalent.

TROUBLESHOOTING

Problem	Possible Solution	
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Wicked Audio Driftr" from your device's Bluetooth list and re-pair. Place earbuds back in the case, close, then reopen to reset pairing mode.	
No sound from one earbud	Ensure both earbuds are charged. Try resetting the earbuds (refer to specific product instructions if a reset procedure is available, otherwise re-pair). Clean any debris from the earbud's speaker mesh.	
Charging case not charging	Check the charging cable and power adapter. Ensure the charging port is clean and free of debris. Try a different USB port or power source.	
Low volume	Increase volume on both your connected device and the earbuds (if applicable). Ensure earbuds are properly seated in your ears for optimal sound isolation. Clean any earwax or debris from the earbud's speaker mesh.	

SPECIFICATIONS

Feature	Detail
Model Name	Wicked Audio Driftr WITW2150
Connectivity Technology	Wireless (Bluetooth)

Feature	Detail
Bluetooth Version	5.0
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Sound Isolation
Control Method	Touch
Frequency Range	20-20,000 Hz
Impedance	33 Ohm
Audio Driver Type	Dynamic Driver
Material	Plastic
Item Weight	2.11 ounces
Product Dimensions	1.5 x 3 x 5.5 inches
UPC	712949012258


WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Wicked Audio website or contact their customer service department. Keep your proof of purchase for warranty claims.

Online Support: Visit the Wicked Audio Store on Amazon for more product information and support resources.

© 2024 Wicked Audio. All rights reserved.

Related Documents - WITW2150





Wicked Audio AXOMA TWS Earbuds User Manual and Guide

Comprehensive user manual for Wicked Audio AXOMA TWS wireless earbuds, covering setup, charging, functions, troubleshooting, and safety information.



Defunc TRUE AUDIO: True Wireless Earbuds with App Control & Low Latency

Explore the Defunc TRUE AUDIO true wireless earbuds. Learn about their app-controlled features, 50 MS low latency, 30-hour battery life, Bluetooth 5.3 connectivity, and user guide.



Defunc TRUE ENTERTAINMENT True Wireless Earbuds User Manual & Guide

Comprehensive guide to Defunc TRUE ENTERTAINMENT true wireless earbuds, covering features like low latency, 3D stereo sound, setup, touch controls, charging, technical specifications, warranty, and safety warnings.

Documents - Wicked Audio - WITW2150



[pdf] Agent Authorization

PLEASE PRINT ON COMPANY LETTERHEAD MiCOM Labs Inc QMS Agent Authorization WICKED AUDIO INC WI TW215X True wireless earbuds 2AFM7WI 2AFM7WITW215X wi tw215X WICKED AUDIO, INC Agent Authorization Company: WICKED AUDIO, INC Address: 875 WEST 325 NORTH, LINDON ... , WI-EX2700-CA, WI-EX2701-CA, WI-EX2702-CA, WI-EX2703-CA, WI-EX2704-CA, WI-EX2705-CA, WI-EX270X-CA, WITW2150, WI-TW2151, WI-TW2152, WI-TW2153, WI-TW2154, WI-TW2155, WI-TW215X, WI-EX2700, WI-EX2701, WI...

lang:en score:26 filesize: 13.89 K page count: 1 document date: 2020-05-25