

[Manuals.plus](#) /

> [Sonik](#) /

> Sonik SK-TEK 4 Season Sleep System Instruction Manual

Sonik SK-TEK 4 Season Sleep System (EC0001)

Sonik SK-TEK 4 Season Sleep System Instruction Manual

Model: SK-TEK 4 Season Sleep System (EC0001)

INTRODUCTION

Thank you for choosing the Sonik SK-TEK 4 Season Sleep System. This product is designed to provide a comfortable and warm sleeping solution for carp anglers in various outdoor conditions. Featuring a revolutionary Stance frame design and an innovative Xpanda insulation system, this sleep system offers stability, warmth, and compact transport. Please read this manual thoroughly before setup and use to ensure optimal performance and longevity of your product.



An overview of two Sonik SK-TEK 4 Season Sleep Systems in an outdoor setting, illustrating their practical design and readiness for use in various fishing environments.

SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- Ensure the bed chair is placed on stable, level ground before use.
- Do not exceed the maximum weight capacity of 150 kg (approximately 330 lbs).
- Keep all moving parts clear of fingers and clothing during setup and folding.
- Do not use near open flames or extreme heat sources.
- Regularly inspect the frame, legs, and fabric for any signs of wear or damage.

SETUP INSTRUCTIONS

1. Unpacking and Initial Inspection

Carefully remove the sleep system from its packaging. Inspect all components for any signs of damage that may have occurred during transit. If any damage is found, do not proceed with setup and contact your retailer.

2. Deploying the Bed Chair

1. Place the folded sleep system on a flat surface.
2. Unclip any securing straps.
3. Gently unfold the bed chair frame until it is fully extended. The double-fold hinges allow for a completely flat profile.



This view from beneath the bed chair highlights the stable Stance frame, the six adjustable legs for varied terrain, and the elasticated lacing providing full lumbar support.

3. Adjusting the Legs

The SK-TEK Sleep System features six adjustable legs. Press the spring-loaded button on each leg and extend or retract to achieve the desired height (between 43 cm and 58 cm). Ensure all legs are securely

locked in place and the bed chair is stable before use.

4. Integrating the Sleeping Bag

The 4-season sleeping bag is designed to be integrated with the bed chair. It features a full fleece-lined quilt and is attached using the Xpanda system. Ensure the sleeping bag is correctly positioned and secured to the bed chair for optimal warmth and comfort.



This image displays the integrated sleeping bag, highlighting its comfortable lining and the robust zipper system that secures it to the bed chair.

OPERATING INSTRUCTIONS

1. Adjusting Lumbar Firmness

The bed chair features full lumbar support that can be adjusted to your preference. Locate the adjustment straps or system beneath the bed chair's fabric in the lumbar area. Tighten or loosen these to achieve the desired firmness for back and shoulder support.



Here, a user adjusts the Xpanda system, which allows the sleeping bag's insulation to conform closely to the body, enhancing warmth and comfort.

2. Utilizing the Xpanda System

The Xpanda system is designed to maximize warmth by allowing the sleeping bag's insulation to expand and conform to your body shape. Ensure the sleeping bag is properly zipped and positioned to benefit from this feature, which helps eliminate cold spots and provides a snug fit.



This photo illustrates a user making final adjustments to the sleep system, showcasing how the sleeping bag integrates seamlessly with the bed chair for a complete setup.

3. Folding for Transport

To fold the sleep system for compact transport:

1. Ensure the sleeping bag is fully zipped and secured to the bed chair.
2. Retract all legs to their shortest position.
3. Fold the bed chair using the double-fold hinges. The design allows for the sleeping bag to remain inside during folding.
4. Secure with the integrated straps.

MAINTENANCE

Cleaning

- **Frame:** Wipe down the steel and aluminum frame with a damp cloth and mild detergent. Dry thoroughly.
- **Fabric & Sleeping Bag:** Spot clean with a damp cloth and mild soap. Do not machine wash or tumble dry the sleeping bag or bed chair fabric. Allow to air dry completely before storage.

Storage

- Store the sleep system in a dry, cool place, away from direct sunlight and extreme temperatures.
- Ensure the product is completely dry before folding and storing to prevent mildew.
- Store in its folded, compact state to save space.

TROUBLESHOOTING

Difficulty Folding/Unfolding

- Ensure all legs are fully retracted before folding.
- Check for any obstructions in the hinge mechanisms.

Bed Chair Instability

- Verify that all six legs are extended to an equal length and securely locked.
- Ensure the bed chair is placed on a firm, level surface.

Insufficient Warmth

- Confirm the sleeping bag is fully zipped and the Xpanda system is properly adjusted to minimize air gaps.
- Consider adding an additional thermal layer in extremely cold conditions.

SPECIFICATIONS

Feature	Detail
Model Number	EC0001
Brand	Sonik
Color	Olive
Season Rating	4 Season

Feature	Detail
Sport Type	Fishing (Carp)
Frame Material	Robust Steel and Aluminum
Sleeping Surface Dimensions (Unfolded)	212 cm (L) x 84 cm (W)
Adjustable Height	43 cm - 58 cm
Folded Dimensions	84 cm (L) x 87 cm (W) x 30 cm (H)
Weight	12.5 kg
Legs	6 adjustable legs
Weight Capacity	Up to 150 kg
Closure Type	Zipper

WARRANTY AND SUPPORT

For warranty information, technical support, or spare parts, please contact your authorized Sonik retailer or visit the official Sonik website. Keep your proof of purchase for any warranty claims.