



Manuals.plus /

› BlumWay /

› BlumWay 32GB USB 2.0 Flash Drive User Manual

BlumWay NW0046

BlumWay 32GB USB 2.0 Flash Drive User Manual

Model: NW0046

PRODUCT OVERVIEW

The BlumWay 32GB USB 2.0 Flash Drive is a portable data storage device designed for convenient digital data storing, transferring, and sharing. It features a FAT32 format, ensuring broad compatibility with various devices and operating systems. Its compact design includes a protective cap and an LED indicator for operational status.



Image: The BlumWay 32GB USB 2.0 Flash Drive, showcasing its white body with blue accents and the removable protective cap.

SETUP AND INITIAL USE

The BlumWay USB flash drive is designed for plug-and-play functionality, requiring no software installation for basic operation.

Connecting the Device

1. Remove the protective cap from the USB flash drive to expose the USB connector.
2. Insert the USB connector into an available USB port on your computer, video capture card, cassette player, or other compatible device.
3. The device will be automatically recognized by most operating systems (Windows, Mac OS, Linux) and compatible devices.



Image: The BlumWay USB flash drive shown within its clear protective case, indicating how it is stored when not in use.

OPERATING INSTRUCTIONS

Data Transfer

Once connected, the flash drive will appear as a removable storage device on your computer or compatible device. You can drag and drop files, copy and paste, or use your device's file management system to transfer data.

- **Storing Data:** Save music, photos, movies, designs, manuals, programs, handouts, and various file formats (MP3, MP4, RMVB, EXCEL, WORD, PDF) directly to the drive.
- **Transferring Data:** Move files between different devices by plugging the flash drive into each device.
- **Sharing Data:** Easily share files with others by providing them with the flash drive.

Storage for All Kinds of Files

You can store video, photos, music, file at a quick speed.



Image: The USB flash drive depicted with icons representing music, photos, videos, and documents, highlighting its versatility for storing various file types.

LED Indicator

The integrated red LED indicator provides visual feedback on the drive's activity:

- When the drive is connected and idle, the light will be on.
- The red light will flash when data is being transferred to or from the drive, indicating active operation.



Led instructions

When your HD video capture is recognizing the flash drive, the led indicator light changes from flashing to steady

Image: The USB flash drive inserted into an HD video capture device, demonstrating how the LED indicator functions during use.

COMPATIBILITY

The BlumWay USB flash drive offers wide compatibility with various devices and operating systems:

- **Operating Systems:** Supports Windows 7 / 8 / 10 / Vista / XP / 2000 / ME / NT, Linux, and Mac OS.
- **Devices:** Compatible with USB 2.0 and below, including personal computers, laptops, tablets, cameras, smartphones, video capture cards, cassette players, and car audio systems.

Wider compatibility



Image: A visual representation of the flash drive's wide compatibility, showing it can be used with car audio systems, HD video capture devices, smart TVs, and cassette players.



Image: The USB flash drive connected to a cassette player, demonstrating its compatibility for recording or playback with such devices.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your BlumWay USB flash drive, follow these care guidelines:

- **Protection:** Always use the provided protective cap to cover the USB interface when the drive is not in use. This helps prevent dust, dirt, and physical damage, and greatly reduces oxidation.
- **Storage:** Store the flash drive in a cool, dry place away from extreme temperatures, direct sunlight, and strong magnetic fields.
- **Cleaning:** If necessary, gently wipe the exterior of the drive with a soft, dry, lint-free cloth. Do not use liquid cleaners or solvents.
- **Safe Removal:** Always safely eject the USB flash drive from your device before physically removing it to prevent data corruption.



Image: The USB flash drive attached to a keyring, highlighting its portable and lightweight design for easy carrying.

TROUBLESHOOTING

If you encounter issues with your BlumWay USB flash drive, consider the following common solutions:

Problem	Possible Cause / Solution
Drive not recognized by computer.	<ul style="list-style-type: none"> • Ensure the drive is fully inserted into the USB port. • Try a different USB port on your device. • Restart your computer or device. • Check if the drive appears in Disk Management (Windows) or Disk Utility (Mac) and is properly formatted (FAT32). • Ensure your device's USB drivers are up to date.
Slow data transfer speeds.	<ul style="list-style-type: none"> • Ensure you are using a USB 2.0 compatible port for optimal speeds. • Close other applications that might be using system resources. • Defragment the drive (Windows) or verify disk permissions (Mac) if performance degrades over time.
LED indicator not lighting up.	<ul style="list-style-type: none"> • Ensure the drive is properly connected to a powered USB port. • Try a different USB port or device.
Cannot write files to the drive.	<ul style="list-style-type: none"> • Check if the drive is full. • Verify file permissions on your computer. • Ensure the drive is not set to read-only mode (though this model does not have a physical write-protect switch).

SPECIFICATIONS

Feature	Detail
Model Number	NW0046
Storage Capacity	32 GB (approx. 29.2-30GB usable)
Interface	USB 2.0 (backward compatible with USB 1.1)
Read Speed	18 Megabytes Per Second
Write Speed	15 MB per second
File System	FAT32 (pre-formatted)
Color	White, Blue
Dimensions (L x W x H)	2.6" x 0.7" x 0.3"
Weight	0.704 ounces
Indicator	Red LED for data transfer activity



USB 2.0 Transmission

Read speed up to 12-18MB/S

Write speed up to 4-10MB/S

Image: The flash drive illustrating its USB 2.0 transmission capabilities, including typical read and write speeds.




Image: A diagram detailing the physical dimensions of the USB flash drive.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official BlumWay website. Keep your proof of purchase for any warranty claims.

For additional assistance, you may contact BlumWay customer service through their official channels.

