

Hisense WF5I8043BWF

Hisense WF5I8043BWF Washing Machine User Manual

Model: WF5I8043BWF

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Hisense WF5I8043BWF slim front-load washing machine. Please read these instructions carefully before using the appliance and retain them for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the appliance is properly grounded.
- Do not allow children to play with or operate the washing machine.
- Never force the door open during operation.
- Unplug the appliance before cleaning or performing maintenance.
- Do not wash items that have been cleaned in, washed in, soaked in, or spotted with combustible or explosive substances.

3. INSTALLATION

3.1 Unpacking and Transit Bolt Removal

Before operating the washing machine, it is crucial to remove all transit bolts located at the rear of the appliance. These bolts secure the drum during transport and must be removed to prevent damage during operation. Refer to the diagram below for bolt locations.

Hisense

WF5I8043BWF



Technical drawing showing the dimensions of the Hisense WF5I8043BWF washing machine: 595mm width, 470mm depth, 845mm height. This diagram also indicates the location of transit bolts at the rear.

3.2 Placement

Place the washing machine on a firm, level surface. Ensure there is adequate space around the appliance for ventilation and maintenance. The slim design (iFit) allows for flexible placement.

iFit™

Più spazio, più adattabilità



Image demonstrating the iFit slim design of the washing machine, featuring a depth of 470mm for easy integration into compact spaces.

3.3 Water and Electrical Connections

Connect the water inlet hose to a cold water tap and the drain hose to a suitable drain. Ensure all connections are secure to prevent leaks. Plug the power cord into a grounded electrical outlet. Consult a qualified technician if you are unsure about any connections.

4. OPERATING INSTRUCTIONS

4.1 Control Panel Overview (iPlay TFT Display)

The washing machine features an iPlay TFT display for intuitive program selection and monitoring.

iPlay™

Display intelligente, uso intelligente



A detailed view of the iPlay TFT display, showcasing its intuitive interface for selecting wash programs like Cotton, Jeans, Wool, Quick 15', and special functions.

4.2 Loading Laundry (Maxi Drum)

The Maxi Drum design provides a larger capacity for easier loading and unloading of up to 8 kg of laundry.



The washing machine with its door open, revealing the spacious drum designed for easy loading and unloading.

4.3 Detergent Dispenser

Add detergent and fabric softener to the appropriate compartments in the dispenser drawer.



The pull-out detergent dispenser drawer, with compartments for pre-wash, main wash, and fabric softener.

4.4 Program Selection

Turn the program selector knob or use the touch display to choose from 15 available programs. Key programs include:

- **Quick Program:** For fast washing cycles.
- **Steam Programs (Hygiene Guard+):** Utilizes high-temperature steam to eliminate 99.99% of bacteria and allergens.
- **Refresh:** Revitalizes clothes and removes creases with minimal water.
- **Anti-Stain:** Targets 9 common stain types by adjusting temperature, speed, and wash duration.
- **Allergy Care:** Uses high-temperature hot air sterilization to remove 99.99% of harmful bacteria.
- **Cold Wash:** Achieves effective cleaning at lower temperatures, saving energy.
- **Quicker:** Reduces wash time by up to 57% for selected programs.

4.5 Smart Features (Connect Life App)

Connect your washing machine to the Connect Life app for enhanced control and monitoring.

- **Smart Assist:** Optimizes wash settings based on fabric type, load volume, and soil level.

Smart Assist

Bucato senza sforzi, risultati sorprendenti




 ConnectLife

Illustration of the Smart Assist feature via the ConnectLife app, allowing users to optimize wash settings based on fabric type, load volume, and soil level.

- **Energy Monitoring:** Track real-time energy and water consumption to manage costs.

Monitoraggio Energetico

Controlla i tuoi consumi, riduci i tuoi costi!



The ConnectLife app's Energy Monitoring function, showing real-time energy and water consumption data to help manage costs.

- **Smart Link:** If you have a compatible Hisense dryer, the washing machine can automatically select the appropriate drying program.

Smart Link

Dal lavaggio all'asciugatura, tutto con un solo tocco



Diagram illustrating the Smart Link feature, which allows the washing machine to communicate with a compatible dryer for optimized drying cycles.

4.6 Adding Items During Cycle

The washing machine allows you to add forgotten items during a cycle. Look for the 'Add Garment' indicator on the display. Ensure the water level is below the door seal before opening.

5. MAINTENANCE

5.1 Drum Clean Function

Regularly use the Drum Clean function to maintain hygiene and prevent the accumulation of mold and bacteria inside the drum. This function uses hot air to dry the drum after washing.

5.2 General Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Clean the detergent dispenser drawer regularly to prevent residue buildup. Check and clean the drain pump filter periodically.

6. TROUBLESHOOTING

If you encounter issues with your washing machine, refer to the following common solutions. For persistent problems, contact customer support.

- **Machine not starting:** Check if the power cord is plugged in, the door is closed properly, and the water supply is on.
- **Excessive vibration/noise:** Ensure all transit bolts have been removed. Verify the machine is level and all four feet are stable on the floor.
- **Water leakage:** Check all hose connections for tightness. Inspect the detergent drawer for excessive detergent buildup.
- **Poor washing results:** Ensure correct detergent dosage and program selection for the load type and soil level.

7. SPECIFICATIONS

Feature	Specification
Model Number	WF5I8043BWF
Capacity	8 kg
Dimensions (W x D x H)	59.5 cm x 47 cm x 84.5 cm
Weight	61 kg
Maximum Spin Speed	1400 rpm
Energy Efficiency Class (New EU)	A
Energy Consumption (Eco 40-60)	33 kWh / 100 cycles
Water Consumption (Eco 40-60)	38 L / cycle
Noise Level (Spin)	72 dB(A)
Voltage	240 Volt
Special Features	Smart Connectivity, Steam, Refresh, Anti-stain, iFit, iPlay, Maxi Drum



ENERG




HISENSE

WF5I8043BWF






33 kWh / 



8.0 kg




3:38



38 L



ABCDEFG



ABCD

2019/2014

The official EU energy label for the Hisense WF518043BWF, indicating its Class A energy efficiency, 8 kg capacity, 33 kWh/100 cycles, 38 L water/cycle, and 72 dB spin noise.

Scheda informativa del prodotto

REGOLAMENTO DELEGATO (UE) 2019/2014

Marchio o nome del fornitore: HISENSE

Indirizzo del fornitore Partizanska cesta 12, 3320 Velenje, SI

Identificativo del modello: WF5I8043BWF

Parametri di prodotto generali:

Parametro	Valore		Parametro	Valore	
Capacità nominale (kg)	8,0		Dimensioni in cm	Altezza	85
				Larghezza	60
				Profondità	47
Indice di efficienza energetica w	36,4	Classe di efficienza energetica	A		
Indice di efficienza di lavaggio	1,031	Efficacia di risciacquo (g/kg)	5,00		
Consumo di energia in kWh per ciclo, basato sul programma eco 40-60. Il consumo effettivo di energia dipende dalle modalità d'uso dell'apparecchiatura.	0,331	Consumo di acqua in litri per ciclo, basato sul programma eco 40-60. Il consumo effettivo di acqua dipende dalle modalità d'uso dell'apparecchiatura e della durezza dell'acqua.	38		
Temperatura massima all'interno dei tessuti trattati (°C)	Capacità nominale	29	Umidità residua ponderata (%)	51,3	
	Metà	29			
	Un quarto	23			
Velocità della centrifuga (h:min)	Capacità nominale	1400	Classe di efficienza della centrifuga -asciugatura	B	
	Metà	1400			
	Un quarto	1400			
Durata del programma (h:min)	Capacità nominale	3:38	Tipo di apparecchiatura	A libera installazione	
	Metà	2:48			
	Un quarto	2:46			
Emissioni di rumore aereo durante la fase di centrifuga (dB (A) re 1 pW)	72	Classe di emissioni di rumore aereo nella fase di centrifuga	A		
Modo spento (W)	0,49	Modo stand-by (W)	-		
Avvio ritardato (W)	4,00	Modo stand-by in rete (W)	2,00		
Durata minima della garanzia offerta dal fornitore: 24 mesi					
Questo prodotto è stato progettato per liberare ioni d'argento durante il ciclo di lavaggio			No		
Informazioni aggiuntive:					
https://www.hisense-europe.com/					

Detailed product data sheet for the Hisense WF5I8043BWF, providing comprehensive technical specifications including dimensions, energy efficiency, spin speed, and warranty information. For more details, visit the [EU EPREL database](#).

8. WARRANTY AND SUPPORT

Your Hisense WF5I8043BWF washing machine comes with a **24-month manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical assistance, spare parts, or further information, please visit the official Hisense website:
<https://www.hisense-europe.com/>

© 2025 Hisense. All rights reserved.