

Simfer B6006EERF

Simfer Electric Built-in Oven 60cm, 64 Liters - Model B6006EERF User Manual

This manual provides essential information for the safe and efficient use of your Simfer Electric Built-in Oven. Please read it thoroughly before installation, operation, or maintenance.

1. INTRODUCTION

Thank you for choosing a Simfer appliance. This electric built-in oven is designed to provide reliable performance and ease of use for all your cooking needs. To ensure optimal performance and safety, please follow the instructions carefully. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

Always adhere to basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, burns, or injury.

- **Electrical Safety:** Ensure the oven is properly grounded. Do not operate with a damaged cord or plug. Disconnect power before servicing.
- **Child Safety:** Keep children away from the oven during operation and cooling. The oven surfaces become hot.
- **Hot Surfaces:** Use oven mitts when handling hot dishes or oven components. Do not touch heating elements.
- **Proper Ventilation:** Ensure adequate ventilation around the built-in oven as per installation instructions.
- **Flammable Materials:** Do not store flammable materials in or near the oven.
- **Cleaning:** Always allow the oven to cool before cleaning. Use non-abrasive cleaners.
- **Installation:** Installation must be performed by a qualified technician in accordance with local regulations.

3. PRODUCT OVERVIEW

Your Simfer Electric Built-in Oven is equipped with various features for versatile cooking. Below is a general view of the appliance.



Figure 3.1: Front view of the Simfer Electric Built-in Oven, showcasing the control panel, oven door, and handle.

The oven features a robust aluminum handle, push-pull control knobs for a sleek finish, and a triple-layer glass door for improved insulation and safety. An interior light allows for easy monitoring of your cooking progress.

4. INSTALLATION GUIDE

This oven is designed for built-in installation into a kitchen cabinet. Proper installation is crucial for safety and optimal performance.

4.1 Electrical Connection

- Ensure the electrical supply matches the voltage and frequency specified on the oven's rating plate (2300 Watts).
- The oven must be connected to a properly grounded outlet.
- Do not use extension cords or adapters.

4.2 Cabinet Integration

- Prepare the cabinet opening according to the dimensions provided in the specifications section.
- Ensure there is sufficient space for ventilation at the rear and sides of the oven.

- Secure the oven to the cabinet using the provided screws and brackets to prevent tipping.

5. OPERATING YOUR OVEN

This section details how to use the various functions and controls of your Simfer oven.

5.1 Control Panel

The oven features push-pull knobs for function selection and temperature control, along with a mechanical timer. To use a knob, push it in, turn to the desired setting, and release.

5.2 Oven Functions

Your oven offers 7 cooking functions, including:

- **Upper and Lower Heating:** Ideal for traditional baking and roasting.
- **Convection (Turbo Fan):** Distributes heat evenly for faster and more consistent cooking.



Figure 5.1: Illustration of the convection fan distributing hot air throughout the oven cavity for even cooking.

- **Grill:** For browning and toasting.
- **Defrost:** Gently thaws frozen foods using the fan without heat.
- **Chicken Rotisserie:** For roasting poultry evenly.

5.3 Setting the Mechanical Timer

Turn the timer knob to the desired cooking duration. The oven will automatically switch off once the set time has elapsed, indicated by an audible signal.

5.4 Preheating

For best results, preheat the oven to the desired temperature before placing food inside. This typically takes 10-15 minutes depending on the selected temperature and function.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your oven and ensure hygienic operation.

6.1 General Cleaning

- Always ensure the oven is cool and disconnected from the power supply before cleaning.
- Wipe the exterior surfaces with a soft cloth and mild detergent.
- For the interior, use a damp cloth and a non-abrasive oven cleaner. Avoid spraying cleaner directly onto electrical components.



Figure 6.1: Cleaning the oven interior with a soft cloth after use. Ensure the oven is cool.

6.2 Removable Door Glass

The oven features a triple-layer glass door that can be disassembled for thorough cleaning.

- Carefully open the oven door fully.
- Follow the specific instructions in the full manual for releasing the inner glass panels.
- Clean the glass panels with warm soapy water or a glass cleaner.
- Reassemble the glass panels securely before closing the door.



Figure 6.2: The oven door's triple-layer glass can be removed for easy and thorough cleaning.

6.3 Replacing the Oven Light

If the oven light needs replacement, ensure the oven is cool and unplugged. Unscrew the protective cover, replace the bulb with a suitable high-temperature oven bulb, and reattach the cover.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Oven does not heat up.	No power supply; oven not switched on; timer not set.	Check power connection; ensure function and temperature knobs are set; set the mechanical timer.
Oven light not working.	Bulb is faulty or loose.	Replace the oven bulb (refer to section 6.3).
Uneven cooking.	Incorrect rack position; oven not preheated; too much food.	Use recommended rack positions; preheat oven fully; avoid overcrowding.

8. TECHNICAL SPECIFICATIONS

Below are the key technical specifications for your Simfer Electric Built-in Oven Model B6006EERF.

Feature	Specification
Brand	Simfer
Model Number	B6006EERF
Type	Electric Built-in Oven
Size	60 cm
Capacity	64 Liters
Power Output	2300 Watts
Heating Method	Convection
Functions	7 (e.g., Upper/Lower Heating, Convection, Grill, Defrost)
Timer Type	Mechanical Timer
Door Type	Triple-layer removable glass
Special Features	Cooling fan, Turbo fan, Push-pull knobs, Aluminum handle, Interior light, Automatic defrost
Item Weight	35 kg
Finish Type	Polished
Door Orientation	Front Part

9. WARRANTY AND CUSTOMER SUPPORT

Your Simfer Electric Built-in Oven Model B6006EERF comes with a **3-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical assistance, or spare parts, please contact Simfer customer support. Keep your purchase receipt as proof of purchase.

Customer Support: Please refer to the contact information provided with your purchase documentation or visit the official Simfer website for regional support details.