

Teioe M7

Teioe Mini Electric Space Heater M7 Instruction Manual

Model: M7

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this Teioe Mini Electric Space Heater. Failure to follow these instructions may result in fire, electric shock, injury to persons, or property damage.

- **Overheat Protection:** The heater is equipped with an automatic overheat protection system. If the heater overheats, it will automatically shut off. Unplug the heater and allow it to cool down for 30 minutes before restarting.
- **Tip-Over Protection:** For enhanced safety, the heater features a tip-over switch. If the heater is accidentally tipped over, it will automatically shut off. Place the heater on a firm, level surface to ensure proper operation.
- **Flame Retardant Material:** The product casing is constructed from flame retardant material for added safety.
- **8-Hour Auto Power-Off:** The heater includes an 8-hour automatic power-off function for energy efficiency and safety.
- **30-Second Delay Shutdown:** After turning off, the fan will continue to run for 30 seconds to cool down the heating elements, extending product lifespan.
- **General Precautions:**
 - Do not cover the heater.
 - Keep flammable materials such as furniture, paper, clothing, and curtains at least 3 feet (0.9 meters) away from the front of the heater and away from the sides and rear.
 - Do not use in wet or damp locations.
 - Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

Tip-Over & Tilt Protection

Auto shut-off & a buzze alarm will sound when tip-over or tilt.

Overheat Protection

Auto shut-off when overheat.



235°F (113°)

149°F (65°)

Beep
beep...



Image: The Teioe Mini Electric Space Heater illustrating its tip-over and overheat protection features. The image shows the heater tilting and a thermometer icon indicating temperature thresholds for automatic shut-off.

2. PRODUCT OVERVIEW

The Teioe Mini Electric Space Heater M7 is a compact and efficient heating solution designed for personal spaces. It utilizes advanced PTC ceramic heating elements to provide rapid warmth.

Key Features:

- **Fast & Powerful Heating:** Heats up to 70°F in 3 seconds.
- **3 Operating Modes:** High heat (800W), Low heat (400W), and Natural wind mode.
- **Portable & Quiet:** Lightweight (1.6 pounds) with a pure leather handle for easy transport. Operates at less than

45dB.

- **Mini Retro Design:** Stylish appearance suitable for various home and office settings.

Teioe®

CERAMIC HEATER



Safety Features



8H Automatic
Shutdown



30S Delay
Shutdown



3 Operation
Modes



Lightweight



Image: A front view of the Teioe Mini Electric Space Heater, highlighting its compact dimensions (8.3 inches wide, 5.5 inches high) and key features like safety, 8H automatic shutdown, 30S delay shutdown, 3 operation modes, and lightweight design.

RETRO DESIGN



Pure Leather Handle



Silicone Anti-slip Pad



Electroplating Switch



Flame Retardant Material

Image: Detailed views of the Teioe Mini Electric Space Heater, showcasing its pure leather handle, silicone anti-slip pads, electroplating switch, and flame retardant material.

LOW NOISE <40dB

Low noise design gives you a comfortable and friendly environment



Image: The Teioe Mini Electric Space Heater operating quietly in a bedroom, with a sleeping person in the background, illustrating its low noise level (less than 40dB).



Image: A collage showing the Teie Mini Electric Space Heater in different environments: an office, living room, bedroom, and reading room, demonstrating its versatility for personal heating.

3. SETUP

1. **Unpack:** Carefully remove the heater from its packaging.
2. **Placement:** Place the heater on a firm, level, and stable surface. Ensure there is at least 3 feet (0.9 meters) of clear space around the front, sides, and rear of the heater to avoid obstruction and fire hazards.
3. **Power Connection:** Plug the heater directly into a 120V AC electrical outlet. Do not use extension cords or power strips.

4. OPERATING INSTRUCTIONS

The Teioe Mini Electric Space Heater offers three operating modes for customized comfort.

1. **Power On:** Ensure the heater is placed on a flat, stable surface. Turn the rotation button to the desired mode.
2. **Select Mode:**
 - **Natural Wind Mode:** Provides a gentle fan-only operation without heat.
 - **Low Heat Mode (400W):** Delivers a moderate level of warmth.
 - **High Heat Mode (800W):** Provides maximum heating power for rapid warmth.
3. **Power Off:** Turn the rotation button to the 'OFF' position. The fan will continue to run for 30 seconds to cool down the heating elements before completely shutting off.

3 Seconds Fast Heating

Adopt safety PTC ceramic heating technology
quickly heat up to 70°F



Image: The Teioe Mini Electric Space Heater with its control dial, illustrating the three operation modes: Cool Air, 400W Heat, and 800W Heat. The image also highlights its 3-second fast heating capability.

Video: An official product video from Teioe demonstrating the small portable space heater in an office setting, showcasing its compact size and ease of use.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to keep the original packaging for storage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in correctly.	Ensure the power cord is securely plugged into a 120V AC outlet.
Heater does not turn on.	Tip-over switch activated.	Place the heater on a firm, level surface. The heater will not operate if the tip-over switch is not fully engaged.
Heater turns off unexpectedly.	Overheat protection activated.	Unplug the heater and allow it to cool down for 30 minutes. Ensure there are no obstructions blocking the air intake or exhaust.
Heater turns off unexpectedly.	8-hour auto power-off activated.	This is a normal safety feature. Simply turn the heater back on if continued operation is desired.

7. SPECIFICATIONS

- **Brand:** Teioe
- **Model Number:** M7
- **Color:** GREY
- **Product Dimensions:** 3.1"D x 5.5"W x 8.3"H
- **Item Weight:** 1.6 pounds
- **Power Output:** 800W (High Heat), 400W (Low Heat)
- **Voltage:** 120 Volts
- **Number of Speeds:** 3 (Natural Wind, Low Heat, High Heat)

- **Heating Coverage:** ~50-100 square feet
- **Special Features:** Energy Efficient, Lightweight, Overheat Protection, Portable, Tip-Over Protection
- **Room Type:** Bedroom, Home Office, Study Room
- **Indoor/Outdoor Usage:** Indoor Only

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Teioe customer service. Keep your purchase receipt for any warranty claims.

© 2026 Teioe. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question