Ariete 2854/02

Ariete 2854 Modern Electric Kettle Instruction Manual

Model: 2854/02

1. Introduction

Thank you for choosing the Ariete 2854 Modern Electric Kettle. This powerful and stylish appliance is designed to quickly and efficiently boil water for your favorite hot beverages. Featuring a 1.7-liter capacity, 2000W power, a 360° cordless base, an integrated thermometer, and an automatic shut-off system, it combines convenience with safety. Please read this manual carefully before first use and keep it for future reference.



Image 1.1: The Ariete 2854 Modern Electric Kettle in black, showcasing its sleek design and integrated thermometer.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot water.
- The kettle is equipped with an automatic shut-off system. Do not attempt to override this feature.
- Ensure the lid is securely closed before operating.

3. Product Overview

Familiarize yourself with the components of your Ariete electric kettle:

1. Kettle Body
2. Lid
3. Handle
4. Spout with Removable Filter
5. Water Level Indicator
6. Integrated Thermometer
7. Power Switch (On/Off Lever)
8. 360° Cordless Power Base



Image 3.1: The Ariete 2854 kettle positioned on its base in a kitchen environment, ready for use.

4. Setup and First Use

4.1 Unpacking

Carefully remove the kettle and all accessories from the packaging. Dispose of packaging materials responsibly.

4.2 Before First Use

Before using your kettle for the first time, it is recommended to boil a full kettle of water and discard it at least twice to remove any manufacturing residues.

1. Fill the kettle with water up to the MAX mark.
2. Place the kettle securely on its power base.
3. Plug the power base into a suitable electrical outlet.
4. Press the power switch down to start boiling. The indicator light will illuminate.

5. The kettle will automatically switch off once the water boils.
6. Discard the boiled water. Repeat this process at least once more.

5. Operating Instructions

5.1 Filling the Kettle

Open the lid and fill the kettle with the desired amount of water. Do not fill below the MIN mark or above the MAX mark indicated on the water level indicator. Ensure the lid is firmly closed before placing the kettle on the base.

5.2 Boiling Water

1. Place the filled kettle onto the 360° cordless power base.
2. Plug the power base into a standard electrical outlet.
3. Push the power switch lever downwards. The indicator light will turn on, signifying that the kettle is heating.
4. The kettle will automatically switch off once the water reaches boiling point (100°C / 212°F). The power switch will return to the 'off' position and the indicator light will turn off.
5. You can also manually switch off the kettle at any time by pushing the power switch lever upwards.





Image 5.1: Demonstrates the kettle being lifted from its 360° cordless base, highlighting its portability.

5.3 Using the Integrated Thermometer

The Ariete 2854 kettle features an integrated thermometer on the front of the kettle body. This allows you to monitor the water temperature as it heats up, providing precision for various hot beverages that require specific temperatures, such as green tea or coffee.


40
60
80
104
140
176
212
100
°C
°F
Temp.
Ariete

Image 5.2: A detailed view of the kettle's built-in thermometer, showing temperature readings.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle and ensure optimal performance.

6.1 General Cleaning

- Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Never immerse the kettle body or the power base in water or any other liquid.

6.2 Cleaning the Removable Filter

The kettle is equipped with a removable filter located behind the spout, which helps to prevent limescale particles from being poured into your cup. Clean the filter regularly, especially in areas with hard water.

1. Ensure the kettle is cool and unplugged.
2. Open the lid and carefully pull the filter upwards to remove it from its slot.
3. Rinse the filter under running water and gently brush away any deposits.
4. Once clean, reinsert the filter into its slot until it clicks into place.



Image 6.1: Illustrates the process of removing the filter from the kettle's spout for cleaning.

6.3 Descaling

Limescale buildup can affect the kettle's performance and lifespan. Descale your kettle regularly (monthly for hard water

areas, every 2-3 months for soft water areas).

- Fill the kettle with a mixture of white vinegar and water (1:2 ratio) or a commercial descaling solution according to product instructions.
- Bring the mixture to a boil and then let it stand for at least 30 minutes, or longer for heavy buildup.
- Empty the kettle and rinse thoroughly with fresh water several times.
- Boil fresh water in the kettle 2-3 times and discard to remove any residual descaling solution taste.

7. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in. Power switch not engaged. Kettle not properly seated on base. No water or too little water.	Ensure power base is plugged into a working outlet. Push the power switch lever down. Ensure the kettle is correctly placed on the power base. Fill the kettle with water above the MIN mark.
Kettle switches off too soon.	Limescale buildup. Lid not closed properly.	Descale the kettle as per Section 6.3. Ensure the lid is securely closed.
Water has an unusual taste.	First use residues. Limescale buildup.	Perform the "Before First Use" steps (Section 4.2). Descale the kettle as per Section 6.3.

8. Specifications

Feature	Detail
Brand	Ariete
Model	2854/02
Color	Black
Capacity	1.7 Liters
Power	2000 Watts
Dimensions (L x W x H)	22 x 22 x 20 cm
Item Weight	1.4 Kilograms
Special Features	Water temperature thermometer, 360° cordless base, Ergonomic handle, Water level indicator, Automatic shut-off

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the

official Ariete website. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may contact Ariete customer service through their official channels. You can find more information about Ariete products and support at the Ariete Store on Amazon.

© 2024 Ariete. All rights reserved.