

ENJOY-UNIQUE Keyboard Cover

ENJOY-UNIQUE Universal Tablet Case with QWERTY Keyboard User Manual

Model: Keyboard Cover

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your ENJOY-UNIQUE Universal Tablet Case with QWERTY Keyboard. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

The ENJOY-UNIQUE Universal Tablet Case is designed to protect your tablet while offering the convenience of a wired QWERTY keyboard. It is compatible with a wide range of 9 to 11-inch Android tablets and features a built-in stand for comfortable viewing and typing.

SETUP INSTRUCTIONS

1. Unpacking the Product

Carefully remove the tablet case and keyboard from its packaging. Ensure all components are present: the tablet case with integrated keyboard and the USB-C adapter.

2. Inserting Your Tablet

1. Open the tablet case.
2. Position your tablet within the case, ensuring it fits securely within the adjustable corner buckles. The buckles are designed to hold tablets ranging from 9 to 11 inches.
3. Adjust the buckles to firmly grip the corners of your tablet, preventing it from slipping.

Buckle design, can fix your tablet well



Image: The tablet case open, showing the adjustable corner buckles and overall dimensions (285mm length x 190mm width).

3. Connecting the Keyboard

The keyboard is wired and connects directly to your tablet via a USB port. The case includes a Micro USB cable and a USB-C adapter for compatibility with various tablet models.

1. Identify the charging/data port on your tablet.
2. If your tablet has a Micro USB port, plug the keyboard's Micro USB cable directly into your tablet's port.
3. If your tablet has a USB-C port, attach the provided USB-C adapter to the keyboard's Micro USB cable, then plug the adapter into your tablet's USB-C port.
4. The keyboard is plug-and-play and should be recognized by your Android tablet automatically. No additional drivers are typically required.



Image: Close-up of the keyboard's Micro USB cable and the included USB-C adapter, illustrating connectivity options.

OPERATING INSTRUCTIONS

1. Using the Keyboard

Once connected, the QWERTY keyboard functions like a standard external keyboard. You can use it for typing documents, emails, messages, and navigating your tablet's interface.

- **Typing:** Simply open any text input field on your tablet and begin typing.
- **Special Keys:** The keyboard includes standard QWERTY layout keys. Some function keys (F1-F12) may have secondary functions depending on your tablet's operating system.
- **Language Input:** To change the keyboard input language on your tablet, refer to your tablet's Android settings under "Language & Input."

2. Using the Stand Function

The case features a built-in stand for hands-free viewing and typing.

1. Fold the back cover of the case to create a triangular support.
2. Rest the tablet (still secured in the case) against this folded support.
3. Adjust the angle for optimal viewing or typing comfort.

Design with stand, keyboard in QWERTY layout



Image: The tablet case configured as a stand, with a tablet inserted and the QWERTY keyboard visible.

MAINTENANCE

1. Cleaning the Case

The synthetic leather material is durable and easy to clean.

- Wipe the exterior of the case with a soft, damp cloth.
- For stubborn stains, use a mild soap solution and then wipe clean with a damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the material.

2. Cleaning the Keyboard

- Use a soft brush or compressed air to remove dust and debris from between the keys.
- Wipe the keycaps with a slightly damp, lint-free cloth.
- Ensure the keyboard is disconnected from the tablet before cleaning.

3. Storage

When not in use, store the tablet case and keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding.	- Loose connection. - Incorrect adapter used. - Tablet settings issue.	- Ensure the Micro USB cable and/or USB-C adapter are securely plugged into both the keyboard and the tablet. - Verify you are using the correct adapter for your tablet's port (Micro USB or USB-C). - Restart your tablet. Check your tablet's "Language & Input" settings to ensure an external keyboard is recognized.
Keys are not typing correctly (e.g., wrong characters).	- Incorrect keyboard layout selected on tablet. - Physical debris under keys.	- Go to your tablet's "Language & Input" settings and ensure the correct QWERTY keyboard layout is selected. - Clean the keyboard as described in the Maintenance section.
Tablet does not fit securely in the case.	- Tablet size outside specified range. - Buckles not adjusted properly.	- Verify your tablet's screen size is between 9 and 11 inches. - Ensure the adjustable corner buckles are stretched and positioned firmly around all four corners of your tablet.

SPECIFICATIONS

Brand	ENJOY-UNIQUE
Model Number	Keyboard Cover
Product Type	Universal Tablet Case with Wired Keyboard
Color	Black
Compatible Tablet Sizes	9 to 11 inches
Case Dimensions (L x W)	285 mm x 190 mm (11.2" x 7.4")
Keyboard Layout	QWERTY
Connectivity	Wired (Micro USB with USB-C adapter)
Compatible OS	Android
Special Features	Built-in stand, durable synthetic leather, plug-and-play keyboard

WARRANTY AND SUPPORT

Information regarding manufacturer's warranty is not available in the product details. For any product-related inquiries or support, please contact the seller directly through the platform where the purchase was made.

Manufacturer: ENJOY-UNIQUE

Country of Origin: China

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question