

[Manuals.plus](#) /

› [ENJOY-UNIQUE](#) /

› 9/9.7/10/10.1 inch Tablet Keyboard Case Cover Universal Keyboard Case for 9" 10" 10.1" Tablet with USB-C Port External Keyboard

ENJOY-UNIQUE Keyboard Cover

Universal Tablet Keyboard Case User Manual

Model: Keyboard Cover | Brand: ENJOY-UNIQUE

INTRODUCTION

Thank you for choosing the ENJOY-UNIQUE Universal Tablet Keyboard Case. This product is designed to provide protection for your 9-10.1 inch Android tablet while offering the convenience of an external keyboard. Made from durable faux leather, it enhances your tablet's functionality for typing wherever and whenever needed.



Image: The keyboard case with a tablet, demonstrating its standing function for comfortable viewing and typing.

SETUP

1. **Unpack the Keyboard Case:** Carefully remove the keyboard case from its packaging.
2. **Insert Your Tablet:** Open the case and gently slide your 9-10.1 inch Android tablet into the designated area. Ensure the tablet is securely held by the corner buckles.
3. **Connect the Keyboard:** Locate the USB-C cable extending from the keyboard. Plug this cable into the USB-C port on your tablet.

Micro USB port + Type C adapter ,
Support for 9 - 10.8" Android Tablet



+



Image: Detail showing the Micro USB port and the included Type-C adapter for connecting the keyboard to your tablet.

4. **Position for Use:** Utilize the built-in stand to prop up your tablet at a comfortable viewing angle.

OPERATING INSTRUCTIONS

The keyboard features a standard QWERTY layout, providing a familiar typing experience. Once connected, your tablet should automatically recognize the external keyboard.

- **Typing:** Begin typing directly into any text field on your tablet.
- **Function Keys:** The top row of keys includes function keys (F1-F12) which may have secondary functions (e.g., volume control, media playback) depending on your tablet's operating system. These are typically accessed by pressing the **Fn** key simultaneously with the desired function key.

- **Standing Function:** The integrated stand allows you to position your tablet for hands-free viewing or typing. Simply fold out the stand from the back of the case.

Design with stand, keyboard in QWERTY layout



Image: The case in standing mode, highlighting the QWERTY keyboard layout for efficient typing.

- **Magnetic Closure:** When not in use, the case can be securely closed using its magnetic button closure, protecting your tablet.



Image: The case closed, secured by its magnetic button, providing full protection.

MAINTENANCE

- **Cleaning the Case:** Wipe the faux leather exterior with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Cleaning the Keyboard:** Use a soft brush or compressed air to remove dust and debris from between the keys. A slightly damp cloth can be used to wipe the keycaps.
- **Storage:** When not in use, store the keyboard case in a clean, dry environment away from extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Keyboard not typing.	• Ensure the USB-C cable is securely connected to both the keyboard and your tablet. • Restart your tablet. • Check your tablet's settings to ensure external keyboards are enabled.
Keys are sticky or unresponsive.	• Clean the keyboard as described in the Maintenance section. • Avoid spilling liquids on the keyboard.
Tablet does not fit securely.	• This case is designed for 9-10.1 inch tablets. Ensure your tablet's size is within this range. • Adjust the corner buckles to firmly hold the tablet.

SPECIFICATIONS

- **Product Dimensions:** 11.22 x 7.48 x 11.22 inches
- **Item Weight:** 15.1 ounces
- **Manufacturer:** ENJOY-UNIQUE
- **Item Model Number:** Keyboard Cover
- **Compatible Devices:** 9-10.1 inch Android Tablets
- **Connectivity Technology:** USB-C (via adapter, originally Micro USB)
- **Keyboard Description:** Tablet Keyboard Case Cover with USB-C External
- **Color:** Black
- **Number of Keys:** 78
- **Style:** Modern
- **Material:** Faux Leather
- **Included Components:** USB Cable
- **Power Source:** Corded Electric (powered by tablet)

Buckle design, can fix your tablet well



Image: Visual representation of the case dimensions and the tablet securing buckles.

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For support or warranty inquiries, please contact the seller or manufacturer directly through your purchase platform.

© 2024 ENJOY-UNIQUE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question