

## sparefixd 00706427

# sparefixd Door & Hinge Assembly Instruction Manual

For Bosch Tumble Dryers - Part Number 00706427

## 1. PRODUCT OVERVIEW

---

This manual provides instructions for the sparefixd Door & Hinge Assembly, a replacement part designed for various Bosch Tumble Dryer models. This assembly includes the complete door unit and its associated hinge mechanism, ensuring proper function and secure closure of your appliance.

**Part Number:** 00706427

## 2. COMPATIBILITY

---

This sparefixd Door & Hinge Assembly is compatible with a wide range of Bosch Tumble Dryer models. To ensure compatibility, verify your appliance's model number, which is typically found inside the door, on the casing, or at the rear of the appliance. The model number consists of numbers and letters printed or stamped on a sticker or plate.

**Examples of compatible models include:**

- WTE84101NL30, WTE84101NL35, WTE84101SN05
- WTE84102GB03, WTE84102GB05, WTE84102GB07
- WTE84103FG30, WTE84103FG35, WTE84103FG36
- WTE84104NL30, WTE84104NL35, WTE84104NL36
- WTE84105AU46, WTE84105GB48, WTE84105NL46
- WTE84106GB48, WTE84106GC48, WTE84106ZA48
- WTE84107DN48, WTE84107EE45, WTE84107EE47
- WTE84120BY03, WTE84120BY05, WTE84120FG01
- WTE84160FG03, WTE84160FG05, WTE84160SK02
- WTE84170NL01, WTE84170NL02, WTE84173NL30
- WTE8418001, WTE8418101, WTE8418205
- WTE8430005, WTE84300FF01, WTE8430103
- WTE84381SN02, WTE84382SN08, WTE84383NL40

This list is not exhaustive. Refer to the product description or contact sparefixd support for a complete list of compatible models.

### 3. INSTALLATION INSTRUCTIONS

---

**Safety First:** Before beginning any installation, ensure the tumble dryer is disconnected from the main power supply. Failure to do so may result in electric shock or injury. If you are unsure about any step, consult a qualified appliance technician.

#### Required Tools:

- Screwdriver set (Phillips and Flathead)
- Pliers (optional, for stubborn connections)
- Work gloves (recommended)

#### Step-by-Step Guide:

1. **Prepare the Appliance:** Disconnect the dryer from the power outlet. Move the dryer to an area with sufficient space to work around it.
2. **Remove the Old Door:**
  - Open the dryer door.
  - Locate the screws or fasteners securing the hinge assembly to the dryer's front panel.
  - Carefully remove these screws. Support the door as you remove the last fasteners to prevent it from falling.
  - Once all fasteners are removed, detach the old door and hinge assembly from the dryer.
3. **Install the New Door & Hinge Assembly:**
  - Align the new sparefixd Door & Hinge Assembly with the mounting points on the dryer's front panel.
  - While supporting the new door, insert the first few screws to hold it in place. Do not tighten them fully yet.
  - Insert and partially tighten all remaining screws for the hinge assembly.
  - Once all screws are in place, tighten them securely, ensuring the door is firmly attached and aligned. Do not overtighten.
4. **Test the Door:** Gently open and close the new door several times to ensure it operates smoothly, latches securely, and seals properly against the dryer opening. Check for any gaps or misalignment.
5. **Reconnect Power:** Once satisfied with the installation, reconnect the dryer to the main power supply.



Image 1: Front view of the sparefixd Door & Hinge Assembly, showing the smooth white exterior.



Image 2: Rear view of the sparefixd Door & Hinge Assembly, highlighting the robust hinge mechanism for attachment to the dryer.



Image 3: Rear view of the sparefixd Door & Hinge Assembly, detailing the latch components that secure the door when closed.

## 4. OPERATING INSTRUCTIONS

---

Once installed, the sparefixd Door & Hinge Assembly operates identically to the original dryer door. Ensure the door is fully closed and latched before starting a drying cycle. If the door is not properly closed, the dryer may not start or may display an error code.

## 5. MAINTENANCE

---

Regular maintenance helps prolong the life of your dryer door and hinge assembly:

- **Cleaning:** Periodically wipe down the door and surrounding areas with a soft, damp cloth. Avoid abrasive cleaners that could damage the finish.
- **Hinge Inspection:** Every few months, visually inspect the hinges for any signs of wear, looseness, or corrosion. If screws appear loose, gently tighten them.
- **Seal Check:** Ensure the door seal (gasket) around the opening is clean and free from debris. A damaged or dirty seal can affect drying efficiency and lead to heat loss.

## 6. TROUBLESHOOTING

---

If you encounter issues after installing the door assembly, consider the following:

- **Door Not Closing/Latching:** Check for any obstructions around the door frame or latch mechanism. Ensure the hinge screws are tightened correctly and the door is properly aligned.
- **Door Squeaks:** A small amount of silicone-based lubricant can be applied to the hinge pins if squeaking occurs. Avoid oil-based lubricants that can attract dust.
- **Dryer Not Starting:** Many dryers have a safety switch that prevents operation if the door is not fully closed and latched. Ensure the door is securely shut. If the issue persists, the door latch switch itself might require inspection by a professional.

For persistent issues, contact a qualified appliance repair technician.

## 7. SPECIFICATIONS

---

<b>Brand</b>	sparefixd
<b>Manufacturer Reference</b>	00706427
<b>Form Factor</b>	Front Load
<b>Access Location</b>	Front Load
<b>Door Orientation</b>	Reversible

## 8. WARRANTY AND SUPPORT

---

For information regarding warranty coverage or technical support for your sparefixd Door & Hinge Assembly, please refer to the documentation provided with your purchase or contact sparefixd customer service directly. Keep your purchase receipt as proof of purchase.