

[manuals.plus](#) /› [Kalorik](#) /› [Team Kalorik TKG SKV 1006 Cordless Stick Vacuum Cleaner User Manual](#)

Kalorik TKG SKV 1006

Team Kalorik TKG SKV 1006 Cordless Stick Vacuum Cleaner User Manual

Model: TKG SKV 1006

INTRODUCTION

Thank you for choosing the Team Kalorik TKG SKV 1006 Cordless Stick Vacuum Cleaner. This appliance is designed for versatile cleaning, functioning as both a powerful stick vacuum and a convenient handheld unit, with an integrated wet cleaning system. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power adapter is compatible with your local power supply.
- Do not immerse the motor unit in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not vacuum liquids, hot ashes, sharp objects, or flammable/combustible materials.
- Use only the charging adapter supplied with the appliance.
- Store the appliance indoors in a dry place.
- This appliance is for household use only.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the parts of your Team Kalorik TKG SKV 1006 vacuum cleaner.



Image: All components of the Team Kalorik TKG SKV 1006 vacuum cleaner. This includes the main motor unit, extension tube, floor brush with LED light, handheld nozzle, charging adapter, and a mop pad for wet cleaning.

1. **Main Motor Unit:** Contains the dustbin, motor, and battery. Functions as the handheld vacuum.
2. **Extension Tube:** Connects the main unit to the floor brush for stick vacuum operation.
3. **Floor Brush with LED Light:** For general floor cleaning, features an integrated LED light to illuminate dust.
4. **Handheld Nozzle/Crevice Tool:** For precise cleaning in tight spaces.
5. **Charging Adapter:** For recharging the appliance's battery.
6. **Water Tank (Removable):** For the wet cleaning function.
7. **Mop Pad:** Attaches to the floor brush for wet cleaning.
8. **Multi-filtration System:** Located within the dustbin for efficient dust separation.
9. **Rotary Handle:** Ergonomically designed for comfortable use.
10. **Charge Indicator Light:** Displays battery status.

SETUP

Assembly

To assemble the stick vacuum:

1. Insert the extension tube into the main motor unit until it clicks into place.
2. Attach the floor brush to the other end of the extension tube, ensuring it is securely fastened.
3. For handheld use, attach the handheld nozzle directly to the main motor unit.

Charging the Battery

Before first use, fully charge the appliance for approximately 4 hours.

- Connect the charging adapter to the charging port on the main motor unit.
- Plug the adapter into a wall outlet.
- The charge indicator light will illuminate during charging and change when fully charged.
- The appliance features an anti-tilt function, but for stable charging, ensure it is placed securely.

OPERATING INSTRUCTIONS





Image: The Team Kalorik TKG SKV 1006 vacuum cleaner configured for handheld use, demonstrating its compact form.

Dry Vacuuming

To begin dry vacuuming:

- Ensure the dustbin is empty and the filters are clean.
- Press the power button to turn on the vacuum.
- For stick vacuuming, use the assembled unit with the floor brush. The LED light on the brush will illuminate the cleaning path.
- For handheld vacuuming, detach the main unit and attach the handheld nozzle for targeted cleaning.
- The appliance offers approximately 30 minutes of runtime on a full charge.

Wet Cleaning System

To use the integrated wet cleaning function:

1. Fill the removable water tank with clean water. Do not use harsh chemicals or detergents that could damage the appliance or leave residue.
2. Attach the mop pad securely to the bottom of the floor brush.
3. Ensure the water tank is properly inserted into its designated slot.
4. Operate the vacuum as usual. The wet cleaning system will dispense water onto the mop pad for simultaneous vacuuming and mopping.
5. After use, empty and clean the water tank and mop pad.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

Emptying the Dustbin

- The dustbin has a capacity of 0.5 liters. Empty it regularly, preferably after each use, to maintain suction power.
- Detach the dustbin from the main unit.
- Open the dustbin and dispose of the collected debris.

Cleaning the Filters

- The appliance features a multiple filtration system. Regularly remove and clean the filters.
- Tap filters gently to remove dust or rinse them with cold water if heavily soiled. Ensure filters are completely dry before reinserting.
- Do not use detergents or hot water on filters.

Cleaning the Water Tank and Mop Pad

- After wet cleaning, empty any remaining water from the tank and rinse it thoroughly.
- Remove the mop pad and wash it, either by hand or machine, according to its care instructions.

Cleaning the Floor Brush

- Periodically check the floor brush for tangled hair or debris. Remove any obstructions to ensure smooth operation.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|--|--|
| Vacuum does not turn on. | Battery is depleted. | Charge the battery for 4 hours. |
| Low suction power. | Dustbin is full or filters are clogged. | Empty the dustbin and clean the filters. |
| Water not dispensing during wet cleaning. | Water tank is empty or improperly installed. | Fill the water tank and ensure it is correctly seated. |
| Brush roll not spinning. | Obstruction in the brush roll. | Turn off the vacuum and remove any tangled hair or debris from the brush roll. |

SPECIFICATIONS

- **Model:** TKG SKV 1006
- **Power:** 90 Watts
- **Voltage:** 230 Volts
- **Battery:** Li-Ion 2200 mAh
- **Charge Time:** Approximately 4 hours
- **Runtime:** Up to 30 minutes
- **Dustbin Capacity:** 0.5 Liters
- **Noise Level:** > 68 dB
- **Dimensions (L x W x H):** 24 x 19 x 116 cm
- **Weight:** 2.55 Kilograms
- **Special Features:** Integrated handheld vacuum, wet cleaning system, multiple filtration, rotary handle, floor brush with LED light, anti-tilt function.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

