

[Manuals.plus](#) /

› [GLOBO](#) /

› Globo Ceiling Fan with Lighting - User Manual

GLOBO 03641

Globo Ceiling Fan with Lighting - User Manual

Model: 03641 | Brand: GLOBO

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Globo Ceiling Fan with Lighting (Model 03641). This fan features a 132 cm diameter, 3 speed settings, integrated LED lighting, and is controlled via a remote. The housing is finished in matte nickel with silver/white blades. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.



Figure 1: Overview of the Globo Ceiling Fan with Lighting.

SETUP AND INSTALLATION

Package Contents

Before beginning installation, ensure all components are present:

- Ceiling Fan Unit (Motor, Blades, Light Kit)
- Remote Control
- 2 x AA Batteries (for remote control)
- Mounting Hardware Kit
- Instruction Manual

Installation Guidelines

Installation of this ceiling fan requires electrical wiring knowledge. It is highly recommended that installation be performed by a qualified electrician to ensure safety and compliance with local electrical codes.

1. **Safety First:** Before starting, ensure the power supply to the installation location is turned off at the circuit breaker.
2. **Mounting Bracket:** Securely attach the mounting bracket to a ceiling joist or a fan-rated outlet box. The bracket must be capable of supporting the fan's weight (approximately 7.09 kg).
3. **Wiring:** Connect the fan's electrical wires to the household wiring according to the provided wiring diagram (not included in this general manual, refer to specific diagram in product packaging). This fan operates on 230 Volts.
4. **Assemble Fan:** Attach the fan motor housing to the mounting bracket.
5. **Blade Attachment:** Securely attach the five fan blades to the motor hub. Ensure all screws are tightened.
6. **Light Kit Installation:** Connect and install the LED light kit to the bottom of the fan motor housing.
7. **Remote Control Batteries:** Open the battery compartment of the remote control and insert the two AA batteries, observing polarity.



Figure 2: Illustration of the fan's mounting rod and housing, typical during installation.

OPERATING INSTRUCTIONS

Using the Remote Control

The Globo Ceiling Fan is operated entirely by the included remote control. Ensure the fan has power and the remote control has fresh batteries installed.

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed Control:** Use the speed buttons to cycle through the 3 available fan speeds (Low, Medium, High).
- **Light On/Off:** Press the light button to turn the integrated LED light on or off.
- **Light Dimming (if applicable):** If your model supports dimming, hold the light button to adjust brightness. (Note: This model features an LED lamp with warm white color, dimming capability is not explicitly stated but common for LED).
- **Silent Operation:** This fan is designed for quiet operation, making it suitable for bedrooms and dining rooms.



Figure 3: The fan's central unit, housing the LED light and motor.

MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:**

- Always turn off the power to the fan at the circuit breaker before cleaning.
- Wipe the fan blades (silver/white) and motor housing (matte nickel) with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- Dust the fan regularly to prevent buildup, which can affect performance and balance.
- **Blade Balance:** If the fan wobbles, check that all blade screws are tight and that the blades are not bent or damaged. Balancing kits are available if needed.
- **Light Source:** The fan uses an integrated LED light source. LEDs typically have a long lifespan and do not require frequent replacement. If the light fails, consult a qualified electrician or contact customer support.

TROUBLESHOOTING

If you encounter issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power; loose wiring; remote control issues.	Check circuit breaker. Ensure all wiring connections are secure. Replace remote control batteries.
Light does not turn on.	Loose wiring; faulty LED module.	Check light kit wiring. If LED module is faulty, contact customer support for replacement.
Fan wobbles.	Loose blade screws; unbalanced blades; improper mounting.	Tighten all blade screws. Check for bent blades. Ensure mounting bracket is securely installed.
Remote control not working.	Dead batteries; remote not paired (if applicable); obstruction.	Replace AA batteries. Ensure no obstructions between remote and fan receiver. Refer to pairing instructions if available.

SPECIFICATIONS

Detailed technical specifications for the Globo Ceiling Fan with Lighting (Model 03641):

Feature	Detail
Brand	GLOBO
Model Number	03641
Product Dimensions	132 x 132 x 40 cm (Diameter x Diameter x Height)
Weight	7.09 Kilograms
Motor Power Consumption	Max 40 Watt
Number of Blades	3
Blade Material	Acryl
Blade Color	Silver/White

Feature	Detail
Housing Color / Finish	Matte Nickel
Light Type	Integrated LED
Lampshade Color	Warm White
Maximum Compatible Wattage (Light)	15 Watt
Voltage	230 Volt
Control Method	Remote Control
Special Features	Silent Operation
Included Components	Remote control, Lamp, Light
Batteries Required	2 AA batteries (included)
Power Source	Corded Electric
First Available Date	August 12, 2020



Figure 4: Detailed view of the fan blades and central motor housing, highlighting the matte nickel finish and acrylic blades.



Figure 5: A single fan blade, demonstrating the silver/white color and acrylic material.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or contact the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: GLOBO

For further assistance, please visit the official GLOBO website or contact their customer service department.
