



[Manuals.plus](#) /

› [Onyx Boox](#) /

› ONYX BOOX Poke 2 Color E Ink Kaleido User Manual

## Onyx Boox Poke 2 Color

# ONYX BOOX Poke 2 Color E Ink Kaleido User Manual

Model: Poke 2 Color

## INTRODUCTION

---

The ONYX BOOX Poke 2 Color is an advanced e-reader featuring the innovative E Ink Kaleido color screen technology. Designed for a comfortable reading experience, this device is compact and lightweight, equipped with a powerful 8-core processor, Wi-Fi, and Bluetooth capabilities, running on the Android 9.0 operating system. This manual provides essential information for setting up, operating, and maintaining your device.

## 1. SETUP

---

### 1.1 Unpacking and Initial Charge

Carefully remove your ONYX BOOX Poke 2 Color from its packaging. Before first use, it is recommended to fully charge the device. Connect the included USB cable to the device's USB port and to a compatible power adapter or computer USB port.



Image: Front view of the ONYX BOOX Poke 2 Color e-reader, displaying its screen.

## 1.2 Powering On/Off

To power on the device, press and hold the power button located on the side or top edge until the screen illuminates. To power off, press and hold the power button until a power-off menu appears, then select "Power Off". A short press of the power button will put the device into sleep mode.

## 1.3 Initial Configuration

Upon first power-on, you will be guided through an initial setup process. This typically includes selecting your preferred language, connecting to a Wi-Fi network, and setting the date and time. Follow the on-screen prompts to complete these steps.

## 1.4 Attaching the Protective Case

Your ONYX BOOX Poke 2 Color comes with a high-quality protective case. Align the device with the case and gently press it into place, ensuring all edges are securely fitted. The case helps protect your device from scratches and minor impacts.




Image: The ONYX BOOX Poke 2 Color e-reader shown with its included protective case open.

## 2. OPERATING YOUR DEVICE

---

### 2.1 Navigation and Interface

The ONYX BOOX Poke 2 Color operates on Android 9.0 and features a multi-touch E Ink Kaleido display. Navigate the interface by tapping, swiping, and pinching gestures, similar to a standard Android tablet. The home screen provides access to your library, applications, and settings.




Image: The ONYX BOOX Poke 2 Color e-reader displaying content on its color E Ink screen.

## 2.2 Supported File Formats

The device supports a wide range of file formats for documents, images, and audio:

- **Text/Document:** TXT, HTML, RTF, FB2, FB2.zip, DOC, DOCX, PRC, MOBI, CHM, PDB, DOC, EPUB, PDF, DjVu
- **Image:** JPG, PNG, GIF, BMP
- **Audio:** MP3, WAV
- **Comic:** CBR, CBZ

## 2.3 Connecting Peripherals (OTG)

The ONYX BOOX Poke 2 Color supports USB On-The-Go (OTG), allowing you to connect external peripherals such as USB flash drives or keyboards without requiring additional driver installations. Use a compatible OTG adapter with the device's USB jack.

## 2.4 Display Settings (Moon Light)

The device features Moon Light illumination for comfortable reading in various lighting conditions. Access display settings through the quick settings panel or the main settings menu to adjust brightness and color temperature. Note that the color experience on an E Ink screen differs from a traditional LCD, and some colors may appear less vibrant.

## 3. MAINTENANCE

---

### 3.1 Cleaning the Device

To clean the screen and body of your e-reader, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid using harsh chemicals or abrasive materials, as these can damage the screen or casing.

### 3.2 Battery Care

To prolong battery life, avoid exposing the device to extreme temperatures. Charge the device regularly, but avoid leaving it fully discharged for extended periods. If storing the device for a long time, ensure it has at least a 50% charge.

### 3.3 Software Updates

Periodically check for software updates to ensure optimal performance and access to new features. Updates can typically be found in the device's settings under "System Update" or "About Device." Connect to Wi-Fi before initiating an update.

## 4. TROUBLESHOOTING

---

### 4.1 Device Not Responding

If the device becomes unresponsive, try performing a forced restart by pressing and holding the power button for approximately 10-15 seconds until the device powers off and then restarts.

### 4.2 Wi-Fi Connectivity Issues

If you experience issues connecting to Wi-Fi, ensure your Wi-Fi router is functioning correctly and the password is entered accurately. Try restarting both your e-reader and your Wi-Fi router. You can also try forgetting the network and reconnecting.

### 4.3 File Not Opening

Verify that the file format is supported by the device (refer to Section 2.2). If the format is supported, ensure the file is not corrupted. Try opening another file of the same format or converting the file to a different supported format.

### 4.4 Further Assistance

For more detailed troubleshooting or specific issues, online help videos and resources may be available from the manufacturer. A simple search using your device model name can often provide solutions to common problems.

## 5. SPECIFICATIONS

---

| Feature    | Detail                        |
|------------|-------------------------------|
| Model Name | Poke 2 Color                  |
| Display    | 6" E Ink Kaleido, 4096 colors |
| Resolution | 1072 x 1448 px, 100 ppi       |

| Feature          | Detail   |
|------------------|--|
| Processor        | 8-core, 2 GHz                                  |
| RAM              | 2 GB   |
| Internal Memory  | 32 GB  |
| Operating System | Android 9.0                                    |
| Connectivity     | Wi-Fi, Bluetooth, USB (OTG support)            |
| Dimensions       | 153 x 107 x 6.8 mm (6.02 x 4.21 x 0.27 inches) |
| Weight           | 150 g (0.33 lbs)                               |
| Battery          | Lithium Ion (included)                         |

## 6. WARRANTY AND SUPPORT

---

For detailed warranty information and technical support, please refer to the official ONYX BOOX website or contact their customer service. Keep your proof of purchase for warranty claims.

**Manufacturer:** ONYX BOOX