

[Manuals.plus](#) /

› [Epson](#) /

› Epson 822 DURABrite Ultra Ink Cartridges User Manual

Epson T822XL-BCS

Epson 822 DURABrite Ultra Ink Cartridges User Manual

Model: T822XL-BCS

PRODUCT OVERVIEW

The Epson 822 DURABrite Ultra Ink Cartridges are formulated with fast-drying pigment ink, designed for high-speed print jobs. These cartridges deliver sharp text, bright colors, and print-shop-quality results, ensuring reliable performance for your compatible Epson WorkForce Pro printer.





Image: The Epson 822 DURABrite Ultra Ink Cartridge Combo Pack, showcasing the black high-capacity and standard color cartridges (Cyan, Magenta, Yellow) in their packaging.

COMPATIBLE PRINTERS

These Epson 822 DURABrite Ultra Ink Cartridges are specifically engineered to work with the following Epson WorkForce Pro printer models:

- WorkForce Pro WF-3820
- WorkForce Pro WF-3823
- WorkForce Pro WF-4820
- WorkForce Pro WF-4830
- WorkForce Pro WF-4833
- WorkForce Pro WF-4834

Engineered Specifically for Your Epson Printer

Works with WorkForce® Pro:

WF-3820	WF-4820	WF-4833
WF-3823	WF-4830	WF-4834



Designed for use exclusively with Epson ink cartridges.

Image: An Epson WorkForce Pro printer on a desk, with text indicating that the ink is engineered specifically for Epson printers and listing compatible models: WF-3820, WF-3823, WF-4820, WF-4830, WF-4833, WF-4834.

SETUP AND INSTALLATION

Follow these steps to properly install your Epson 822 DURABrite Ultra Ink Cartridges:

1. **Power On:** Ensure your Epson WorkForce Pro printer is powered on.
2. **Open Ink Cartridge Cover:** Locate and open the ink cartridge access cover on your printer. The print head will move to the replacement position.
3. **Remove Used Cartridge:** If replacing an existing cartridge, gently press the tab on the old cartridge and lift it straight out. Dispose of the used cartridge responsibly.
4. **Unpack New Cartridge:** Carefully remove the new Epson 822 ink cartridge from its packaging. **Do not touch the green chip on the cartridge.**
5. **Insert New Cartridge:** Insert the new cartridge into the correct slot for its color (Black, Cyan, Magenta, or Yellow). Push it down firmly until it clicks into place.

6. **Close Cover:** Close the ink cartridge access cover. The printer will begin initializing the new ink cartridge.

It is recommended to use only genuine Epson cartridges. Use of non-genuine ink could potentially cause damage to your printer and may not be covered under the printer's limited warranty.



Image: A close-up view of Epson 822 ink cartridges (Black, Cyan, Magenta, Yellow) inserted into their respective slots within a printer, illustrating the individual, combo, and high-capacity options.

OPERATING INSTRUCTIONS

Once the ink cartridges are installed, your Epson WorkForce Pro printer is ready for operation. These cartridges are designed for optimal performance with Epson's printing system.

- **Printing Documents:** Send print jobs from your computer or mobile device as usual. The fast-drying pigment ink ensures quick output, especially for high-speed print jobs.
- **Quality Output:** Expect sharp text and vibrant colors for all your documents and images, achieving print-shop-quality results.

- **Ink Levels:** Monitor ink levels through your printer's display or the Epson printer utility software on your computer. Replace cartridges when prompted or when ink levels are low to avoid interruptions.



**Vibrant Colors.
Instant Drying.
Consistent Quality.**

Image: An Epson WorkForce Pro printer in the process of printing, with a document showing vibrant colors and text, emphasizing the "Vibrant Colors. Instant Drying. Consistent Quality." features.

MAINTENANCE

Proper maintenance ensures the longevity of your printer and the quality of your prints when using Epson 822 ink cartridges.

- **Store Cartridges Properly:** Store unopened ink cartridges in their original packaging in a cool, dry place, away from direct sunlight.
- **Regular Printing:** Print regularly to prevent ink from drying in the print head nozzles. If you don't print often, consider printing a test page once a week.
- **Nozzle Check and Head Cleaning:** If print quality declines (e.g., missing lines, faded colors), perform a nozzle check and head cleaning using your printer's utility software or control panel.
- **Genuine Ink:** Always use genuine Epson ink cartridges to maintain optimal print quality and prevent potential damage to

your printer's print head.

TROUBLESHOOTING

Here are some common issues and their solutions related to ink cartridges:

Problem	Solution
Printer not recognizing cartridge:	Remove the cartridge and reinsert it firmly until it clicks. Ensure the green chip is clean and free of debris. If the issue persists, try a new genuine Epson cartridge.
Poor print quality (streaks, faded colors):	Perform a nozzle check and head cleaning cycle through your printer's maintenance utility. Ensure you are using genuine Epson ink.
"Ink Low" or "Replace Ink" message:	Replace the indicated ink cartridge with a new genuine Epson cartridge.
Ink dries out quickly:	Ensure the printer is turned off correctly (using the power button) so the print head is capped. Print regularly to keep nozzles clear.

For more detailed troubleshooting, refer to your specific Epson WorkForce Pro printer's user manual or visit the official Epson support website.

SPECIFICATIONS

Attribute	Detail
Model Number	T822XL-BCS
Ink Type	DURABrite Ultra Pigment Ink
Ink Colors	Black (High Capacity), Cyan, Magenta, Yellow (Standard Capacity)
Page Yield (Black)	Approx. 300 pages (ISO/IEC 24711 and 24712)
Compatible Printer Models	WF-3820, WF-3823, WF-4820, WF-4830, WF-4833, WF-4834
Special Feature	Quick Dry
Item Weight	4.8 ounces
Product Dimensions	2.7 x 3.6 x 6.2 inches

WARRANTY AND SUPPORT

Epson genuine ink cartridges are designed to work seamlessly with your Epson printer. Using non-genuine ink may void your printer's limited warranty if damage occurs as a result.

For comprehensive support, including detailed user manuals for your specific printer model, troubleshooting guides, and contact information, please visit the official Epson support website:

[Epson Official Support](#)

A PDF version of a user manual for this product is also available for download:[Download User Manual \(PDF\)](#)



