

manuals.plus /

› [HOMOOI](#) /

› [HOMOOI L-Shaped Computer Desk User Manual](#)

HOMOOI LCD112001WA

HOMOOI L-Shaped Computer Desk User Manual

Model: LCD112001WA

INTRODUCTION

Thank you for choosing the HOMOOI L-Shaped Computer Desk. This manual provides detailed instructions for assembly, usage, and maintenance to ensure optimal performance and longevity of your desk. Please read this manual thoroughly before beginning assembly and retain it for future reference.



Image: The HOMOOI L-Shaped Computer Desk, showcasing its spacious design with a monitor, laptop, and decorative items. This desk is designed for efficient use of corner spaces in home offices or study areas.

Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Keep all small parts and packaging materials away from children and pets.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload the desk or shelves. Refer to the specifications section for weight capacity.
- Assemble the desk on a soft, clean surface to prevent scratches.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.
- Use only the provided hardware. Using incorrect hardware may compromise stability.

Package Contents

Before assembly, verify that all components are present and undamaged. If anything is missing, please contact customer support.

| Part | Description | Quantity |
|------|-------------|----------|
|------|-------------|----------|

| Part | Description | Quantity |
|------|--|----------|
| A | Main Desktop Panel (Oak Finish) | 1 |
| B | Side Desktop Panel (Black Finish) | 1 |
| C | Metal Frame Legs (Left) | 1 |
| D | Metal Frame Legs (Right) | 1 |
| E | Mesh Shelf | 1 |
| F | Bottom Shelf | 1 |
| G | Adjustable Leveling Feet | 4 |
| H | Assembly Hardware (Screws, Allen Wrench) | 1 Set |

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your HOMOOI L-Shaped Computer Desk. It is recommended to have two people for assembly.

1. **Step 1: Prepare the Workspace**

Clear a spacious area and lay down a blanket or cardboard to protect your floor and desk components from scratches during assembly.

2. **Step 2: Attach Leveling Feet to Metal Frames**

Screw the adjustable leveling feet (Part G) into the pre-drilled holes at the bottom of both metal frame legs (Parts C and D). Do not overtighten. These feet help stabilize the desk on uneven surfaces.



Image: Detailed view of the desk's features, including the adjustable leveling feet at the base of the metal frame, the waterproof desktop surface, and the sturdy mesh shelf.

3. **Step 3: Assemble the Side Shelf Unit**

Attach the mesh shelf (Part E) and the bottom shelf (Part F) to the side metal frame (Part D) using the provided screws from the hardware kit (Part H). Ensure the shelves are oriented correctly as per the diagram in your physical instruction manual. The side shelf unit can be assembled on either the left or right side of the main desk, depending on your preference.




Image: A visual representation demonstrating the reversible design of the L-shaped desk, allowing the shelving unit to be positioned on either the left or right side to suit different room layouts.

4. **Step 4: Attach Desktop Panels to Frames**

Carefully align the main desktop panel (Part A) with the metal frame legs (Part C) and secure with screws. Then, align the side desktop panel (Part B) with the assembled side shelf unit (Part D, E, F) and secure with screws. Ensure all connections are firm.

5. **Step 5: Connect the Two Desk Sections**

Join the main desktop section and the side shelf section together. There are pre-drilled holes and connecting plates/screws to secure the L-shape. Ensure the desk is stable and all screws are tightened.

6. **Step 6: Final Check**

Once assembled, gently shake the desk to ensure it is stable. Adjust the leveling feet (Part G) if necessary to eliminate any wobbling.

OPERATING AND USAGE

The HOMOOI L-Shaped Computer Desk is designed for versatility and efficiency in various settings.

- **Spacious Workstation:** The L-shaped design provides ample surface area for multiple monitors, laptops, keyboards, and other office essentials, making it ideal for studying, working, or gaming.
- **Integrated Storage:** Utilize the two-tier open shelves for organizing books, files, office supplies, or decorative items. The mesh shelf offers a unique aesthetic and practical storage.
- **Reversible Design:** As mentioned in assembly, the shelving unit can be installed on either the left or right side to best fit your room layout and personal preference.
- **Ergonomic Use:** Position your monitor and keyboard at comfortable heights to maintain good posture. The desk's dimensions are designed to support a comfortable sitting position.



Image: The HOMOOO L-Shaped Computer Desk integrated into a modern office environment, demonstrating its functional design and aesthetic appeal with a computer setup and plant.

MAINTENANCE

Proper care will extend the life and appearance of your desk.

- **Cleaning:** Wipe the desktop and metal frame with a soft, damp cloth. For stubborn marks, use a mild soap solution and dry

immediately. Avoid harsh chemicals or abrasive cleaners.

- **Spills:** The desktop is waterproof. In case of spills, wipe them immediately to prevent water damage, especially around edges and seams.
- **Protection:** Use coasters for drinks and mouse pads to protect the surface from scratches and heat.
- **Tightening:** Periodically check all screws and connections and re-tighten them as needed to maintain stability.
- **Placement:** Avoid placing the desk in direct sunlight or near heat sources, as this can cause material degradation over time.

TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

Problem: The desk is wobbly or unstable.

Solution:

- Ensure all screws are fully tightened.
- Adjust the leveling feet at the bottom of the desk legs to compensate for uneven flooring. Turn them clockwise or counter-clockwise until the desk is stable.
- Verify that the desk is assembled correctly according to the instructions.

Problem: Parts are missing or damaged upon arrival.

Solution:

- Do not proceed with assembly.
- Contact HOMOOI customer support immediately with your purchase details and a description of the missing/damaged parts.

Problem: Difficulty aligning screw holes during assembly.

Solution:

- Ensure you are using the correct screws for each part as indicated in the assembly diagram.
- Loosen other screws slightly to allow for more flexibility in alignment, then tighten them all once the problematic screw is in place.
- Verify that components are not installed backward or upside down.

SPECIFICATIONS

Key specifications for the HOMOOI L-Shaped Computer Desk:

| Feature | Detail |
|---------------------------------|---|
| Model Number | LCD112001WA |
| Overall Dimensions (L x W x H) | 1250 x 800 x 750 mm (approx. 49.2 x 31.5 x 29.5 inches) |
| Product Dimensions (from specs) | 120 x 80 x 75 cm; 16.8 kg |
| Color | Oak & Black |
| Material | Wood (E2 particle board), Metal |
| Item Weight | 16.8 kg (approx. 37 lbs) |
| Max Capacity | 50 kg (approx. 110 lbs) |

| Feature | Detail |
|------------------|--|
| Special Features | Ergonomic, Waterproof & Scratch Resistant Desktop, Adjustable Leveling Feet, Reversible Shelving |



PERFECT SIZE FOR SMALL SPACES

Image: An overhead view of the HOMOOI L-Shaped Computer Desk with precise measurements in millimeters, highlighting its compact yet functional design suitable for small spaces.

WARRANTY AND SUPPORT

HOMOOI is committed to providing high-quality products. For any questions, concerns, or warranty claims, please contact our customer support team.

- **Warranty Information:** Please refer to your purchase documentation or the HOMOOI official website for specific warranty terms and conditions. Typically, products are covered against manufacturing defects for a limited period from the date of purchase.
- **Customer Support:** If you require assistance with assembly, have missing parts, or experience any issues with your desk, please reach out to the seller or HOMOOI customer service through the platform where you made your purchase. Provide

your order number and a clear description of the issue for prompt assistance.

- **Online Resources:** Visit the HOMOOI brand page or product listing for additional information, FAQs, or updated assembly guides.