

[Manuals.plus](#) /

> [let'me](#) /

> let'me Cordless Ceramic Hair Straightener Brush Instruction Manual

let'me Cordless Ceramic Hair Straightener Brush

let'me Cordless Ceramic Hair Straightener Brush Instruction Manual

Model: Cordless Ceramic Hair Straightener Brush (ASIN: B08DXJCMJ8)

1. INTRODUCTION

Thank you for choosing the let'me Cordless Ceramic Hair Straightener Brush. This manual provides essential information for the safe and effective use of your new hair styling tool. Please read these instructions carefully before first use and retain for future reference.

This cordless hair straightener brush features ceramic heating technology, anti-scald design, and multiple temperature settings for versatile styling. Its portable design makes it ideal for travel and daily use.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using this appliance.
- Keep away from water. Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If appliance falls into water, unplug it immediately. Do not reach into the water.
- Always unplug this appliance immediately after using.
- Unplug this appliance before cleaning.
- Do not use with a voltage converter.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

- Do not use an extension cord with this appliance.
- This appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.
- Do not place the heated appliance directly on any surface while it is hot or plugged in.
- The anti-scald brush teeth are designed to minimize direct contact with the heating plate, but caution should always be exercised.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your let'me Cordless Ceramic Hair Straightener Brush.



Figure 3.1: let'me Cordless Ceramic Hair Straightener Brush. This image displays the overall design of the white cordless hair straightener brush with its black ceramic bristles and a power button with indicator lights.

Ceramic Heating Plate Uniform Heating

Provide quick heat and even heat distribution that easily turns curly hair into straight hair in minutes!



Figure 3.2: Close-up of the Ceramic Heating Plate and Anti-scald Comb Teeth. This image highlights the ceramic heating plate and the surrounding anti-scald comb teeth, designed for uniform heating and user safety.



Adopted MCH Heating Tech

designed with anti-scald brush teeth to hair root






Figure 3.3: Diagram illustrating MCH Heating Technology. This graphic shows the rapid heating capability of the MCH technology and the design of the anti-scald brush teeth.

Key Components:

- **Ceramic Heating Plate:** Provides quick and even heat distribution.
- **Anti-scald Comb Teeth:** Designed to protect the scalp and skin from direct contact with the heating elements.
- **Power Button/Temperature Control:** Used to power on/off and select temperature settings.
- **Indicator Lights:** Display charging status and selected temperature.
- **USB Charging Port:** For recharging the internal battery.

4. CHARGING AND INITIAL SETUP

Before first use, ensure the device is fully charged.

1. Connect the provided USB cable to the charging port on the straightener brush and to a suitable USB power adapter (not included).
2. During charging, the red light around the power button will be illuminated.

3. A full charge typically takes approximately 1.5 to 3 hours. Once fully charged, the red charging light will change to green.
4. Disconnect the USB cable once charging is complete.




Figure 4.1: Cordless Design with Rechargeable Battery and USB Port. This image illustrates the cordless design, the 3000mAh rechargeable battery, and the USB charging port with its cable length.

5. OPERATING INSTRUCTIONS

Follow these steps to use your hair straightener brush:

1. **Power On:** Press and hold the power button for approximately 3 seconds to turn on the device. The green light around the button will illuminate, and the comb will begin to heat up. The initial heating temperature is 150°C (300°F). Allow 1-2 minutes for the device to reach the desired temperature.
2. **Select Temperature:**

- For **175°C (350°F)**: Gently tap the power button once. Both the blue and green lights will be illuminated.
 - For **200°C (400°F)**: Tap the power button again. The red, blue, and green lights will all be illuminated.
3. **Styling**: Once the desired temperature is reached, slowly brush through sections of dry, detangled hair from root to tip. For best results, work in small sections.
 4. **Power Off**: Press and hold the power button for approximately 3 seconds to turn off the device. All indicator lights will extinguish, and the comb will stop heating.
 5. **Low Battery Indicator**: If the red light around the power button flashes for 5 seconds, it indicates insufficient battery. The straightener will automatically shut down. Recharge the device as described in Section 4.

ONE BUTTON OPERATION

60s Fast Heating;
3 Temp Level Settings;
Fit For Any Hair Types;



Figure 5.1: One Button Operation and Temperature Settings. This graphic illustrates the single power button for controlling the device and the three available temperature settings: 150°C (300°F), 175°C (350°F), and 200°C (400°F).

With Safety Certification Approved to Ensure Your Safety



Figure 5.2: Before and After Hair Straightening Results. This image demonstrates the effectiveness of the straightener brush on various hair types, showing before and after results.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your device.

- Always ensure the device is turned off and completely cool before cleaning.
- Use a dry brush or cloth to gently clean any hair or debris from the comb teeth and heating plate.
- Do not use harsh chemicals, abrasive cleaners, or immerse the device in water.
- Store the straightener brush in a cool, dry place, away from direct sunlight and moisture.
- Recharge the battery periodically if the device is not used for extended periods to maintain battery health.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the USB cable.
Device not heating up.	Device not powered on correctly or low battery.	Ensure the power button is pressed and held for 3 seconds. Check battery level and recharge if necessary.
Red light flashes and device shuts off.	Low battery warning.	Recharge the device immediately.
Hair not straightening effectively.	Incorrect temperature setting or large hair sections.	Increase temperature setting if suitable for your hair type. Work with smaller, dry, and detangled hair sections.

8. SPECIFICATIONS

- **Model:** Cordless Ceramic Hair Straightener Brush
- **Brand:** let'me
- **ASIN:** B08DXJCMJ8
- **Material:** Ceramic
- **Color:** White
- **Shape:** Comb
- **Battery:** 1 Lithium Polymer battery (included), 3000mAh
- **Charging:** USB (cable included)
- **Temperature Settings:** 150°C (300°F), 175°C (350°F), 200°C (400°F)
- **Manufacturer:** Suplyss
- **Package Dimensions:** 10.7 x 3.4 x 2.3 inches
- **Weight:** 8 ounces

9. WARRANTY AND SUPPORT

This product comes with a **1-year warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, technical support, or any questions regarding your let'me Cordless Ceramic Hair Straightener Brush, please contact our customer service team. Please refer to your purchase documentation for specific contact details or visit the official let'me store on Amazon.

Online Support: [Visit the let'me Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08DXJCMJ8>

More documents and user manuals: **<https://manuals.plus/>**