

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [MAIDeSITE](#) /
- › [MAIDeSITE T1 Pro Electric Height-Adjustable Desk User Manual](#)


## MAIDeSITE T1 Pro

# MAIDeSITE T1 Pro Electric Height-Adjustable Desk User Manual

## INTRODUCTION

---

Thank you for choosing the MAIDeSITE T1 Pro Electric Height-Adjustable Desk. This desk is designed to provide a stable, quiet, and ergonomic workspace, allowing you to effortlessly switch between sitting and standing positions. This manual contains important information regarding the assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and keep it for future reference.



An overview of the MAIDeSITE T1 Pro electric height-adjustable desk.

## SAFETY WARNINGS

---

**WARNING:** The maximum load capacity for this desk is 80 kg (176 lbs). Do not exceed this weight limit. Ensure the desk is correctly assembled and all fasteners are tightened to guarantee stability and safe operation. Keep children and pets away from the desk during height adjustments. Avoid placing liquids directly on the control panel or motor components.



This image visually confirms the desk's robust construction and load capacity, capable of supporting up to 80 kg.

## PACKAGE CONTENTS

---

Before beginning assembly, please verify that all components are present and undamaged. The package typically includes:

- MAIDeSITE T1 Pro Desk Frame (legs and crossbar)
- Control Panel with Memory Functions
- Power Adapter and Cable
- Assembly Hardware (screws, bolts, tools)
- User Manual (this document)

*Note: The desktop surface is typically sold separately and is not included in the standard package.*

## SETUP AND ASSEMBLY

---


Assembly of the MAIDeSITE T1 Pro desk frame is designed to be straightforward. Follow the included graphical instructions carefully. It is recommended to have a second person assist with certain steps, especially when lifting and positioning the desktop.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Legs and Crossbar:** Attach the desk legs to the central crossbar using the provided screws and tools. Ensure all connections are secure.
3. **Install Control Box and Motor:** Mount the control box and motor according to the diagrams in the assembly guide. Connect all cables as indicated.
4. **Attach Desktop:** Carefully place your chosen desktop onto the assembled frame. Align it properly and secure it using the provided screws.
5. **Connect Power:** Plug the power adapter into the control box and then into a wall outlet.

Ensure all screws are tightened firmly but do not overtighten. A properly assembled desk will be stable and operate smoothly.



This image highlights the ease of assembly, indicating minimal tools required and an estimated assembly time of 30 minutes.



This diagram illustrates the adjustable frame width, ranging from 96 cm to 160 cm, accommodating desktop sizes from 100 cm to 180 cm in width and 50 cm to 80 cm in depth.


## OPERATING INSTRUCTIONS

The MAIDeSiTe T1 Pro desk features an intuitive control panel for easy height adjustment and memory functions.

### Height Adjustment

- **Raise Desk:** Press and hold the **UP** arrow button (▲) to raise the desk to your desired standing height.
- **Lower Desk:** Press and hold the **DOWN** arrow button (▼) to lower the desk to your desired sitting height.

The desk can be adjusted smoothly within a height range of 72 cm to 120 cm.



The image illustrates the desk's height adjustment range, showing it can be set from a minimum of 72 cm to a maximum of 120 cm, suitable for various user heights.

### Memory Presets

The control panel features 4 memory preset buttons (1, 2, 3, 4) to save and recall your preferred heights.

1. **Set a Memory Position:** Adjust the desk to your desired height using the UP/DOWN buttons. Press the **M** button, then immediately press one of the number buttons (1, 2, 3, or 4) until you hear a beep or see the display flash. The current height is now saved to that preset.
2. **Recall a Memory Position:** Simply press the corresponding number button (1, 2, 3, or 4). The desk will automatically move to the saved height.

### Child Safety Lock

To prevent accidental adjustments, the control panel includes a child safety lock function.

- **Activate Lock:** Press and hold the **'M'** button for 5 seconds until a lock icon appears on the display. All buttons will be disabled.
- **Deactivate Lock:** Press and hold the **'M'** button again for 5 seconds until the lock icon disappears. The

buttons will now be active.



This image displays the intuitive control panel, featuring an LCD screen for height display, buttons for memory presets, a child safety lock, and a convenient USB charging port.

## Motor Performance

The desk is equipped with a powerful and quiet motor, ensuring smooth and efficient height transitions.

- **Speed:** Approximately 30 mm/s.
- **Noise Level:** Less than 45 dB during operation.




A visual representation of the desk's motor, highlighting its fast adjustment speed of 30mm/s and quiet operation at less than 48dB.

## SPECIFICATIONS

Feature	Specification
Brand	MAIDeSITE
Model Number	T1 Pro
Color	Grey
Height Adjustment Range	72 cm - 120 cm
Frame Width Adjustment Range	96 cm - 160 cm
Recommended Desktop Width	100 cm - 180 cm
Recommended Desktop Depth	50 cm - 80 cm
Maximum Load Capacity	80 kg (176 lbs)
Motor Speed	30 mm/s
Noise Level	< 45 dB

Material	100% High-Quality Carbon Steel
Product Dimensions (L x W x H)	60 x 160 x 120 cm (max height)
Item Weight	19 kg



A detailed view of the desk's leg structure, emphasizing its robust construction with thicker pipe walls and features like anti-rust coating, silent operation, and overall durability.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your MAIDeSITE T1 Pro desk, follow these simple maintenance guidelines:

- **Regular Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Check Connections:** Periodically inspect all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Keep power and data cables organized to prevent snagging or damage during height adjustments.
- **Avoid Overloading:** Do not exceed the maximum load capacity of 80 kg to prevent strain on the motor and frame.

## TROUBLESHOOTING

---

If you encounter any issues with your MAIDeSITE T1 Pro desk, refer to the following common troubleshooting steps:

- **Desk Not Moving:**
  - Check if the power cable is securely plugged into both the desk and the wall outlet.
  - Ensure the child safety lock is not activated (refer to Operating Instructions).
  - If the display shows an error code, consult the full troubleshooting guide available on the MAIDeSITE website or contact customer support.
- **Uneven Movement:**
  - Verify that the desk is placed on a level surface.
  - Check for any obstructions under or around the desk legs.
  - Ensure all assembly screws are properly tightened.
- **Noise During Operation:**

- A slight motor hum is normal. If the noise is excessive or unusual, check for loose components or obstructions.

For more complex issues or if the problem persists, please contact MAIDeSITE customer support.

## WARRANTY AND SUPPORT

---

MAIDeSITE offers a **5-year warranty** on the T1 Pro electric height-adjustable desk, ensuring reliability and durability. This warranty covers manufacturing defects and malfunctions under normal use.

For any questions, technical assistance, or warranty claims, please contact our customer service team. Our support is available 24/7 to provide you with the best possible service.

- **Customer Service:** Refer to the contact information provided with your purchase or visit the official MAIDeSITE website.
- **Online Resources:** Additional FAQs, video tutorials, and detailed troubleshooting guides may be available on the MAIDeSITE support page.