

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WE-VIBE](#) /

› [WE-VIBE Nova 2 Dual Rabbit Vibrator Instruction Manual](#)

## WE-VIBE Nova 2

# WE-VIBE Nova 2 Dual Rabbit Vibrator Instruction Manual

Model: Nova 2 | Brand: WE-VIBE

## INTRODUCTION

---

The WE-VIBE Nova 2 is a dual-stimulation vibrator designed for comprehensive pleasure. It features a flexible external arm for clitoral stimulation and an internal shaft for G-spot massage. With 10 customizable vibration modes and remote app control via the We-Connect app, it offers versatile experiences. The device is made from body-safe silicone and is fully waterproof (IPX7) for easy cleaning and use in various environments.

## PRODUCT OVERVIEW

---

The Nova 2 is crafted from smooth silicone, providing a comfortable and safe experience. Its unique design allows for simultaneous stimulation of both the clitoris and G-spot. The device is equipped with intuitive controls for adjusting vibration patterns and intensity, which can also be managed through the We-Connect app.



## Dual stimulation



Nova creates rumbly vibrations on your clitoris while also stimulating your G-spot.

Image: The WE-VIBE Nova 2 Dual Rabbit Vibrator, showcasing its ergonomic design and dual stimulation points.



## Constant clitoris contact



Nova's flexible external arm ensures constant contact with the clitoris.

Image: Close-up of the Nova 2 highlighting its flexible external arm, designed for constant clitoral contact during use.

Video: An official product overview of the We-Vibe Nova 2 in Fuchsia, demonstrating its features and design.

Video: An official product overview of the We-Vibe Nova 2 in Black, showcasing its design and functionality.

Video: An official product overview of the We-Vibe Nova 2 in Blue, highlighting its features and design.

## SETUP

### Unpacking the Device

Upon opening the package, you will find the Nova 2 vibrator, a USB charging cable, a storage pouch, and a sample of water-based lubricant. Please inspect all items for any damage before first use.



Image: The complete contents of the Nova 2 package, showing the vibrator, charging cable, storage pouch, and instruction materials.

## Charging the Nova 2

Before initial use, fully charge your Nova 2. Connect the magnetic USB charging cable to the charging points on the device. Plug the USB end into a compatible USB power source (e.g., computer, wall adapter). The indicator light will flash while charging and turn solid when fully charged. A full charge typically takes approximately 90 minutes and provides up to 90 minutes of playtime.




Image: The Nova 2 vibrator being connected to its magnetic USB charging cable, illustrating the charging process.

### **Connecting to the We-Connect App**

Download the We-Connect app from your device's app store. Ensure your Nova 2 is charged and turned on. Open the app and follow the on-screen instructions to pair your device via Bluetooth. The app allows for personalized control, custom vibration patterns, and remote play with a partner.



## App enabled



Play and share control from anywhere, create custom vibes and use with other We-Vibe products.

Image: A smartphone displaying the We-Connect app interface, positioned next to the Nova 2, demonstrating app connectivity.

### OPERATING INSTRUCTIONS

#### Basic Device Controls

The Nova 2 features intuitive buttons for direct control:

- **Power Button:** Press and hold to turn on/off.
- **Intensity Buttons (+/-):** Adjust the vibration intensity.
- **Mode Button:** Cycle through the 10 pre-set vibration patterns.



## Adjust vibration mode & intensity

Choose between whether the internal motor & external motor are running solo or simultaneously.

Image: A detailed view of the control buttons located on the Nova 2, indicating power, intensity, and mode functions.

### Using the We-Connect App

The We-Connect app provides enhanced control and customization options:

- **Custom Patterns:** Create and save your own unique vibration patterns.
- **Remote Control:** Allow a trusted partner to control your Nova 2 from anywhere in the world.
- **Touch Mode:** Control vibrations by touching your phone screen.
- **Music Sync:** Sync vibrations to your favorite music.

### Dual Stimulation Technique

Apply a generous amount of water-based lubricant to the Nova 2. Position the internal shaft for G-spot stimulation and adjust the flexible external arm to rest comfortably on the clitoris. Experiment with different angles and vibration settings to find your preferred sensations. The flexible design ensures continuous contact during movement.

## MAINTENANCE

### Cleaning Instructions

The Nova 2 is **100% waterproof (IPX7)**, making cleaning simple and hygienic. After each use, wash the device thoroughly with warm water and a mild soap or a specialized toy cleaner. Rinse well and pat dry with a lint-free cloth. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone material.



## Take a bath with your Nova



It is waterproof (IPX7) making it easy to enjoy anywhere and is super simple to clean.

Image: The Nova 2 vibrator partially submerged in water, illustrating its waterproof design for easy cleaning.

### Storage

Store your Nova 2 in the provided storage pouch in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid storing it with other toys made of different materials to prevent potential damage or reactions. The Nova 2 also features a travel lock function to prevent accidental activation during transport. Consult the app or device instructions for activating this feature.

### TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger and check if the indicator light appears. If not, try a different USB power source.
- **App connectivity issues:** Ensure Bluetooth is enabled on your smartphone and the Nova 2 is charged and powered on. Try restarting both the app and the device. If issues persist, ensure the app is updated to the latest version.
- **Weak vibrations:** The device may require charging. If fully charged and vibrations are still weak, contact

customer support.

- **Battery not holding charge:** Over time, battery performance can degrade. Ensure you are using the original charging cable. If the issue persists after a full charge cycle, contact customer support.

## SPECIFICATIONS

Feature	Detail
Model Name	Nova 2
Brand	WE-VIBE
Material	Body-safe Silicone
Waterproof Rating	IPX7 (fully submersible)
Battery	1 Lithium Ion battery (included)
Dimensions	11.1 x 5.2 x 2.95 inches
Weight	0.01 ounces
Vibration Modes	10
App Control	We-Connect App





Image: A visual representation of the Nova 2's dimensions, indicating its size and shape.

## **SAFETY INFORMATION**

---

Please read and understand all safety warnings before using your Nova 2. This device is intended for adult use only. Discontinue use immediately if you experience any discomfort or irritation. Do not use if the device appears damaged. Always use with water-based lubricant. Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

## **WARRANTY AND SUPPORT**

---

For warranty information, product support, or to contact customer service, please refer to the official WE-VIBE website or the contact details provided in your product packaging. Keep your proof of purchase for warranty claims.