

Manuals.plus /

› NUTRI FIT /

› NUTRI FIT Digital Kitchen Scale Instruction Manual - Model B08F28YZHB

## NUTRI FIT B08F28YZHB

# NUTRI FIT Digital Kitchen Scale Instruction Manual

Model: B08F28YZHB

## PRODUCT OVERVIEW

The NUTRI FIT Digital Kitchen Scale is designed for precise measurement of food ingredients, liquids, and other items up to 11 lbs (5 kg). Its ultra-slim design and stainless steel platform make it a practical and durable tool for any kitchen.



Image: NUTRI FIT Digital Food Scale, Slim & Compact design with a bowl of berries and tomatoes on the scale.

### Key Features:

- **High Accuracy:** Equipped with high-precision sensors for measurements from 0.1 oz / 1 g up to 11 lbs / 5 kg.

- **Multiple Units:** Easily switch between lb:oz, g, ml, and fl.oz.
- **Tare Function:** Zero out the weight of containers for accurate net weight measurements.
- **Ultra-Slim Design:** Compact dimensions (7 x 5.2 x 1.1 inches) for easy storage.
- **Durable Material:** Stainless steel platform for easy cleaning and longevity.
- **Energy Efficient:** Auto-off function after 2 minutes of inactivity to conserve battery life.
- **Clear Display:** Large backlit LCD screen for easy readability.

## SETUP

---

1. **Unpack the Scale:** Carefully remove the scale from its packaging.
2. **Install Batteries:**
  - Locate the battery compartment on the underside of the scale.
  - Open the compartment cover.
  - Insert two (2) AAA batteries, ensuring correct polarity (+/-).
  - Close the battery compartment cover securely.
3. **Placement:** Place the scale on a hard, flat, and stable surface to ensure accurate readings. Avoid soft or uneven surfaces.

## OPERATING INSTRUCTIONS

---

1. **Power On/Off:**
  - Press the **ON/OFF/ZERO** button to turn on the scale. The LCD will display "8888" and then "0".
  - To turn off the scale, press and hold the **ON/OFF/ZERO** button for a few seconds, or wait for the automatic 2-minute auto-off feature.
2. **Unit Conversion:**
  - Press the **UNIT/M** button to cycle through the available measurement units: grams (g), pounds and ounces (lb:oz), milliliters (ml), and fluid ounces (fl.oz).
  - The selected unit will be displayed on the LCD screen.



## Convertible Weight Units

Measure units between lb:oz/g for weight and fl'oz/ml for volume.



Weight mode

lb:oz ⇄ g



Water volume mode

fl'oz ⇄ ml



Milk volume mode

fl'oz ⇄ ml



Image: Digital scale displaying various measurement units like lb:oz, g, fl'oz, and ml.

### 3. Tare Function (Zeroing):

- Place an empty container on the scale platform. The display will show the weight of the container.
- Press the **ON/OFF/ZERO** button. The display will reset to "0", effectively subtracting the container's weight.
- You can now add ingredients to the container, and the scale will display only the net weight of the ingredients.

# EASY TARE

Easily reduce the weight of the bowl without affecting the actual weight of the food.



Image: A four-step visual guide demonstrating how to use the tare function to weigh food accurately by subtracting the bowl's weight.

## 4. Weighing Items:

- Turn on the scale and ensure it displays "0".
- Place the item(s) directly onto the scale platform or into a tared container.
- The weight will be displayed on the LCD screen.

Your browser does not support the video tag.

Video: Official NUTRI FIT demonstration of the digital ultra-slim food scale, showcasing its features and ease of use.

## MAINTENANCE

### • Cleaning:

- Wipe the scale with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water.
- The stainless steel platform is resistant to stains and easy to clean.



# EASY CLEAN UP

Made of waterproof stainless steel, wipe it with a cloth with any stain.

Image: A hand wiping the stainless steel platform of the scale with a cloth, demonstrating easy cleanup.

- **Storage:** Store the scale in a cool, dry place. Its ultra-slim design allows for easy storage in cabinets or drawers.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display. Use 2 AAA batteries.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
"Lo" or Low Battery Indicator	Batteries are low.	Replace with new AAA batteries.
"O-Ld" or Overload Indicator	Weight exceeds maximum capacity (11 lbs / 5 kg).	Remove items immediately to prevent damage.
Inaccurate Readings	Scale is on an uneven surface. Scale is dirty. Batteries are weak.	Place on a hard, flat surface. Clean the scale. Replace batteries.
Scale Does Not Turn On	Batteries are not installed correctly. Batteries are dead.	Check battery polarity. Replace batteries.

## SPECIFICATIONS

---

- **Model:** B08F28YZHB
- **Capacity:** 11 lbs / 5 kg
- **Accuracy:** 0.1 oz / 1 g
- **Units:** lb:oz, g, ml, fl.oz
- **Display:** Backlit LCD
- **Platform Material:** Stainless Steel
- **Dimensions:** 7 x 5.2 x 1.1 inches
- **Power:** 2 x AAA Batteries (included)
- **Auto-Off:** 2 minutes

## WARRANTY AND SUPPORT

---

For warranty information or product support, please refer to the contact details provided with your purchase or visit the official NUTRI FIT website.

**Manufacturer:** NUTRI FIT

**UPC:** 782938067590