



Manuals.plus /

› sparefixd /

› sparefixd Ice Box Freezer Compartment Door for Smeg Refrigerator & Freezer Instruction Manual

sparefixd 696135911

sparefixd Ice Box Freezer Compartment Door Instruction Manual

Model: 696135911

Brand: sparefixd

INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your sparefixd Ice Box Freezer Compartment Door. This replacement part is designed for specific Smeg refrigerator and freezer models. Please read this manual thoroughly before installation to ensure proper fit and function.

PRODUCT OVERVIEW

The sparefixd Ice Box Freezer Compartment Door is a direct replacement for the original freezer compartment door in compatible Smeg refrigerator and freezer units. It is designed to maintain the temperature within the ice box section, ensuring efficient freezing and storage.



Figure 1: Front view of the sparefixd Ice Box Freezer Compartment Door.



Figure 2: Angled view highlighting the handle area of the door.

MODEL COMPATIBILITY

This freezer compartment door (part number 696135911) is compatible with a wide range of Smeg refrigerator and freezer models. It is crucial to verify your appliance's model number before installation.

Locating Your Model Number:

The model number is typically located inside the refrigerator or freezer compartment. You may need to remove a salad drawer or freezer drawer to locate the model number plate. Alternatively, it might be on the side or back of the appliance. The model number is usually printed or stamped on a sticker or plate and consists of numbers and letters.

Compatible Smeg Models:

FAB28LAZ, FAB28LB, FAB28LBL, FAB28LBV, FAB28LCS, FAB28LDE, FAB28LG, FAB28LIT, FAB28LNE, FAB28LO, FAB28LP, FAB28LR, FAB28LRO, FAB28LUJ, FAB28LV, FAB28LVE, FAB28LX, FAB28QAZ, FAB28QB, FAB28QBL, FAB28QBV, FAB28QCS, FAB28QG, FAB28QIT, FAB28QNE, FAB28QO, FAB28QP, FAB28QR, FAB28QRO, FAB28QUJ, FAB28QV, FAB28QVE, FAB28QX, FAB28RAZ, FAB28RB, FAB28RBL, FAB28RBV, FAB28RCS, FAB28RDE, FAB28RG, FAB28RIT, FAB28RNE, FAB28RO, FAB28RP, FAB28RR, FAB28RRO, FAB28RUJ, FAB28RV, FAB28RVE, FAB28RX, FAB28YAZ, FAB28YB, FAB28YBL, FAB28YBV, FAB28YCS, FAB28YG, FAB28YIT, FAB28YNE, FAB28YO, FAB28YP, FAB28YR, S29STRP, S29STRP1, S29STRP2, S29STRP3, S29STRPU, S29STRPU2, S29STRPU3.

INSTALLATION INSTRUCTIONS

1. **Preparation:** Ensure your refrigerator/freezer is unplugged from the power supply before beginning installation.
2. **Remove Old Door (if applicable):** Carefully open the freezer compartment and identify how the existing door is attached. Most doors slide into place or are hinged. Gently remove the old door.
3. **Inspect New Door:** Examine the new sparefixd freezer compartment door for any damage or defects before installation.
4. **Install New Door:** Align the new door with the designated slots or hinges in your freezer compartment. Gently slide or snap it into place until it is securely fitted. Ensure it opens and closes smoothly.
5. **Test:** Once installed, plug in your appliance and allow it to reach operating temperature. Check that the door seals properly and maintains the freezer compartment's temperature.



Figure 3: Back view of the door, illustrating the sealing edge and attachment mechanism.

OPERATION

The sparefixd Ice Box Freezer Compartment Door operates like your original door. Simply open it to access the freezer compartment and close it firmly to maintain the internal temperature. Ensure the door is fully closed after each use to prevent frost buildup and energy loss.

MAINTENANCE

To ensure the longevity and proper function of your freezer compartment door:

- **Cleaning:** Regularly clean the door and its seals with a soft cloth and mild, non-abrasive detergent. Avoid harsh chemicals that could damage the plastic.
- **Seal Inspection:** Periodically check the door seal for any cracks, tears, or signs of wear. A damaged seal can lead to inefficient cooling and increased energy consumption.
- **Hinge/Slide Check:** Ensure the door's hinges or sliding mechanisms are free from debris and operate smoothly.

TROUBLESHOOTING

Door Does Not Fit:

Issue: The new door does not fit into the freezer compartment.

Solution: Double-check your appliance's model number against the compatible models listed in this manual. Ensure you have the correct replacement part. If the model number matches and the door still does not fit, contact customer support.

Door Does Not Close Properly:

Issue: The door does not seal tightly or springs open.

Solution: Inspect the installation. Ensure the door is correctly seated in its slots or hinges. Check for any obstructions preventing it from closing fully. Examine the door seal for damage or misalignment.

SPECIFICATIONS

| Feature | Detail |
|---------------------------|-----------------------------|
| Part Number | 696135911 |
| Brand | sparefixd |
| Compatible Appliance Type | Smeg Refrigerator & Freezer |
| Date First Available | July 31, 2020 |
| ASIN | B08F2M38M2 |

WARRANTY AND SUPPORT

For warranty information or technical support, please contact your retailer or the manufacturer, sparefixd. Refer to your purchase documentation for specific warranty terms and contact details.