

## STAR WARS F1304

# STAR WARS The Black Series Moff Gideon Action Figure Instruction Manual

Model: F1304

### INTRODUCTION

This manual provides instructions for the STAR WARS The Black Series Moff Gideon 6-inch collectible action figure. This figure is designed for display and imaginative play, featuring premium detail and multiple points of articulation.

#### **Safety Information:**

- **WARNING: CHOKING HAZARD** – Small parts may be generated. Not for children under 3 years.



Image 1: Front view of the Moff Gideon action figure, showcasing its detailed design and cape.

## SETUP AND ASSEMBLY

1. **Unboxing:** Carefully remove the figure and its accessories from the packaging. Retain packaging for future reference or storage.



Image 2: The Moff Gideon action figure displayed within its retail packaging.

2. **Accessory Attachment:** The figure comes with two character-inspired accessories: a Darksaber and a blaster



pistol.

- To attach the Darksaber, gently insert the hilt into the figure's right hand.
- To attach the blaster pistol, gently insert it into the figure's left hand or the holster on the figure's right hip.



## OPERATING THE FIGURE (ARTICULATION)

The Moff Gideon action figure features multiple points of articulation, allowing for various poses and dynamic displays.

- **Head:** The head can rotate and tilt for expressive poses.
- **Shoulders:** Shoulders are articulated to allow for arm movement up, down, and rotation.
- **Elbows and Wrists:** Bendable elbows and rotating wrists enable precise positioning of weapons and hands.
- **Torso:** The torso may have limited articulation for slight bending or twisting.
- **Hips and Knees:** Articulated hips and knees allow for leg movement and standing poses.
- **Ankles:** Ankle articulation assists in balancing the figure in various stances.

When posing, apply gentle pressure to avoid stressing the joints. Do not force movements beyond their natural range of motion.





Image 4: Two different poses of the Moff Gideon figure, demonstrating articulation. One shows a neutral stance, the other shows him aiming a blaster.



## CARE AND MAINTENANCE

- **Cleaning:** To clean the figure, gently wipe with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the paint or plastic.
- **Storage:** Store the figure away from direct sunlight and extreme temperatures to prevent discoloration or warping. Keep accessories in a safe place to avoid loss.
- **Joint Care:** If joints become stiff, gently warm the area with a hairdryer on a low setting for a few seconds to loosen the plastic before attempting to move.

## TROUBLESHOOTING

Issue	Possible Cause	Solution
Stiff joints	Plastic is cold or new.	Gently warm the joint area with a hairdryer on a low setting for a few seconds to soften the plastic before moving.
Accessories do not fit	Incorrect orientation or slight manufacturing variance.	Ensure accessories are oriented correctly. Apply gentle, even pressure. Do not force.
Figure does not stand upright	Improper leg/foot positioning.	Adjust leg and ankle articulation to find a stable center of gravity. Consider using a display stand (not included) for more complex poses.

## SPECIFICATIONS

- **Product Dimensions:** 9.06 x 1.97 x 5.12 inches
- **Item Weight:** 6.3 ounces
- **Model Number:** F1304
- **Manufacturer Recommended Age:** 4 years and up
- **Brand:** STAR WARS The Black Series
- **Manufacturer:** Hasbro
- **Release Date:** May 8, 2021

## WARRANTY AND SUPPORT

For information regarding product warranty or support, please contact Hasbro customer service directly or visit their official website. Specific warranty details may vary by region and retailer.

Manufacturer: Hasbro

For further assistance, please refer to the official STAR WARS or Hasbro websites.