

DASH DCSM350GBBU02

DASH Delish Compact Stand Mixer User Manual

Model: DCSM350GBBU02 | Brand: DASH

INTRODUCTION

The DASH Delish Compact Stand Mixer is a versatile and essential kitchen appliance designed to simplify your baking and cooking tasks. With its compact size and powerful motor, it's perfect for a wide range of recipes, from light batters to heavier doughs. This manual provides detailed instructions for safe operation, assembly, maintenance, and troubleshooting to ensure you get the most out of your new stand mixer.

Key Features

- **VERSATILE:** The Delish by Dash Stand Mixer is the perfect kitchen accessory for the budding baker or home cook looking to mix, beat, cream, or whip something up—sweet or savory.
- **COMPACT:** Weighing less than 5 lbs and standing only 10.5" tall, the Dash Stand Mixer fits underneath most kitchen cabinets. Perfect for that first apartment, smaller kitchen, or limited countertop space!
- **TILTING HEAD:** The tilting motor head makes it easy to remove the stainless steel mixing bowl and eject the beaters or dough hooks. No more mess! Plus, the retro design and variety of trendy colors options will accent any kitchen.
- **ADJUSTABLE SLIDE:** Move the bowl from side to side so you can add or reincorporate ingredients while mixing. With 5 speeds ranging from gentle mixing to high-speed whipping, it's never been easier to find the perfect setting!
- **INCLUDES:** Delish by Dash Stand Mixer is backed by a 1-year manufacturer warranty and includes a 3.5 qt stainless steel mixing bowl, 2 dough hooks & 2 mixer beaters. All non-electric parts are dishwasher safe.



Figure 1: The DASH Delish Compact Stand Mixer in its assembled state.

SETUP GUIDE

Unboxing and Components

Carefully remove all components from the packaging. Ensure all parts are present and undamaged before proceeding with assembly.

- Main Mixer Unit
- 3.5 Quart Stainless Steel Mixing Bowl
- 2 Mixer Beaters
- 2 Dough Hooks

FABULOUSLY FEATURED



3.5qt Stainless Steel
Bowl cleans up easily!



Whip, beat, and mash
with 5-speed power.



Beaters and Dough
Hooks included!



Amazing Delish
recipes inside!

Figure 2: Key components of the DASH Delish Compact Stand Mixer.

Assembly

1. **Attach the Mixing Bowl:** Place the 3.5-quart stainless steel mixing bowl onto the base of the mixer. Align the grooves on the bottom of the bowl with the corresponding slots on the mixer base. Twist the bowl clockwise until it locks securely into place. You should feel it latch in and it will not move freely.
2. **Install the Attachments:** Press the 'TILT' button located on the side of the mixer head to raise the motor head. Select either the mixer beaters or dough hooks based on your recipe. Insert the shafts of the attachments into the openings on the underside of the motor head. Push firmly until you hear a distinct clicking sound, indicating they are securely locked.
3. **Lower the Motor Head:** Gently push down the motor head until it clicks back into its locked position. Ensure it is fully lowered before operation.

OPERATING YOUR STAND MIXER

Controls

The mixer features a simple control layout for ease of use:

- **Tilt Button:** Located on the side of the mixer head, this button allows you to raise and lower the motor head for easy attachment and bowl removal.
- **Speed Knob:** Positioned on the front of the mixer, this knob controls the mixing speed from 0 (off) to 5 (highest speed).
- **Adjustable Slide:** A lever on the side of the base allows you to slide the mixing bowl from side to side. This feature helps ensure all ingredients are thoroughly incorporated and prevents sticking to the bowl's edges.

Speed Settings

The mixer offers 5 distinct speed settings for various mixing needs:



Figure 3: Visual guide to the 5-speed power settings.

- **Speed 1 (Mixing):** Ideal for combining dry ingredients or starting liquid mixtures.
- **Speed 2-3 (Beating/Folding):** Suitable for beating eggs, mixing cake batters, or gently folding ingredients.
- **Speed 3-4 (Creaming):** Use for creaming butter and sugar, or mixing heavier batters.
- **Speed 5 (Whipping):** Perfect for whipping cream, egg whites, or light meringues to stiff peaks.

Mixing Techniques

For optimal results, always start at a lower speed and gradually increase as needed. Utilize the adjustable slide to move the bowl and ensure all ingredients are thoroughly mixed, especially when dealing with thicker mixtures or ingredients that tend to stick to the sides of the bowl.

CARE AND MAINTENANCE

Cleaning the Bowl and Attachments

The 3.5-quart stainless steel mixing bowl, mixer beaters, and dough hooks are all dishwasher safe for convenient cleaning. For best results, rinse off any excess food residue before placing them in the dishwasher.

Cleaning the Main Unit

To clean the main mixer unit, unplug the appliance from the power outlet. Wipe the exterior with a damp cloth and mild detergent. Do not immerse the main unit in water or any other liquid. Ensure the unit is completely dry before storing or next use.

TROUBLESHOOTING COMMON ISSUES

Problem	Possible Cause	Solution
Mixer not thoroughly mixing ingredients, or ingredients stick to sides.	Bowl position not optimal; ingredients not reaching beaters.	Use the adjustable slide to move the bowl from side to side during mixing. Periodically stop the mixer and scrape down the sides of the bowl with a spatula.
Mixing bowl does not secure to the base.	Bowl not properly aligned or twisted.	Ensure the grooves on the bowl align with the slots on the base. Twist the bowl firmly clockwise until it latches into place.
Attachments (beaters/dough hooks) do not stay in place.	Attachments not fully inserted or clicked into place.	Raise the motor head using the 'TILT' button. Re-insert attachments firmly into the openings until you hear a distinct clicking sound.
Mixer struggles with very thick dough.	The compact mixer is designed for a range of tasks, but extremely dense doughs may exceed its capacity.	For very heavy or stiff doughs, consider mixing smaller batches or completing the kneading process by hand. Do not overload the mixer.

PRODUCT SPECIFICATIONS

Specification	Detail
Brand	DASH
Model Name	Delish by Dash Compact Stand Mixer, 3.5 Quart
Model Number	DCSM350GBBU02
Color	Blue
Capacity	3.5 Quarts
Product Dimensions	8"D x 11.5"W x 10.5"H
Item Weight	5 Pounds
Controls Type	Knob
Blade Material	Stainless Steel
Container Material	Stainless Steel
Is Dishwasher Safe	Yes (Non-electric parts)

Specification	Detail
UPC	850015418266









Figure 4: Dimensions of the Compact Stand Mixer.

WARRANTY AND CUSTOMER SUPPORT

The DASH Delish Compact Stand Mixer is backed by a **1-year manufacturer warranty**. This warranty covers defects in material and workmanship under normal household use.

For warranty claims, technical assistance, or any product-related inquiries, please refer to the contact information provided in your product packaging or visit the official DASH website for the most up-to-date support resources.

 <p>3.5QT TILT-HEAD STAND MIXER Instruction Manual Recipe Guide</p>	<p>Dash 3.5QT Tilt-Head Stand Mixer: Instruction Manual and Recipe Guide</p> <p>Comprehensive instruction manual and recipe guide for the Dash 3.5QT Tilt-Head Stand Mixer (Model DSTM370). Learn how to set up, use, clean, and troubleshoot your mixer, plus find delicious recipes for various dishes.</p>
 <p>COMPACT AIR FRYER AirCrisp™ Technology 2-Quart Capacity 1500 Watts</p>	<p>Dash Compact Air Fryer DCAF150: User Manual, Recipes & Support</p> <p>Comprehensive guide for the Dash Compact Air Fryer (DCAF150), including important safety instructions, parts identification, usage tips, troubleshooting, a detailed recipe book, and customer support information.</p>
 <p>DIGITAL COMPACT AIR FRYER AirCrisp™ Technology 2-Quart Capacity 1200 Watts</p>	<p>Dash Digital Compact Air Fryer DCAF155 User Manual and Recipe Book</p> <p>Comprehensive user manual for the Dash Digital Compact Air Fryer (DCAF155) featuring AirCrisp™ Technology. Includes detailed safety instructions, operating guide, parts identification, usage tips, cooking charts, cleaning and maintenance, troubleshooting, a collection of recipes, customer support information, and warranty details.</p>
 <p>DELUXE AIR FRYER AirCrisp™ Technology 6-Quart Capacity 1700 Watts</p>	<p>Dash Deluxe Air Fryer: User Manual, Features, and Recipes</p> <p>Comprehensive guide for the Dash Deluxe Air Fryer (DFAF455GB), including important safety instructions, parts and features, usage guide, cleaning tips, troubleshooting, and a collection of delicious recipes.</p>
 <p>DELUXE COMPACT COLD PRESS POWER JUICER Instruction Manual Recipe Guide</p>	<p>Dash Deluxe Compact Cold Press Power Juicer Instruction Manual and Recipe Guide</p> <p>Comprehensive instruction manual and recipe guide for the Dash Deluxe Compact Cold Press Power Juicer (Model #DCSJ255). Learn how to set up, use, clean, and maintain your juicer, plus discover delicious juice recipes.</p>
 <p>COMPACT AIR FRYER Instruction Manual Recipe Guide</p>	<p>Dash DCAF150 Compact Air Fryer: Instruction Manual & Recipe Guide</p> <p>Comprehensive guide for the Dash DCAF150 Compact Air Fryer, including safety instructions, parts overview, usage tips, troubleshooting, and a collection of delicious recipes.</p>