

[Manuals.plus](#) /

> [STYLUSHOME](#) /

> StylusHome 2-in-1 Fiber Tip Capacitive Stylus Pens Instruction Manual

STYLUSHOME B08F33JZ6F

StylusHome 2-in-1 Fiber Tip Capacitive Stylus Pens Instruction Manual

Model: B08F33JZ6F

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your StylusHome 2-in-1 Fiber Tip Capacitive Stylus Pens. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: Overview of the StylusHome 6-pack stylus pens, showing various colors and included replacement tips, with a tablet being used in the background.

2. PACKAGE CONTENTS

Upon opening your StylusHome stylus pen package, you should find the following items:

- 6 x Stylus Pens (various colors)
- 6 x 0.2 inch (5mm) Replacement Fiber Tips
- 6 x 0.24 inch (6mm) Replacement Fiber Tips



Image: Contents of the StylusHome package, displaying six stylus pens in different colors along with twelve extra fiber tips of two distinct sizes.

3. PRODUCT FEATURES

The StylusHome 2-in-1 Fiber Tip Capacitive Stylus Pens offer several key features designed for enhanced usability and durability:

- **2-in-1 Design:** Each stylus features two different sizes of fiber tips on opposing ends, providing versatility for various tasks and preferences.
- **Sensitive and Anti-scratch Tips:** The soft fiber tips ensure smooth interaction with touch screens, preventing scratches and minimizing fingerprints.
- **Replaceable Tips:** Both fiber tips on each stylus are replaceable, extending the product's lifespan. Twelve extra replacement tips are included.
- **Pen Clip Design:** A convenient clip allows for easy attachment to pockets, books, or device cases, enhancing portability.

Image: Illustration of the two distinct fiber tip sizes (5mm and 6mm) available on the stylus pens.

Image: A visual comparison demonstrating the higher precision and sensitivity of the StylusHome stylus compared to a generic alternative.

Product Overview Video

Your browser does not support the video tag.

Video: This video demonstrates the high precision fiber tip stylus for touchscreen devices, showcasing its features and smooth operation.

4. SETUP AND USAGE

General Use

The StylusHome stylus is ready for immediate use with any capacitive touch screen device. Simply touch the fiber tip to your device's screen to navigate, draw, write, or play games. No pairing or power is required.

Replacing Fiber Tips

To replace a worn or damaged fiber tip, follow these steps:

1. Gently screw off the silver metal part at the tip of the stylus.
2. Carefully pull off the old fiber tip from the stylus.
3. Insert a new fiber tip onto the stylus.
4. Screw the silver metal part back onto the stylus to secure the new tip.

Image: Step-by-step visual guide on how to easily replace the fiber tips of the stylus pen.

Usage Scenarios

Image: Using the stylus while wearing gloves for screen interaction.

Image: The stylus facilitates comfortable use for individuals with long nails.

Image: Precise typing on a smartphone using the stylus.

Image: Effortless web browsing and navigation on a tablet with the stylus.

Image: Demonstrates the stylus's utility in public interfaces like elevators, ATMs, and vehicle monitors.

5. MAINTENANCE

To ensure the longevity and optimal performance of your StylusHome stylus pens, please observe the following maintenance guidelines:

- **Keep Tips Clean:** Regularly inspect and clean the fiber tips. Dirt or debris on the tip can reduce responsiveness and potentially scratch your device's screen. Use a soft, dry cloth for cleaning.
- **Screen Protection:** While the fiber tips are designed to be anti-scratch, it is recommended to use a screen protector on your device to prevent any possible damage from accumulated dirt or accidental impact.
- **Tip Replacement:** Replace fiber tips when they show signs of wear or damage to maintain optimal performance. Refer to the "Replacing Fiber Tips" section for instructions.
- **Storage:** Store the stylus pens in a clean, dry place when not in use. The pen clip design allows for secure attachment to cases or notebooks.

6. COMPATIBILITY

The StylusHome 2-in-1 Fiber Tip Capacitive Stylus Pens are universally compatible with all capacitive touch screen devices. This includes, but is not limited to:

- Apple iPad (all generations, including iPad Pro, iPad Mini, iPad Air)
- Apple iPhone (all models)
- Android Tablets & Smartphones (e.g., Samsung Galaxy, Asus Transformer, Asus Nexus 7, Motorola Xoom)
- Other capacitive touch screen devices

Image: The StylusHome stylus is compatible with a wide range of capacitive touch screen devices, including popular tablets and smartphones.

7. SPECIFICATIONS

Attribute	Value
Brand	STYLUSHOME
Model Number	B08F33JZ6F
Material	Aluminum
Item Weight	0.6 ounces (17 Grams)
Item Diameter	0.4 Inches
Package Dimensions	8.19 x 3.7 x 0.59 inches
Batteries Required	No
UPC	190065915798



Image: Detailed dimensions of the StylusHome stylus pen, including length and tip sizes.

8. TROUBLESHOOTING

If you encounter any issues with your StylusHome stylus pens, consider the following common troubleshooting steps:

- **Lack of Responsiveness:**
 - Ensure the fiber tip is clean and free of dirt or debris.
 - Check if the fiber tip is securely attached and not worn out. Replace if necessary.
 - Verify that your device's screen is clean.
- **Inaccurate Input:**
 - Clean the stylus tip and device screen.
 - Ensure the tip is not damaged or excessively worn.
- **Scratches on Screen:**
 - Immediately check the stylus tip for any embedded debris or damage. Replace the tip if any issues are found.
 - Always ensure your device screen is clean before use.

If problems persist, please contact customer support.

9. WARRANTY AND SUPPORT

StylusHome provides a 12-month after-sales service for its products, including replacement and return services. For any inquiries, technical support, or warranty claims, please contact us directly.

Contact Information:

Email: sales@stylushomeusa.com