

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Trainers Warehouse](#) /

› [Trainers Warehouse Me First v.3 Wireless Game Buzzers 4-Player Instruction Manual](#)

Trainers Warehouse GAMFB4

Trainers Warehouse Me First v.3 Wireless Game Buzzers (4-Player)

Instruction Manual

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Trainers Warehouse Me First v.3 Wireless Game Buzzers (4-Player). Please read this manual thoroughly before using the product to ensure proper function and longevity.

PACKAGE CONTENTS

Your Me First v.3 Wireless Game Buzzer system includes the following components:

- 4 x Wireless Player P.A.D.s (Personal Answer Domes)
- 1 x Facilitator Control Unit
- Batteries for all units
- Instruction Booklet (this manual)
- USB Cable (for integration with select game show software)



INCLUDES...

- 4 player pads
- 1 facilitator remote
- Batteries
- Easy-play instructions



NO WIRES!
NO SOFTWARE !

Trainers
WAREHOUSE

Image: The complete 5-piece starter kit, including four player pads and one facilitator control unit.

SETUP

Follow these steps to set up your Me First v.3 Wireless Game Buzzers:

- Battery Installation:** The player P.A.D.s and facilitator control unit come with batteries pre-installed. If replacement is needed, open the snap-open battery pack on the underside of each unit and insert new batteries according to the polarity markings.
- Power On:** To turn on each player P.A.D. and the facilitator unit, press and hold the ON/OFF button for approximately 3 seconds until the red light appears.
- Initial Reset:** Once all units are powered on, press the 'RESET' button on the facilitator control unit. All player P.A.D.s will illuminate with a yellow light, indicating they are ready for play.



Image: The facilitator control unit, showing the ON/OFF, Reset, Sound, Right, Wrong, and Continue buttons, along with the snap-open battery pack.

Your browser does not support the video tag.

Video: This official Trainers Warehouse video demonstrates the unboxing, powering on, and basic operation of the Me First v.3 Wireless Game Buzzers, including how players buzz in and how the facilitator manages responses.

OPERATING INSTRUCTIONS

The Me First v.3 Wireless Game Buzzers are designed for interactive question-and-answer sessions. Here's how to operate them:

1. **Player Buzz-In:** When a question is posed, the first player to press their P.A.D. will have their P.A.D. light up green. All other P.A.D.s will turn red, indicating they are locked out. The facilitator control unit will also light up green.
2. **Facilitator Response:** The facilitator can then use their control unit to indicate if the player's answer is correct or incorrect:
 - Press the 'RIGHT' button for a correct answer.
 - Press the 'WRONG' button for an incorrect answer.
3. **Continuing Play:** After a player has answered, the facilitator has two options:

- **'CONTINUE' Button:** Pressing 'CONTINUE' will allow other players to buzz in, excluding the player who just answered. This is useful for multi-part questions or when multiple attempts are allowed.
 - **'RESET' Button:** Pressing 'RESET' will clear all current responses, turning all P.A.D.s back to yellow, and allow all players to buzz in again for the next question.
4. **Sound Settings:** The facilitator control unit includes a 'SOUND' button to toggle between multiple sound settings for buzz-in alerts.
 5. **Tracking Scores:** At the end of the game, the facilitator can press and hold the 'RIGHT' button on their control unit to display which players had the most correct answers.



TRAINERS' DREAM BUZZERS!

Pads are large enough for multiple teammates

1st place turns green, all others turn red

**Block previous responders
or let everyone play**

Right & Wrong Sounds

See who got the most right answers



Trainers
WAREHOUSE

Image: Player pads demonstrating the first-to-buzz feature, with one pad glowing green and others red.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your buzzers:

- **Cleaning:** Wipe the surface of the player P.A.D.s and facilitator unit with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the lights dim or the units become unresponsive. Use the recommended battery type (specified on the unit or in the packaging).

- **Storage:** Store the buzzers in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Remove batteries if storing for extended periods to prevent leakage.

TROUBLESHOOTING

If you encounter issues with your Me First v.3 Wireless Game Buzzers, refer to the following common solutions:

- **Units Not Turning On:**
 - Ensure batteries are correctly installed and not depleted. Replace if necessary.
 - Confirm the ON/OFF button is held for at least 3 seconds until the red light appears.
- **Player P.A.D.s Not Responding:**
 - Ensure the facilitator control unit has been reset (all P.A.D.s should be yellow).
 - Check that the P.A.D.s are within the 80-foot RF range of the facilitator unit.
 - Verify that the P.A.D.s are powered on.
- **Interference:**
 - Minimize obstructions between the facilitator unit and player P.A.D.s.
 - Avoid using the system near other strong radio frequency sources.

SPECIFICATIONS

Item Package Dimensions (L x W x H)	9.69 x 7.09 x 2.92 inches
Package Weight	0.67 Kilograms
Item Dimensions (L x W x H)	3 x 3 x 1.5 inches (per P.A.D.)
Brand Name	Trainers Warehouse
Manufacturer	Trainers Warehouse
Part Number	GAMFB4
Size	3 inches (diameter of player P.A.D.s)
ASIN	B08F5K7Y96
Date First Available	August 3, 2020

WARRANTY INFORMATION

Specific warranty details are not provided within this instruction manual. Please refer to the product packaging, any included warranty cards, or contact Trainers Warehouse directly for comprehensive warranty information.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Trainers Warehouse Me First v.3

Wireless Game Buzzers, please contact the manufacturer directly. Contact information can typically be found on the product packaging or on the official Trainers Warehouse website.