

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [tectake](#) /
- › [TecTake Garden Bench Model 800796 User Manual](#)

tectake 800796

TecTake Garden Bench Model 800796 User Manual

Aluminium Frame 2-Seater Outdoor Bench

INTRODUCTION

This manual provides essential information for the safe and proper assembly, operation, and maintenance of your TecTake Garden Bench, Model 800796. Please read these instructions carefully before use and retain them for future reference.



Image: Front view of the TecTake Garden Bench, showcasing its dark grey finish and two-seater design.

SAFETY INSTRUCTIONS

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the bench on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely. Periodically check and re-tighten fasteners to maintain stability.
- Do not exceed the maximum load capacity of 250 kg (551 lbs).
- Place the bench on a level, stable surface to prevent tipping.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- This bench is designed for outdoor seating. Do not use it for purposes other than its intended use.

BOX CONTENTS

Before beginning assembly, verify that all parts listed below are included in your package:

- Garden Bench Components (Frame, Seat Slats, Backrest Slats, Armrests)
- Mounting Material (Screws, Bolts, Washers, Allen Key)
- Assembly Instructions

SETUP AND ASSEMBLY

Assembly is quick and straightforward. It is recommended to have two people for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Attach Armrests to Frame:** Secure the armrests to the main frame components using the provided screws and bolts. Do not fully tighten yet.
3. **Install Seat Slats:** Attach the polystyrene seat slats to the frame. Ensure they are correctly oriented.
4. **Install Backrest Slats:** Attach the polystyrene backrest slats to the frame.
5. **Final Tightening:** Once all components are in place, gradually tighten all screws and bolts evenly until secure. Avoid over-tightening.
6. **Stability Check:** Gently rock the bench to ensure it is stable and all connections are firm.




Image: Technical diagram illustrating the dimensions of the garden bench, including length, depth, height, seat height, and armrest height.

OPERATING INSTRUCTIONS

The TecTake Garden Bench is designed for comfortable outdoor seating for up to two people. Ensure the bench is placed on a flat, stable surface before use. Avoid standing on the bench or using it as a step stool. Distribute weight evenly when sitting.



Image: A person enjoying the TecTake Garden Bench in a landscaped garden, demonstrating its intended use for relaxation.

MAINTENANCE AND CARE

This garden bench is designed for low maintenance. Regular care will help preserve its appearance and extend its lifespan.

- **Cleaning:** Wipe the bench with a damp cloth and mild soap solution. Rinse with clean water and dry thoroughly. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Inspection:** Periodically inspect all fasteners (screws, bolts) and re-tighten if necessary to ensure structural integrity.
- **Weather Protection:** While weather-resistant, storing the bench indoors or covering it during extreme weather conditions (heavy rain, snow, prolonged direct sunlight) can further prolong its life and maintain its appearance.
- **Storage:** If storing for extended periods, clean the bench thoroughly and store it in a dry, protected area.



Image: Detailed view of the polystyrene backrest slats, highlighting the wood-like texture and dark grey finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bench feels wobbly or unstable.	Loose fasteners; uneven ground.	Check and tighten all screws and bolts. Move the bench to a level surface.
Scratches or minor surface damage.	Impact during assembly or use.	Minor scratches on the frame can be touched up with appropriate outdoor paint. Polystyrene slats are durable but can be scratched.
Difficulty during assembly.	Incorrect part orientation; fasteners not aligned.	Refer to the assembly instructions carefully. Ensure parts are oriented correctly before tightening. Do not force components.

SPECIFICATIONS

Model:	800796
Brand:	TecTake
Total Dimensions (L x D x H):	Approx. 128 x 59 x 88 cm
Seat Area (L x D):	Approx. 113 x 41 cm
Seat Height:	Approx. 44 cm
Backrest Height:	Approx. 47 cm
Armrest Height from Ground:	Approx. 64.5 cm
Maximum Load Capacity:	250 kg (551 lbs)
Weight:	Approx. 12.5 kg
Materials:	Powder-coated Aluminium Frame, Polystyrene (Polywood) Slats
Color:	Dark Grey

WARRANTY INFORMATION

Specific warranty details for your TecTake Garden Bench are typically provided with the product packaging or can be obtained by contacting TecTake customer support. Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, missing parts, or questions regarding your TecTake Garden Bench, please contact TecTake customer service. Refer to the contact information provided in your product packaging or visit the official TecTake website.



