

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BISSELL](#) /

› [BISSELL Spinwave Cordless Hard Floor Expert Spin Mop Cleaner 18V User Manual](#)

BISSELL 23159

BISSELL Spinwave Cordless Hard Floor Expert Spin Mop Cleaner 18V User Manual

Model: 23159

INTRODUCTION

The BISSELL Spinwave Cordless Hard Floor Expert Spin Mop Cleaner 18V is designed to simplify hard floor cleaning. This cordless device effectively cleans sealed hard floors such as wood, tile, linoleum, and vinyl, removing tough messes with ease. Its lightweight design and swivel steering enhance maneuverability, making it suitable for various areas in your home.

SAFETY INFORMATION

Please read all instructions before using your BISSELL Spinwave Cordless Hard Floor Expert Spin Mop. Failure to follow the warnings and instructions may result in electric shock, fire, or serious injury.

- Always disconnect the charger from the electrical outlet before cleaning or performing maintenance.
- Do not immerse the appliance in water or other liquids.
- Use only BISSELL cleaning formulas intended for this appliance to prevent internal component damage.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not use on wet surfaces or where liquids are present.
- Store the appliance indoors in a dry place.

PACKAGE CONTENTS

Your BISSELL Spinwave Cordless Hard Floor Expert Spin Mop package includes the following items:

- BISSELL Spinwave Cordless Hard Floor Expert Spin Mop (main unit)
- 18V Lithium-Ion Battery (pre-installed)
- Charging Adapter
- 4 Reusable Mop Pads (2 soft pads, 2 scrubby pads)
- 2 Trial-Size Cleaning Solutions

- Storage Tray



Image: The BISSELL Spinwave Cordless Hard Floor Expert Spin Mop, along with its charging adapter, four mop pads, and two trial-size cleaning solutions.

SETUP

1. Assembly

The BISSELL Spinwave Cordless Mop typically requires minimal assembly. Ensure the handle is securely attached to the main body of the mop. Refer to the quick start guide included in your packaging for specific handle attachment instructions if needed.

2. Charging the Battery

Before first use, fully charge the 18V Lithium-Ion battery. The battery is pre-installed. Connect the charging adapter to the mop and plug it into a wall outlet. A full charge takes approximately four hours. The battery indicator lights on the mop will show charging status.

3. Attaching Mop Pads

Select the appropriate mop pads for your cleaning task. The package includes two soft pads for gentle cleaning and two scrubby pads for tougher messes. Align the mop pads with the hook and loop fasteners on the bottom of the mop head and press firmly to secure them.




Image: Close-up view of the mop pads, showing their attachment mechanism to the Spinwave cleaner head.

OPERATING INSTRUCTIONS

1. Filling the Solution Tank

Remove the clean water tank from the mop. Unscrew the cap and fill the tank with warm water up to the indicated 'WATER' line. Add your preferred BISSELL cleaning formula up to the 'FORMULA' line. Replace the cap and reinsert the tank into the mop until it clicks into place.



Personalize Your Clean

Mix water with the solution you love.

Image: A hand pouring cleaning solution into the removable water tank of the BISSELL Spinwave mop, demonstrating the filling process.

2. Powering On/Off

To turn the mop on, press the power button located on the handle. The mop pads will begin to spin. To turn it off, press the power button again.

3. Using the Spray Function

Press the spray trigger on the handle to dispense cleaning solution onto the floor. Control the amount of solution by pressing the trigger as needed. This allows for targeted cleaning of specific areas or stains.




Image: The BISSELL Spinwave mop actively spraying cleaning solution onto a hard floor, highlighting the on-demand spray feature.

4. Maneuvering the Mop

The Spinwave mop features a lightweight design and swivel steering, making it easy to maneuver around furniture and into tight spaces. The spinning pads help propel the mop forward, requiring minimal effort from the user.



Image: The BISSELL Spinwave mop demonstrating its swivel steering capability by cleaning around the legs of a chair.

5. Recommended Floor Types

This appliance is safe for use on all sealed hard floors, including wood, tile, linoleum, and vinyl. It is designed to clean effectively without causing damage or scratches.



Safely Clean

Sealed Hard Floors

Image: The BISSELL Spinwave mop cleaning a sealed hard floor, with an inset graphic illustrating various compatible floor types like wood, tile, and linoleum.

MAINTENANCE

1. Cleaning Mop Pads

After each use, remove the mop pads from the mop head. The pads are machine washable. Wash them with similar items in warm water. Do not use bleach or fabric softener. Tumble dry low.

2. Emptying and Cleaning the Solution Tank

Empty any remaining solution from the tank after each use. Rinse the tank thoroughly with warm water and allow it to air dry before storing.

3. Storage

Store the mop in its provided storage tray to prevent the pads from touching the floor and to catch any residual drips. Ensure the mop is fully charged before storing for extended periods.



Image: The BISSELL Spinwave mop resting on its dedicated storage tray, designed for convenient and tidy storage.

TROUBLESHOOTING

- Mop not turning on:** Ensure the battery is fully charged and the power button is pressed firmly.
- No solution dispensing:** Check if the solution tank is correctly inserted and filled. Ensure the spray trigger is being pressed.
- Pads not spinning:** Verify that the mop pads are securely attached and not obstructed.
- Streaking on floors:** This may occur if too much solution is used or if pads are dirty. Use less solution or replace/clean pads.

SPECIFICATIONS

Brand	Bissell
Model Name	SpinWave Cordless Hard Floor Expert
Model Number	23159
Power Source	Battery Powered (18V Lithium Ion)
Item Weight	9.5 Pounds
Surface Recommendation	Hard Floor
Included Components	Battery, 4 Mop Pads, 2 Trial-Size Cleaning Solutions
UPC	011120260540

WARRANTY AND SUPPORT

BISSELL offers various protection plans for your Spinwave Cordless Hard Floor Expert Spin Mop:

- 2-Year Protection Plan:** Available for purchase.
- 3-Year Protection Plan:** Available for purchase.
- Complete Protect:** A monthly plan covering all eligible past and future purchases.

For further assistance, product registration, or to purchase accessories, please visit the official BISSELL website or contact customer support. The manufacturer is BISSELL.