



Manuals.plus /

› PARASOL /

› PARASOL 2x3m Rectangular Garden Tilting Table Umbrella User Manual

PARASOL Rectangular Garden Tilting Table Umbrella

PARASOL 2x3m Rectangular Garden Tilting Table Umbrella User Manual

Model: Rectangular Garden Tilting Table Umbrella

ASIN: B08F79RTQC

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and operating your PARASOL umbrella. Retain this manual for future reference.

- Always close the umbrella when not in use or during windy conditions to prevent damage or injury.
- Ensure the umbrella base (not included) is sufficiently weighted to prevent tipping.
- Do not use the umbrella near open flames or heat sources.
- Keep children and pets away from the umbrella during operation.
- Inspect the umbrella regularly for any signs of wear or damage. Do not use if damaged.

2. PRODUCT OVERVIEW

The PARASOL Rectangular Garden Tilting Table Umbrella provides shade and comfort for your outdoor living space. It features a durable 180g polyester canopy, an aluminum frame, a convenient crank handle for opening and closing, and a tilting mechanism for adjustable shade.



Image 1: The PARASOL rectangular umbrella in an open position, providing shade over a patio table and chairs. The canopy is a light beige color.

3. COMPONENTS AND DIMENSIONS

Before assembly, ensure all components are present and undamaged. Refer to the diagram below for key dimensions and parts.

- Canopy (180g Polyester)
- Umbrella Pole (Aluminum, 38mm diameter)
- Crank Handle Mechanism
- Tilting Mechanism
- Ribs and Spreader Arms




Image 2: A technical diagram illustrating the umbrella's dimensions: 2 meters by 3 meters for the canopy, 2.5 meters total height, and a 38mm diameter pole. Details of the 30-degree tilt function and the crank handle are also highlighted.

4. SETUP INSTRUCTIONS

Follow these steps to assemble your umbrella:

1. **Prepare the Base:** Ensure you have a suitable, weighted umbrella base (sold separately) placed on a flat, stable surface.
2. **Insert the Pole:** Carefully insert the lower section of the umbrella pole into the umbrella base. Tighten any securing screws on the base to hold the pole firmly in place.
3. **Attach the Canopy Section:** Align the upper section of the umbrella pole (with the canopy attached) with the lower pole section. Secure them together according to the design (usually a push-button lock or screw-in connection).
4. **Verify Stability:** Gently shake the assembled umbrella to ensure it is stable and securely seated in the base.

5. OPERATING INSTRUCTIONS

5.1 Opening the Umbrella

1. Locate the crank handle on the umbrella pole.
2. Turn the crank handle clockwise to slowly open the umbrella canopy. Continue cranking until the canopy is fully extended and taut. Do not over-crank.

5.2 Tilting the Canopy

The umbrella features a tilting mechanism to adjust the angle of the canopy for optimal shade.

1. Once the umbrella is fully open, locate the tilting button or lever on the pole, typically above the crank

handle.

2. Press the button or engage the lever and gently push the canopy in the desired direction to tilt it. The umbrella can tilt up to 30 degrees.
3. Release the button/lever to lock the canopy in the tilted position.

5.3 Closing the Umbrella

1. If the umbrella is tilted, return it to the upright position first by engaging the tilt mechanism and gently pushing the canopy back.
2. Turn the crank handle counter-clockwise to slowly retract the umbrella canopy.
3. Continue cranking until the canopy is fully closed and secured.



Image 3: The rectangular umbrella fully open, demonstrating its coverage over an outdoor seating area. This view highlights the canopy's shape and how it integrates with patio furniture.

6. MAINTENANCE

Regular maintenance will extend the life of your PARASOL umbrella.

- **Cleaning the Canopy:** Clean the polyester canopy with mild soap and water. Rinse thoroughly and allow to air dry completely before closing or storing. Do not use harsh chemicals or abrasive cleaners.

- **Frame Care:** Wipe the aluminum frame with a damp cloth. Avoid scratching the finish.
- **Lubrication:** Periodically apply a silicone-based lubricant to the crank mechanism and tilting joints to ensure smooth operation.
- **Storage:** When not in use for extended periods, especially during harsh weather or winter, close the umbrella and secure it with a tie strap (if included). For best protection, use a weather-resistant umbrella cover or store it indoors.



Image 4: The rectangular umbrella in a fully closed position, standing upright. This demonstrates how the canopy folds neatly around the pole for compact storage.



Image 5: A close-up view of the underside of the umbrella canopy, revealing the robust aluminum frame structure and ribs that support the polyester fabric. This image shows the internal construction.

7. TROUBLESHOOTING

- **Umbrella not opening/closing smoothly:**
Check for any obstructions in the canopy or crank mechanism. Apply silicone lubricant to the crank and moving parts. Ensure the pole sections are securely connected.
- **Tilting mechanism is stuck:**
Ensure the umbrella is fully open before attempting to tilt. Check for debris or corrosion in the tilting joint. Apply lubricant if necessary.
- **Umbrella feels unstable:**
Verify that the umbrella base is adequately weighted and placed on a level surface. Ensure the umbrella pole is fully inserted and secured in the base.

8. SPECIFICATIONS

- **Canopy Dimensions:** 2 meters x 3 meters (Rectangular)
- **Overall Height:** 2.5 meters

- **Pole Diameter:** 38 mm
- **Canopy Material:** 180g Polyester
- **Frame Material:** Aluminum
- **Features:** Crank Handle, 30-degree Tilting Mechanism

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. If you require further assistance or have questions not covered in this manual, please contact the seller directly through your purchase platform.