

[Manuals.plus](#) /

> [JBL](#) /

> JBL GO 3 Portable Bluetooth Speaker User Manual

JBL JBLGO3BLU

JBL GO 3 Portable Bluetooth Speaker User Manual

Model: JBLGO3BLU

INTRODUCTION

The JBL GO 3 is an ultra-portable and lightweight Bluetooth speaker designed for on-the-go use. It features JBL Pro Sound, a modern design, and is available in various colors. This speaker allows you to stream music wirelessly from your mobile phone or smartphone, offering up to 5 hours of playtime on a single charge. The GO 3 is built to withstand outdoor adventures, being IP67 rated for water and dust resistance.



Image: The JBL GO 3 speaker, demonstrating its ultra-portable design, shown on a sandy beach next to individuals.

WHAT'S IN THE BOX

Upon unboxing your JBL GO 3, you should find the following items:

- 1x JBL GO 3 Portable Bluetooth Speaker
- 1x USB Type-C Cable
- 1x Quick Start Guide

- 1x Safety Sheet

PRODUCT OVERVIEW

Speaker Components



Image: Front view of the JBL GO 3 speaker, showcasing its compact design and JBL logo.



Image: Top panel of the JBL GO 3, displaying the volume up (+), play/pause (triangle), and volume down (-) buttons.



Image: Side view of the JBL GO 3, featuring the integrated fabric loop for portability.



Image: Bottom view of the JBL GO 3, showing the anti-slip rubberized feet and regulatory markings.

SETUP

1. Charging the Battery

Before first use, fully charge the JBL GO 3. Connect the supplied USB Type-C cable to the charging port on the speaker and to a USB power adapter (not included). The charging indicator light will show the charging status.

- **Charging Time:** Approximately 2.5 hours (with 5V/1A adapter).
- **Battery Type:** Lithium-ion polymer (22.2 Wh).



Image: The JBL GO 3 speaker shown during a picnic, illustrating its battery life of up to 5 hours.

2. Power On/Off

To power on the speaker, press the power button located on the side. Press and hold the power button again to turn it off.

3. Bluetooth Pairing

1. Turn on the JBL GO 3. The Bluetooth indicator light will flash, indicating it is in pairing mode.
2. On your mobile device, go to Bluetooth settings and select "JBL GO 3" from the list of available devices.
3. Once connected, the Bluetooth indicator light will remain solid.



Image: Icon representing Bluetooth connectivity.

OPERATING INSTRUCTIONS

Playing Music

- **Play/Pause:** Press the play/pause button (triangle icon) once to play or pause music.
- **Next Track:** Double-press the play/pause button to skip to the next track.
- **Volume Control:** Use the volume up (+) and volume down (-) buttons on the speaker to adjust the audio level.



Image: Icon representing JBL Pro Sound quality.

MAINTENANCE

Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive materials. Ensure the charging port cover is securely closed before cleaning with water.

Water and Dust Resistance (IP67)

The JBL GO 3 is IP67 rated, meaning it is protected against dust ingress and can withstand immersion in water up to 1 meter for up to 30 minutes. For optimal performance and longevity, ensure the charging port cover is fully sealed before exposing the speaker to water or dust. After exposure to water, allow the speaker to dry completely before charging.



**FULLY WATERPROOF
AND DUSTPROOF IP67**

Image: The JBL GO 3 speaker shown partially submerged in shallow water on a sandy beach, illustrating its IP67 waterproof capability.



Image: Icon indicating IP67 water and dust resistance.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the supplied USB-C cable.
Cannot pair via Bluetooth.	Speaker is not in pairing mode or too far from device.	Ensure speaker is on and Bluetooth indicator is flashing. Move device closer. Try re-pairing.
No sound or low volume.	Volume too low on speaker or connected device.	Increase volume on both the speaker and your connected device.
Poor sound quality.	Interference or device too far.	Move speaker closer to the connected device. Avoid obstacles between devices.
Speaker unresponsive.	Temporary software glitch.	To reset the product, turn on the speaker and simultaneously press the volume + button and the Bluetooth button for 3 to 5 seconds until the speaker turns off.

SPECIFICATIONS



Image: Diagram showing the dimensions of the JBL GO 3 speaker.

Model Name: JBLGO3BLU

Brand: JBL

Output Power: 4.2 Watts RMS

Frequency Response: 110 Hz to 20 kHz

Signal-to-Noise Ratio: > 85 dB

Connectivity Technology: Bluetooth, USB

Bluetooth Version: 5.1

Bluetooth Profiles: A2DP 1.3, AVRCP 1.6

Bluetooth Transmitter Power: ≤ 8 dBm (EIRP)

Bluetooth Range: 10 Meters

Battery Life: Up to 5 hours (varies with volume level and audio content)

Battery Charge Time: 2.5 hours (5V/1A)

Battery Type: Lithium-ion polymer (22.2 Wh)

Water Resistance: IP67 (Waterproof and Dustproof)

Material: Plastic

Dimensions (P x L x H): 7.5 x 8.7 x 4.1 cm (Depth x Width x Height)

Item Weight: 209 Grams

Compatible Devices: Laptop, Tablet, Smartphone

Control Method: Buttons

UPC: 050036374378, 194644118723

WARRANTY AND SUPPORT

The JBL GO 3 comes with a limited warranty. Please refer to the safety sheet included in the box for detailed warranty information.

- **Warranty Description:** 12 Months
- **Availability of Spare Parts:** 2 Years

For further assistance, please visit the official JBL support website or contact their customer service. You can visit the JBL brand store for more products and information:[JBL Brand Store](#)