Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- QUALIAZERO /
- > QUALIAZERO 50L/13Gal Heavy Duty Hands-Free Stainless Steel Commercial/Kitchen Step Trash Can Instruction Manual

QUALIAZERO QAMZZ10002

QUALIAZERO 50L/13Gal Stainless Steel Step Trash Can Instruction Manual

Model: QAMZZ10002

1. PRODUCT OVERVIEW

The QUALIAZERO 50L/13Gal Heavy Duty Hands-Free Stainless Steel Step Trash Can is designed for versatile use in various environments such as kitchens, offices, living rooms, and commercial spaces. Its rectangular shape and fingerprint-resistant stainless steel construction offer both functionality and a sleek aesthetic. Key features include a soft-close lid, a convenient step-on mechanism, and a removable inner bucket for easy waste management.



Figure 1: Front view of the QUALIAZERO 50L Stainless Steel Step Trash Can.

2. KEY FEATURES

- 100% Satisfaction Guarantee: Backed by a dedicated customer support team and worry-free defective replacement.
- High-Quality Construction: Made from durable stainless steel and ABS, built for longevity.
- Fingerprint and Smudge Resistant: Special coating ensures easy cleaning and maintains a pristine appearance.
- Large, Wide Opening: Provides easy access for daily waste disposal.
- Modern, Stylish Design: Elegant design that complements various home and office decors.
- **Multi-Purpose Use:** Suitable for kitchens, bathrooms, schools, hotels, airports, construction sites, offices, indoor/outdoor use, boats, RVs, and more.

3. SPECIFICATIONS

Attribute	Detail
Brand	QUALIAZERO
Capacity	50 Liters / 13.2 Gallons
Color	STAINLESS STEEL
Opening Mechanism	Step-On
Material	Stainless Steel
Finish Type	Matte Gray
Item Weight	11.8 Pounds
Product Dimensions (L x W x H)	17" x 14.8" x 24.41"
Model Number	QAMZZ10002
UPC	810055170012
Assembly Required	No
Special Feature	Quiet Close




Figure 2: Product dimensions and capacity.

4. SETUP GUIDE

- 1. Unboxing: Carefully remove the trash can from its packaging. Inspect for any damage during transit.
- 2. **Placement:** Position the trash can in your desired location. Ensure there is enough space for the lid to open fully without obstruction.
- 3. **Insert Inner Bucket:** The trash can comes with a removable inner bucket. Place this bucket securely inside the main stainless steel body.
- 4. **Install Trash Bag:** Line the inner bucket with a standard 13-gallon (50L) trash bag. Ensure the bag's rim is tucked neatly around the top edge of the inner bucket to keep it hidden from view.







Figure 3: Inner bucket for easy bag installation.

5. OPERATING INSTRUCTIONS

- 1. **Opening the Lid (Foot Pedal):** Gently step on the foot pedal located at the base of the trash can. The lid will open smoothly.
- 2. **Soft-Close Mechanism:** Release the foot pedal, and the lid will slowly and quietly close on its own, preventing slamming and reducing noise.
- 3. **Keeping the Lid Open:** To keep the lid open for extended periods (e.g., when changing bags or during food preparation), manually push the lid back until it stays in the open position.
- 4. **Removing/Replacing Trash Bag:** Once the trash bag is full, lift the inner bucket out of the main body. Remove the full bag, dispose of it, and replace it with a new one. Reinsert the inner bucket into the main body, ensuring it is seated flush and flat for proper lid closure.



Figure 4: Illustration of the soft-close lid operation.



Figure 5: Detail of the durable foot pedal.

6. CARE AND MAINTENANCE

- **Regular Cleaning:** For routine cleaning of the stainless steel exterior, use a damp microfiber cloth. Wipe gently to remove dust, fingerprints, and smudges.
- **Stubborn Marks:** For more stubborn marks, a mild stainless steel cleaner can be used. Always wipe in the direction of the grain to avoid streaks.
- Inner Bucket Cleaning: The removable inner bucket can be washed with soap and water. Rinse thoroughly and dry before reinserting.
- Avoid Harsh Chemicals: Do not use abrasive cleaners, steel wool, or harsh chemical solvents, as these can damage the finish.
- Lid Mechanism: Keep the lid mechanism clean and free of debris. Avoid forcing the lid open or closed, as this can damage the soft-close feature.



Figure 6: Internal components and inner rim.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Lid mechanism broke / doesn't close slowly	Damage to the soft-close mechanism due to excessive force or wear.	Avoid forcing the lid. If under warranty, contact customer support for replacement.
Lid not closing tightly	Inner trash can not seated flush or flat.	Ensure the inner bucket is properly aligned and fully seated inside the main body.
Trash can "walks" or moves from its position	Repeated use of the lift pedal causing slight movement; light weight of the can.	Consider adding a non-slip mat underneath or placing some weight in the bottom of the can to stabilize it.

8. WARRANTY AND CUSTOMER SUPPORT

The QUALIAZERO 50L/13Gal Stainless Steel Step Trash Can comes with a **1-year manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or any questions regarding your product, please contact QUALIAZERO customer support. Refer to the product packaging or the official QUALIAZERO website for the most current contact information.

© 2025 QUALIAZERO. All rights reserved.

Related Documents - QAMZZ10002

Warranty

In the control of the cont

QualiaWare Product Warranty Information and Terms

Comprehensive warranty details for QualiaWare products, covering standard residential and commercial use, exclusions, registration, and liability limitations. Learn about your product's warranty coverage.