Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HAOBO Home B08FCB78R4

HAOBO Home Accent Chair Instruction Manual

Model: living room chairs | Brand: HAOBO Home

Introduction

Thank you for choosing the HAOBO Home Accent Chair. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure you get the most out of your new furniture. Please read through this manual carefully before beginning assembly or use.



Image: The HAOBO Home Accent Chair, showcasing its elegant design and ivory upholstery.

Specifications

Feature	Detail
Brand	HAOBO Home
Model Name	living room chairs
Color	Ivory
Product Dimensions	39"D x 27"W x 32"H
Item Weight	34.3 pounds
Fill Material	Foam

Style	Contemporary
Special Feature	Arm Rest, Cushion Availability
Recommended Uses	Dining, Living Room, Bedroom



Image: Detailed size information for the accent chair.



Image: Product details illustrating the button tufted curved backrest, soft fabric, and sturdy wood legs.

Setup and Assembly

The HAOBO Home Accent Chair is designed for straightforward assembly. Please follow the steps below. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

Assembly Video Guide

Your browser does not support the video tag.

Video: Official assembly guide for the HAOBO Home Accent Chair, demonstrating each step of the setup process.

Step-by-Step Assembly Instructions:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components and hardware are present according to the parts list. The main components include the seat base, backrest, and four legs. Hardware includes various bolts and washers.

2. **Prepare Hardware:** Identify the different types of bolts and washers (e.g., longer bolts for the backrest, shorter bolts for the legs). Ensure you have the correct quantity of each.
3. **Attach Front Legs:** Locate the fabric flap on the underside of the seat base. Open this flap to reveal the pre-drilled holes. Attach the two front legs to the designated corners using the appropriate bolts and washers. Tighten securely with the provided Allen wrench.
4. **Attach Rear Legs:** Similarly, attach the two rear legs to the remaining corners on the underside of the seat base. Ensure all leg attachments are firm and stable.
5. **Connect Backrest to Seat Base:** Align the backrest with the seat base. There are pre-drilled holes on both components that will match up. Use the longer bolts and washers to secure the backrest to the seat base. Tighten all bolts evenly to ensure a stable connection.
6. **Final Check:** Once all parts are assembled, gently shake the chair to ensure it is stable. Retighten any loose bolts if necessary. Close the fabric flap on the underside of the seat base.

Usage and Placement

The HAOBO Home Accent Chair is versatile and can enhance various spaces in your home. Its armless design and compact footprint make it ideal for smaller areas or as an additional seating option.

- **Living Room:** Perfect as an accent chair, providing extra seating for guests or a cozy spot for reading.
- **Bedroom:** Can serve as a stylish vanity chair or a comfortable corner seat.
- **Dining Room:** Suitable as an occasional dining chair, especially for smaller dining areas.
- **Study Room/Office:** Offers a comfortable alternative to traditional office chairs for short periods of relaxation or reading.
- **Entryway:** Provides a convenient spot to sit while putting on or taking off shoes.

Ensure the chair is placed on a flat, stable surface to prevent wobbling. Avoid placing it in direct sunlight or near heat sources to preserve the fabric and foam integrity.



Image: Examples of the accent chair in various home settings, including bedroom, living room, study room, and dining room.

Care and Maintenance

Proper care will extend the life and appearance of your HAOBO Home Accent Chair.

- **General Cleaning:** For everyday cleaning, simply wipe the chair clean with a soft, dry cloth.
- **Spot Cleaning:** For spills or stains, blot immediately with a clean, dry cloth. For tougher stains, use a mild fabric cleaner and follow the product instructions. Test the cleaner on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or solvents, as these can damage the fabric and finish.
- **Vacuuming:** Regularly vacuum the upholstery using a soft brush attachment to remove dust and debris.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight can cause fading. Position the chair away from direct sunlight or use curtains/blinds to protect it.
- **Check Connections:** Periodically check all bolts and connections to ensure they remain tight. Retighten if necessary to

maintain stability and safety.

Troubleshooting

If you encounter any issues with your HAOBO Home Accent Chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair wobbles or is unstable.	Legs are not evenly tightened or floor is uneven.	Ensure all leg bolts are tightened securely and evenly. If the floor is uneven, consider using furniture pads or shims under the shorter leg(s).
Squeaking noises during use.	Loose connections or friction between parts.	Check and tighten all assembly bolts. If squeaking persists, a small amount of silicone lubricant can be applied to contact points between wood and metal, if applicable.
Fabric appears loose or wrinkled.	Normal settling of upholstery over time.	This is often normal for upholstered furniture. Gently smooth the fabric by hand. Avoid excessive pulling or stretching.
Missing parts during assembly.	Packaging error or lost during unpacking.	Double-check all packaging materials. If parts are still missing, contact HAOBO Home customer support with your purchase details.

Warranty and Support

For any questions, concerns, or to inquire about warranty information, please contact HAOBO Home customer support. Keep your purchase receipt and model information handy for faster service.
You can visit the official HAOBO Home store for more products and support:HAOBO Home Store
Protection plans are also available for extended coverage:

- 2-Year Protection Plan: $27.99
- 3-Year Protection Plan: $34.99
- Complete Protect: $16.99/month (covers all eligible past and future purchases)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08FCB78R4

More documents and user manuals: **https://manuals.plus/**