

[Manuals.plus](#) /

> [Movado](#) /

> [Movado Analog Blue Dial Men's Watch - Model 607356 Instruction Manual](#)

Movado 607356

Movado Analog Blue Dial Men's Watch - Model 607356 Instruction Manual

Your guide to setting up, operating, and maintaining your Movado timepiece.

PRODUCT OVERVIEW

The Movado Modern Classic Collection watch, model 607356, features a sophisticated blue round dial with a 39 mm stainless steel case and a multi-colour stainless steel strap. It operates on a precise quartz movement and is protected by a durable mineral glass. This timepiece is designed for men and offers a blend of classic elegance and modern functionality.



Image: Front view of the Movado Analog Blue Dial Men's Watch, Model 607356, showcasing its blue dial, gold-tone accents, and two-tone stainless steel bracelet.

SETUP AND INITIAL USE

Before wearing your new Movado watch, it is important to set the correct time and date (if applicable). Your watch is powered by a quartz movement, which means it uses a battery (1 Lithium Ion battery included).

Setting the Time:

1. **Locate the Crown:** The crown is the small knob on the right side of the watch case.
2. **Pull Out the Crown:** Gently pull the crown outwards to the first or second position. For time setting, pull it out to the furthest position (usually the second click).
3. **Adjust the Time:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
4. **Push In the Crown:** Once the time is set, push the crown back in completely to its original position. This will start the

watch movement.

Setting the Date (if applicable):

This model features a date display. To set the date:

1. **Pull Out the Crown:** Gently pull the crown outwards to the first position (usually the first click).
2. **Adjust the Date:** Turn the crown in the appropriate direction (usually clockwise) to advance the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.
3. **Push In the Crown:** Once the date is set, push the crown back in completely to its original position.

OPERATING YOUR WATCH

Your Movado watch is designed for daily wear. Once the time and date are set, the watch will operate continuously. The quartz movement ensures accurate timekeeping with minimal intervention.

Water Resistance:

This watch has a water resistance depth of 30 meters (3 ATM). This rating means the watch is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in before any contact with water.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your Movado watch.

- **Cleaning:** Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and dirt. For the stainless steel components, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not expose your watch to harsh chemicals, solvents, or detergents, as these can damage the case, strap, or internal components.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect the movement and battery life.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, as they can affect the accuracy of the quartz movement.
- **Battery Replacement:** The watch uses a Lithium Ion battery. When the watch stops or the second hand begins to jump erratically (if applicable), it indicates a low battery. Battery replacement should be performed by a qualified watchmaker or authorized service center to ensure proper sealing and functionality.

TROUBLESHOOTING

If you encounter issues with your Movado watch, consider the following common solutions:

- **Watch Not Running:**
 - Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
 - The battery may be depleted. Refer to the "Battery Replacement" section under Maintenance.
- **Incorrect Time/Date:**
 - Re-set the time and date according to the "Setup and Initial Use" instructions.
 - Ensure the crown is fully pushed in after setting.

- **Condensation Under Glass:**

- This indicates moisture has entered the watch. Immediately take the watch to an authorized service center to prevent further damage to the movement.

For issues not covered here, or for professional service, please contact an authorized Movado service center.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	607356
Dial Color	Blue
Case Shape	Round
Dial Glass Material	Mineral
Band Color	Multi-Colour
Band Material	Stainless Steel
Watch Movement Type	Quartz
Watch Display Type	Analog
Case Material	Stainless Steel
Case Diameter	39 millimeters
Water Resistance Depth	30 meters
Batteries	1 Lithium Ion batteries required (included)
Product Dimensions	8 x 8 x 8 cm
Item Weight	300 g
Date First Available	6 August 2020
Department	Men

WARRANTY AND SUPPORT

Your Movado watch comes with a manufacturer's warranty to cover defects in materials and workmanship.

- **Warranty Period:** The product is covered by a 2-year warranty period.
- **Warranty Type:** Manufacturer Warranty.
- **Service:** For warranty claims or service, please contact an authorized Movado service center. Retain your proof of purchase for warranty validation.

For further assistance or inquiries, you may contact the manufacturer or importer directly:

Manufacturer: Bettlachstrasse 8, 2540 Grenchen Suisse, Movado

Importer: La Sagne au Droz 18, 2714 Les Genevez Tel: +41 (0) 32 484 70 10, +41 (0) 32 484 70 580

