

LOWELL JA7082JU1

LOWELL Juventus FC Quartz Analog Alarm Clock Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your LOWELL Juventus FC Quartz Analog Alarm Clock. Please read this manual thoroughly before using the product to ensure proper function and longevity.

2. SAFETY INFORMATION

- Keep the alarm clock away from water and high humidity.
- Avoid exposing the device to extreme temperatures or direct sunlight.
- Do not attempt to disassemble or repair the alarm clock yourself. Refer to qualified personnel for service.
- Dispose of used batteries responsibly according to local regulations.
- Keep batteries out of reach of children.

3. PACKAGE CONTENTS

- LOWELL Juventus FC Quartz Analog Alarm Clock (Model: JA7082JU1)
- Instruction Manual

4. PRODUCT OVERVIEW



Figure 1: Front and side view of the LOWELL Juventus FC Quartz Analog Alarm Clock. The clock is designed in the shape of a soccer ball, featuring the Juventus logo prominently on its black face. The analog display has white numbers and luminous hands for visibility in low light. A small knob for setting time and alarm is visible on the back/side.

The LOWELL Juventus FC Quartz Analog Alarm Clock is a battery-operated device designed for timekeeping and alarm functions. It features a quartz movement for accurate time and luminous hands for easy reading in the dark.

Key Components:

- **Time Setting Knob:** Located on the back, used to adjust the current time.
- **Alarm Setting Knob:** Located on the back, used to set the desired alarm time.
- **Alarm ON/OFF Switch:** Located on the back, used to activate or deactivate the alarm.
- **Battery Compartment:** Located on the back, for battery installation.

5. SETUP

5.1. Battery Installation

1. Open the battery compartment cover located on the back of the alarm clock.
2. Insert one AA battery (not included) into the compartment, ensuring the correct polarity (+ and -).
3. Close the battery compartment cover securely.

5.2. Initial Time Setting

1. Locate the Time Setting Knob on the back of the clock.
2. Rotate the knob in either direction until the hour and minute hands display the current time.

6. OPERATING INSTRUCTIONS

6.1. Setting the Alarm

1. Locate the Alarm Setting Knob on the back of the clock.
2. Rotate this knob until the small alarm hand points to your desired alarm time.

6.2. Activating/Deactivating the Alarm

1. To activate the alarm, slide the Alarm ON/OFF Switch to the 'ON' position.
2. To deactivate the alarm, slide the Alarm ON/OFF Switch to the 'OFF' position.

6.3. Luminous Feature

The hour and minute hands are designed with a luminous coating. After exposure to light, they will glow in the dark for a period, allowing for easy time reading at night.

7. MAINTENANCE

- **Cleaning:** Wipe the clock surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace the battery when the clock starts losing time or the alarm weakens. Always use a fresh AA battery.
- **Storage:** If storing the clock for an extended period, remove the battery to prevent leakage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not working / losing time	Dead or weak battery	Replace with a new AA battery.
Alarm not sounding	Alarm switch is OFF	Slide the Alarm ON/OFF Switch to 'ON'.
	Alarm time not set correctly	Adjust the Alarm Setting Knob to the desired time.

9. SPECIFICATIONS

- **Brand:** LOWELL
- **Model:** JA7082JU1
- **Color:** White (with black accents)
- **Dimensions:** Approximately 12.2 x 10.9 x 10.1 cm
- **Weight:** Approximately 160 grams
- **Material:** Rubber
- **Special Features:** Alarm, Luminous hands
- **Display Type:** Analog
- **Power Source:** 1 x AA Battery (not included)
- **Movement:** Quartz

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer where the product was purchased or contact LOWELL customer service directly. Please retain your proof of purchase for any warranty claims.