

[Manuals.plus](#) /

> [JOYMOR](#) /

> JOYMOR 5-in-1 Convertible Baby High Chair Instruction Manual (Model HCW)

JOYMOR HCW

JOYMOR 5-in-1 Convertible Baby High Chair Instruction Manual

Model: HCW | Brand: JOYMOR

[Introduction](#) [What's in the Box](#) [Assembly](#) [Operation](#)
[Modes](#) [Maintenance](#) [Specifications](#) [Troubleshooting](#) [Warranty & Support](#)

1. INTRODUCTION

The JOYMOR 5-in-1 Convertible Baby High Chair (Model HCW) is designed to adapt to your child's growth, offering multiple configurations from infancy through toddlerhood. This manual provides detailed instructions for assembly, operation, maintenance, and safety to ensure proper use of the product.

Key Features:

- **Versatile 5-in-1 Functionality:** Transforms into a full-size highchair, infant floor seat, toddler booster, kid's chair, and a kid's table and chair set.
- **Removable and Adjustable Tray:** Features a 4-position adjustable and removable double tray for easy cleaning and adaptability as your child grows.
- **Sturdy and Safe Design:** Equipped with an adjustable and removable 5-point harness, A-shaped structure for anti-tip stability, and anti-slip foot pads.
- **Easy Installation and Cleaning:** Tool-free installation with clear instructions. Detachable PU cushion allows for quick wiping with a damp cloth.

5-in-1 Convertible High Chair



**Kids
Table & Chair**



Todder Chair



**Baby Feeding
Low Chair**



Kids Chair

Figure 1: Visual representation of the 5-in-1 convertible modes.

2. WHAT'S IN THE BOX

Please verify that all components listed below are present in your package before beginning assembly.

- High Chair Body (Upper body, Chair body)
- Double Plate (Tray)
- Cushion
- Safety Belt (5-point harness)
- Foot Pads (4 pieces)
- Lower Legs (4 pieces)
- Upper Legs (4 pieces)
- Table
- Table Cover

- Netbag
- Storage Basket



Figure 2: All included components of the high chair.

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. No tools are required.

3.1. Watch the Assembly Video

Your browser does not support the video tag.

Video 1: Step-by-step assembly guide for the JOYMOR Baby High Chair.

This video demonstrates the unboxing and assembly process for the high chair, showcasing how to configure it into different modes.

3.2. Low Chair Assembly

1. **Attach Upper Body to Chair Body:** Align the backrest (upper body) with the main seat (chair body) and press down until it clips securely into place. You should hear a "ka" sound indicating proper installation.
2. **Install Short Legs:** Insert the four short leg tubes into the designated holes on the underside of the chair body. Ensure they are firmly seated.
3. **Attach Seat Cushion:** Place the leather seat cushion onto the chair. Thread the safety belt through the designated slots in the cushion and the chair body.
4. **Secure Safety Belt:** Adjust the 5-point harness to fit your child snugly and securely.
5. **Attach Tray:** Align the double plate tray with the chair's armrests. Press the buttons on the underside of the tray to adjust its position. The tray is removable for easy cleaning.



Figure 3: Key safety and convenience features.

3.3. High Chair Assembly

1. **Prepare Table Base:** Take the table component and insert the four long leg tubes into its underside. Ensure they click into place.

2. **Attach Low Chair to Table Base:** Place the assembled low chair onto the table base. The legs of the low chair should fit into the central opening of the table base, creating a stable high chair structure.
3. **Secure Tray:** Re-attach the double plate tray to the high chair's armrests, adjusting it to the desired position.
4. **Install Storage Basket:** The netbag storage basket can be attached to the underside of the table base for convenient storage.



Figure 4: The high chair in its full assembly.

4. OPERATING MODES

The JOYMOR high chair offers five versatile modes to accommodate your child's developmental stages:

- **Full-Size Highchair (0-2 years old):** Provides a secure and elevated feeding position, allowing your child to join family meals at the table.
- **Infant Floor Seat (0-2 years old):** By removing the long legs, the seat can be used directly on the floor for younger infants.

- **Toddler Booster (3-6 years old):** The seat can be used as a booster seat, attaching to an adult dining chair (attachment straps not explicitly mentioned but implied by booster function).
- **Kid's Chair (3-6 years old):** The low chair configuration can serve as a standalone chair for toddlers.
- **Kid's Table and Chair Set (6+ years old):** The table base and the low chair can be used independently as a play or activity table with a matching chair.



Figure 5: Child using the low chair and table configuration.

5. MAINTENANCE AND CLEANING

- **Seat Cushion:** The detachable PU cushion is designed for easy cleaning. Simply wipe it with a damp cloth to remove spills and food residue.
- **Trays:** The double plate tray is removable and can be washed by hand or placed in a dishwasher for thorough cleaning.
- **Frame and Legs:** Wipe down the plastic and wooden components with a damp cloth and mild soap as needed. Avoid abrasive cleaners.
- **Safety Harness:** The 5-point harness can be removed and hand-washed with mild soap and water. Ensure it is completely dry before reattaching.
- **Regular Inspection:** Periodically check all parts for wear, damage, or loose connections. Discontinue use if any part is broken or missing.



Figure 6: Easy-to-clean seat cushion.

6. TROUBLESHOOTING

If you encounter any issues with your JOYMOR high chair, please refer to the following common solutions:

- **Difficulty Assembling Legs:** Ensure the leg tubes are aligned correctly with the holes and pushed firmly until a click is heard. If stuck, try rotating slightly while applying pressure.
- **Tray Not Attaching/Adjusting:** Verify that the tray is correctly aligned with the armrests. Press the release buttons firmly when attaching or adjusting the tray. Ensure no food debris is obstructing the mechanism.
- **Chair Feels Unstable:** Double-check that all legs are fully inserted and locked into place. Ensure the anti-slip foot pads are properly attached and the chair is on a flat, stable surface.
- **Harness Too Loose/Tight:** Adjust the straps of the 5-point harness to ensure a snug but comfortable fit for your

child. Refer to the assembly section for proper threading.

If the problem persists, please contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	24.5"D x 24.5"W x 39.5"H (High Chair Mode)
Item Model Number	HCW
Maximum Weight Recommendation	33 Pounds
Material Type	Beech Wood, Plastic, PU Leather
Item Weight	15.92 pounds (7.24 Kilograms)
Color	Gray/White
Portability	Yes



Figure 7: Product dimensions in various configurations.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact JOYMOR customer service through the retailer where the product was purchased or visit the official JOYMOR website.

Keep your purchase receipt as proof of purchase for any warranty claims.