

Manuals.plus /

- › **Globe Electric** /
- › Globe Electric 50200 Smart Wi-Fi Light Switch User Manual

## Globe Electric 50200

# Globe Electric 50200 Smart Wi-Fi Light Switch User Manual

Model: 50200

## INTRODUCTION

The Globe Electric 50200 Smart Wi-Fi Light Switch allows you to automate and control your home lighting using the GLOBE SUITE™ App, voice commands, or directly from the switch. This manual provides essential information for installation, operation, and maintenance to ensure safe and efficient use of your smart switch.



Image: The Globe Electric Smart Switch, highlighting its compatibility with various smart home platforms.

## SAFETY INFORMATION

Before installing or operating the Globe Electric 50200 Smart Wi-Fi Light Switch, please read and understand all safety instructions. Failure to follow these instructions may result in electric shock, fire, or property damage.

- **WARNING:** Risk of Electric Shock. Installation requires working with high voltage wiring. Always turn off power at the circuit breaker before installation.
- Consult a qualified electrician if you are unsure about any part of the installation process.
- This device is for indoor use only.

- Ensure the switch is installed in a standard wall box.
- Do not exceed the maximum wattage rating of 100 watts.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- Globe Electric 50200 Smart Wi-Fi Light Switch
- Screwless Faceplate
- Wires and Backplate
- Screws (2)
- Wire Nuts (4)
- Wire Label Stickers

## SETUP AND INSTALLATION

---

Follow these steps for proper installation of your smart switch. This switch is designed for single-pole indoor use only.

1. **Turn Off Power:** Locate your circuit breaker and turn off the power to the switch you are replacing. Verify the power is off using a voltage tester.
2. **Remove Old Switch:** Carefully remove the existing wall plate and unscrew the old switch from the wall box. Disconnect the wires, noting their connections (e.g., Line, Load, Neutral, Ground). Use the provided wire label stickers if needed.
3. **Wire the Smart Switch:** Connect the wires from your wall box to the corresponding wires on the Globe Electric 50200 Smart Switch using the provided wire nuts.
  - Connect the **Line** wire (usually black, coming from the breaker) to the Line wire on the smart switch.
  - Connect the **Load** wire (usually black, going to the light fixture) to the Load wire on the smart switch.
  - Connect the **Neutral** wire (usually white) to the Neutral wire on the smart switch. A neutral wire is required for this smart switch.
  - Connect the **Ground** wire (usually bare copper or green) to the Ground wire on the smart switch.
4. **Mount the Switch:** Gently push the wired smart switch into the wall box. Secure it with the provided screws. Attach the screwless faceplate.
5. **Restore Power:** Turn the power back on at the circuit breaker. The indicator light on the smart switch should illuminate.
6. **App Connection:**
  - Download the free **GLOBE SUITE™ App** from your smartphone's app store.
  - Open the app and create an account or log in.
  - Press the restart button located on the right side below the on/off rocker after installation.
  - Follow the in-app instructions to add your new smart switch. Ensure your phone is connected to a 2.4 GHz Wi-Fi network during the initial setup. You can switch back to a 5 GHz network afterward if preferred.

Replace traditional switches  
with smart to control your lights.



Image: The smart switch installed in a wall, demonstrating its integration into a home environment.

## OPERATING INSTRUCTIONS

Once installed and connected to the GLOBE SUITE™ App, you can operate your smart switch in several ways:

- **Manual Control:** Press the rocker switch directly to turn connected lights on or off.
- **App Control:** Use the GLOBE SUITE™ App on your smartphone to turn lights on/off from anywhere with an internet connection.
- **Voice Control:** Integrate with Amazon Alexa, Google Assistant, or Siri for hands-free control.
  - *Example Commands:* "Alexa, turn on the living room light," "Hey Google, turn off the kitchen switch," "Siri, activate evening scene."

Control your lights  
from anywhere.



Image: A user controlling the smart switch remotely via the GLOBE SUITE™ mobile application.

## APP INTEGRATION AND SMART FEATURES

The GLOBE SUITE™ App unlocks the full potential of your smart switch:

- **Scheduling:** Create custom schedules to automatically turn lights on or off at specific times, days of the week, or based on sunrise/sunset.
- **Scenes:** Combine multiple smart devices into custom scenes. For example, a "Movie Night" scene could dim lights and turn on entertainment devices simultaneously.
- **Automation:** Set up automations based on conditions like presence detection, temperature, or other smart device triggers.

Schedule your lights  
to turn On/Off.



Image: The GLOBE SUITE™ app interface demonstrating the scheduling feature for automated lighting control.



Link your smart products  
to create custom scenes.



Image: Demonstrates how to link multiple Globe Electric smart products to create custom scenes for various home activities.

## MAINTENANCE

The Globe Electric 50200 Smart Wi-Fi Light Switch requires minimal maintenance.

- **Cleaning:** Disconnect power at the circuit breaker before cleaning. Wipe the switch and faceplate with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Firmware Updates:** Periodically check the GLOBE SUITE™ App for available firmware updates to ensure optimal performance and security.

## TROUBLESHOOTING

If you encounter issues with your Globe Electric 50200 Smart Wi-Fi Light Switch, refer to the following common solutions:

Problem	Possible Cause	Solution
Switch does not turn on/off lights.	No power, incorrect wiring, or bulb issue.	Check circuit breaker. Verify wiring connections (Line, Load, Neutral, Ground). Test the light bulb.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi band, weak signal, or incorrect password.	Ensure your router is broadcasting a 2.4 GHz network. Move closer to the router. Double-check Wi-Fi password. Press the restart button on the switch and try pairing again.
Voice control not working.	Incorrect integration with voice assistant or device naming.	Ensure the GLOBE SUITE™ App is correctly linked to your Amazon Alexa, Google Assistant, or Siri account. Verify the device name in the app matches what you are saying.
Switch frequently disconnects.	Weak Wi-Fi signal or network interference.	Ensure the switch is within good range of your 2.4 GHz Wi-Fi router. Consider a Wi-Fi extender if necessary.

## SPECIFICATIONS

Feature	Detail
Model	50200
Brand	Globe Electric
Connectivity Protocol	Wi-Fi (2.4 GHz)
Control Method	App, Voice, Manual
Controller Type	Amazon Alexa, Google Assistant, Siri
Wattage	100 watts (Max)
Operation Mode	ON-NONE-ON or ON-ON-OFF
Switch Type	Rocker
Mounting Type	Wall Mount
Item Dimensions (L x W x H)	1.96 x 2.05 x 4.13 inches
Material	Metal, Plastic
Item Weight	0.28 Pounds
UPC	058219502006

## WARRANTY INFORMATION

The Globe Electric 50200 Smart Wi-Fi Light Switch comes with a **1-year manufacturer's limited warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the official Globe Electric website or contact customer support.

## SUPPORT

For further assistance, technical support, or warranty claims, please contact Globe Electric customer service. You can find contact information on the official Globe Electric website: [www.globe-electric.com](http://www.globe-electric.com).

You can also visit the Globe Electric Store on Amazon for more products and information: [Globe Electric Amazon Store](#).