

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Wireless Gear](#) /
- › [Wireless Gear Secure Fit Wireless Bluetooth Earbuds User Manual](#)

## Wireless Gear G0688

# Wireless Gear Secure Fit Wireless Bluetooth Earbuds

## USER MANUAL

Model: G0688

## Introduction

Thank you for purchasing the Wireless Gear Secure Fit Wireless Bluetooth Earbuds. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new device. Please read it carefully to ensure optimal performance and longevity of your earbuds.



Image: A pair of black Wireless Gear Secure Fit Wireless Bluetooth Earbuds, showing their ergonomic design with ear hooks.

## Setup

Follow these steps to set up your Wireless Gear earbuds for the first time.

### 1. Charging the Earbuds

Before first use, ensure the earbuds are fully charged. While specific charging instructions are not provided, these earbuds typically charge via a USB cable. Connect the charging cable to the earbuds and a power source. A full charge usually takes 1-2 hours.

## 2. Pairing with Your Device

The Wireless Gear earbuds feature automatic pairing for seamless connection.

1. Ensure your earbuds are charged and powered on.
2. Activate Bluetooth on your smartphone, tablet, laptop, or MP3 player.
3. Search for available Bluetooth devices. The earbuds should appear as "Wireless Gear Earbuds" or a similar name.
4. Select the earbuds from the list to connect. Once connected, you will hear an audio confirmation.



Image: The earbuds shown next to a smartphone and laptop, illustrating the automatic pairing and power-on feature for seamless connection with various devices.

## 3. Achieving a Secure Fit

The earbuds are designed with secure behind-the-ear hooks and ear gels for comfortable all-day wear, especially during activities like sports.

- Gently place the earbud into your ear canal.

- Position the ear hook over the back of your ear, ensuring it rests comfortably and securely.
- Adjust the earbud and hook until you achieve a snug fit that feels stable without causing discomfort.



Image: A person wearing the Wireless Gear earbuds, demonstrating the secure behind-the-ear fit provided by the contoured shape and ear hooks.

## Operating Instructions

The Wireless Gear earbuds feature convenient one-touch controls for easy operation.

### Music Playback Control

- **Play/Pause:** Single tap the touch button on either earbud.
- **Next Track:** Double tap the touch button on the right earbud.
- **Previous Track:** Double tap the touch button on the left earbud.

### Call Management

With the built-in microphone, you can manage calls hands-free.

- **Answer/End Call:** Single tap the touch button on either earbud during an incoming call.
- **Reject Call:** Press and hold the touch button for 2 seconds during an incoming call.

## Voice Assistant Activation

For iOS devices, you can activate Siri using the earbuds.

- **Activate Siri:** Triple tap the touch button on either earbud.



Image: Close-up view of the earbuds highlighting the touch control area and indicating features like hands-free calling with noise reduction.

## Battery Life

The earbuds provide up to 8 hours of playtime on a single charge, depending on usage volume and conditions.

# TRUE WIRELESS BLUETOOTH SPORT EARHOOKS

Advanced Bluetooth 5.0 and true wireless stereo technology provide rich sound quality and extreme bass



up to  
**8**  
HOURS  
of playtime

Image: A person wearing the earbuds, with text indicating "True Wireless Bluetooth Sport Earhooks," "up to 8 HOURS of playtime," and "Advanced Bluetooth 5.0."

## Maintenance

Proper care will extend the life of your earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Water Exposure:** Avoid exposing the earbuds to excessive moisture or submerging them in water. While designed for sports, they are not fully waterproof unless specified.

## Troubleshooting

If you encounter issues with your earbuds, try the following solutions:

Problem	Possible Cause	Solution
Earbuds won't turn on.	Low battery.	Charge the earbuds fully.
Cannot pair with device.	Bluetooth is off on device; earbuds not in pairing mode; too far from device.	Ensure Bluetooth is enabled. Make sure earbuds are powered on and discoverable. Move earbuds closer to the device (within 10 meters). Try forgetting the device on your phone and re-pairing.
No sound or poor sound quality.	Volume too low; earbuds not properly connected; interference.	Increase volume on both earbuds and connected device. Reconnect the earbuds. Move away from sources of strong electromagnetic interference.
Earbuds frequently disconnect.	Out of range; low battery; interference.	Stay within Bluetooth range. Charge the earbuds. Avoid strong Wi-Fi signals or other Bluetooth devices nearby.

## Specifications

Feature	Detail
<b>Model Name</b>	Wireless Gear True Wireless Bluetooth Secure Fit Earbuds, Black
<b>Model Number</b>	G0688
<b>Brand</b>	Wireless Gear
<b>Connectivity Technology</b>	Wireless (Bluetooth 5.0)
<b>Ear Placement</b>	In-Ear with Secure Ear Hooks
<b>Control Method</b>	Touch
<b>Color</b>	Black
<b>Compatible Devices</b>	Laptops, MP3 Players, Tablets, Mobile Phones
<b>Special Features</b>	Designed for Sports, Hands-free Calling, Noise Reduction
<b>Battery Type</b>	2 Lithium Ion (included)
<b>Estimated Playtime</b>	Up to 8 hours
<b>Product Dimensions</b>	Approx. 5.7 cm x 5.7 cm x 1.9 cm (2.25" x 2.25" x 0.75" each earbud)
<b>Package Dimensions</b>	13.97 x 7.62 x 3.81 cm
<b>Product Weight</b>	227 g (package weight)

# DIMENSIONS



Image: Diagram showing the approximate dimensions of the Wireless Gear earbuds, indicating their compact size.

## Warranty and Support

For detailed warranty information and customer support, please refer to the documentation included with your purchase or visit the official Wireless Gear website. Keep your proof of purchase for any warranty claims.

**Online Support:** [www.wirelessgear.com/support](http://www.wirelessgear.com/support) (Example link, please refer to actual product documentation for correct URL)

© 2023 Wireless Gear. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

## Related Documents - G0688

 EARBUDS PAIR AS WG-BT-EB	<p><a href="#"><u>Wireless Gear True Wireless Mini Earbuds User Manual and Specifications</u></a></p> <p>Comprehensive user manual for Wireless Gear True Wireless Mini Earbuds (WG-BT-EB) including setup, pairing, operation, features, safety, FCC information, and warranty details.</p>
	<p><a href="#"><u>Wireless Gear True Wireless Stereo Earbuds User Manual</u></a></p> <p>User manual for Wireless Gear True Wireless Stereo Earbuds, covering Bluetooth pairing, charging, device safety, battery information, FCC compliance, and limited warranty.</p>
	<p><a href="#"><u>Wireless Gear True Wireless Stereo Earbuds User Manual</u></a></p> <p>User manual for Wireless Gear True Wireless Stereo Earbuds, covering Bluetooth pairing, automatic pairing, charging instructions, device safety, battery information, technical support, FCC information, and limited warranty.</p>
	<p><a href="#"><u>Wireless Gear Wireless Charger BL2185-BL2189 User Manual</u></a></p> <p>User manual for the Wireless Gear Wireless Charger, models BL2185 and BL2189. Includes instructions, FCC information, and limited warranty details.</p>
	<p><a href="#"><u>POM Gear DriveX Premium Secure Fit Wireless Earbuds User Manual</u></a></p> <p>User manual for POM Gear DriveX Premium Secure Fit Wireless Earbuds. Learn about charging, basic use, pairing, making calls, technical specifications, warnings, and warranty.</p>
	<p><a href="#"><u>Jaybird Vista 2 User Manual</u></a></p> <p>User manual for the Jaybird Vista 2 true wireless sport earbuds, covering setup, controls, app features, and maintenance.</p>