

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Wireless Gear](#) /
- › [Wireless Gear Bluetooth 5.0 True Wireless Stereo Earbuds User Manual](#)

Wireless Gear G0678

Wireless Gear Bluetooth 5.0 True Wireless Stereo Earbuds User Manual

Model: G0678

INTRODUCTION

Thank you for choosing the Wireless Gear Bluetooth 5.0 True Wireless Stereo Earbuds. This manual provides comprehensive instructions to help you set up, operate, and maintain your new earbuds, ensuring optimal performance and longevity. These earbuds are designed to deliver rich audio and extreme bass with the convenience of true wireless technology.

TRUE WIRELESS STEREO

Bluetooth 5.0 technology with touch button control and auto pairing for easy use and strong connection



Image: A user enjoying music with the Wireless Gear True Wireless Stereo Earbuds, highlighting the seamless wireless experience.

SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- Do not expose the earbuds or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble, repair, or modify the product. This will void the warranty.
- Keep out of reach of children.
- Use only the provided charging cable or a certified equivalent.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a safe level.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Wireless Gear True Wireless Stereo Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your Wireless Gear Earbuds:



Image: The Wireless Gear Earbuds nestled in their charging case, ready for use or charging.

- **Earbuds:** Left (L) and Right (R) earbuds with built-in microphones and touch controls.
 - **Charging Case:** Portable case that charges the earbuds and protects them when not in use. Features LED indicators for charging status.
 - **Touch Control Area:** Located on the side of each earbud for managing playback, calls, and voice assistant.
 - **Charging Port:** On the charging case for connecting the USB charging cable.
-



Image: Demonstrating the convenient touch control feature on the earbud.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case. Ensure they are seated correctly.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The LED indicators on the case will show charging status. Once fully charged, the indicators may turn off or change color.
4. A full charge provides up to 10 hours of playtime for the earbuds, and the case can provide 4 to 5 additional charges, totaling up to 50 hours of playback.



INCLUDED CHARGING CASE

with 4-5
recharges per
full case

Image: The charging case provides multiple recharges for extended listening.

up to
8

HOURS

of use after
a single
charge for
extended
battery life



Extreme
BASS
SOUND

for optimal
sound acoustics
and noise
reduction

Image: Visual representation of the earbuds' battery life and sound capabilities.

2. Pairing with a Bluetooth Device

The earbuds feature auto-pair and auto-power on functionality for seamless connection.

1. **Power On:** Open the charging case or take the earbuds out of the case. They will automatically power on and enter pairing mode. You may hear an audible prompt.
2. **Activate Bluetooth:** On your smartphone, tablet, or laptop, enable Bluetooth.
3. **Select Device:** In the Bluetooth settings, search for "Wireless Gear Earbuds" (or similar name) in the list of available devices and select it to connect.
4. **Confirmation:** Once successfully paired, you will hear a confirmation sound, and the earbuds' indicator lights may change.
5. **Automatic Reconnection:** After initial pairing, the earbuds will automatically connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

The Wireless Gear Earbuds feature convenient touch controls for easy management of your audio and calls.

Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.

Voice Assistant (Siri/Google Assistant)

- **Activate Voice Assistant:** Triple tap on either earbud.

Power On/Off

- **Power On:** Earbuds automatically power on when removed from the charging case.
- **Power Off:** Earbuds automatically power off when placed back into the charging case.

MAINTENANCE

Proper care will extend the life of your earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Water:** The earbuds are not waterproof. Avoid exposure to water, sweat, or excessive moisture.
- **Charging:** Charge the device regularly, even if not in frequent use, to maintain battery health.

TROUBLESHOOTING

If you encounter issues, try the following solutions:

Problem	Solution
Earbuds not pairing/connecting.	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Wireless Gear Earbuds" from your device's Bluetooth list and re-pair. Place earbuds back in the case, close, wait a few seconds, then open and try again.
Only one earbud working.	Ensure both earbuds are charged. Place both earbuds back into the charging case, close the lid, and then take them out together. Try re-pairing the earbuds with your device.

Problem	Solution
Earbuds not charging.	<p>Ensure the charging cable is securely connected to both the case and the power source.</p> <p>Check if the charging port on the case is clean and free of debris.</p> <p>Try a different USB cable or power adapter.</p>
Poor sound quality.	<p>Ensure earbuds are clean and free of earwax buildup.</p> <p>Move closer to your Bluetooth device to avoid interference.</p> <p>Check the audio source (e.g., music file quality).</p>

SPECIFICATIONS

Detailed technical specifications for your Wireless Gear Earbuds:

Feature	Detail
Model Number	G0678
Bluetooth Version	5.0
Connectivity Technology	Bluetooth
Earbud Playtime	Up to 10 hours
Total Playtime (with case)	Up to 50 hours (4-5 additional charges)
Control Type	Touch Control
Microphone	Built-In
Form Factor	In Ear
Material	Plastic
Charging Case Dimensions	Approx. 2" x 3" x 0.5"
Manufacturer	ESI Wireless Accessories
Battery Type	Lithium Ion (included)




Image: Dimensions of the earbuds and charging case for reference.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Wireless Gear website. Keep your proof of purchase for warranty claims.

Manufacturer: ESI Wireless Accessories

Related Documents - G0678

	<p>Wireless Gear True Wireless Stereo Earbuds User Manual User manual for Wireless Gear True Wireless Stereo Earbuds, covering Bluetooth pairing, charging, device safety, battery information, FCC compliance, and limited warranty.</p>
	<p>Wireless Gear True Wireless Stereo Earbuds User Manual User manual for Wireless Gear True Wireless Stereo Earbuds, covering Bluetooth pairing, automatic pairing, charging instructions, device safety, battery information, technical support, FCC information, and limited warranty.</p>
	<p>Wireless Gear True Wireless Mini Earbuds User Manual and Specifications Comprehensive user manual for Wireless Gear True Wireless Mini Earbuds (WG-BT-EB) including setup, pairing, operation, features, safety, FCC information, and warranty details.</p>
	<p>Wireless Gear Wireless Charger BL2185-BL2189 User Manual User manual for the Wireless Gear Wireless Charger, models BL2185 and BL2189. Includes instructions, FCC information, and limited warranty details.</p>
	<p>QCY-T17 True Wireless Earbuds User Manual Comprehensive user manual for QCY-T17 True Wireless Earbuds, covering overview, wearing instructions, pairing, button controls, LED guide, charging, powering on/off, factory resetting, and customer service.</p>
	<p>Q78 True Wireless Stereo Earphones User Guide Comprehensive user guide for Q78 True Wireless Stereo Earphones, covering product specifications, pairing instructions, call and music controls, charging procedures, maintenance tips, and frequently asked questions for optimal use.</p>