

[Manuals.plus](#) /

› [L.O.L. Surprise!](#) /

› L.O.L. Surprise! OMG Sweets Fashion Doll Instruction Manual

L.O.L. Surprise! 572763EUC

L.O.L. Surprise! OMG Sweets Fashion Doll Instruction Manual

Model: 572763EUC

INTRODUCTION

Welcome to the world of L.O.L. Surprise! This manual provides comprehensive instructions for your new OMG Sweets Fashion Doll. Designed for children aged 4 and up, this doll set includes 20 surprises to enhance play and customization. Sweets features stunning details, beautiful hair, and a unique style, making her a standout addition to any collection. She is also the big sister to the fan-favorite L.O.L. Surprise! character, Sugar.

The L.O.L. Surprise! OMG Series 4 dolls are themed around opposites. Each doll's package includes a removable piece that forms half of a heart. Collect both Sweets and Spicy Babe to complete the heart. The packaging itself transforms into a reusable play space, allowing for imaginative scenarios and display.



L.O.L. Surprise! OMG Sweets Fashion Doll, approximately 10 inches (25cm) tall.

WHAT'S INCLUDED

Your L.O.L. Surprise! OMG Sweets Fashion Doll set comes with 20 surprises, carefully packaged for an exciting unboxing experience. The contents typically include:

- One L.O.L. Surprise! OMG Sweets Fashion Doll
- Complete fashion outfit
- Pair of shoes

- Various accessories
- Hat box
- Hair brush
- Garment bag
- Sticker sheet
- Hanger
- Doll stand
- Reusable package play space

SETUP AND ASSEMBLY

The L.O.L. Surprise! OMG Sweets Fashion Doll requires minimal assembly, primarily involving dressing and posing. Follow these steps to prepare your doll for play:

1. **Unboxing:** Carefully unbox your doll and all 20 surprises. The packaging is designed to be a reusable play space; retain it for future use.
2. **Dressing the Doll:** The doll's hands are removable to facilitate easy dressing. Gently pull the hands off before putting on the outfit, then reattach them. Dress Sweets in her fierce fashions and fabulous accessories.
3. **Posing:** Sweets is articulated, allowing for a wide range of poses. Adjust her limbs at the joints to create dynamic and expressive stances. Use the included doll stand to help her maintain poses and for display.
4. **Accessories:** Open the hat box to find additional accessories. Place them on the doll as desired to complete her look.



Close-up of Sweets, showcasing her detailed features and accessories.

PLAYING WITH YOUR DOLL

The L.O.L. Surprise! OMG Sweets Fashion Doll is designed for imaginative play and display. Here are some tips for maximizing your play experience:

- **Fashion Play:** Mix and match Sweets' outfit and accessories with other L.O.L. Surprise! OMG dolls to create unique styles.
- **Storytelling:** Use the doll and her accessories to create various stories and scenarios. The reusable package play space can serve as a backdrop for these adventures.
- **Posing and Display:** Utilize the doll's articulation and the included doll stand to pose Sweets in different ways for display in your collection.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your L.O.L. Surprise! OMG Sweets Fashion Doll:

- **Cleaning:** Wipe the doll's body with a soft, damp cloth to remove dust or dirt. Avoid harsh chemicals or abrasive cleaners.
- **Hair Care:** Gently brush the doll's hair with the included hair brush or a soft doll brush. Avoid excessive pulling or tugging to prevent damage. If the hair becomes tangled, use a small amount of water and a gentle conditioner, then carefully comb through.
- **Storage:** Store the doll and its accessories in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or damage.
- **Clothing and Accessories:** Hand wash doll clothing with mild soap and cold water if necessary. Air dry completely.

TROUBLESHOOTING

While L.O.L. Surprise! dolls are designed for durability, occasional issues may arise. Here are some common concerns and solutions:

- **Loose or Detached Limbs:** The doll's limbs are articulated and designed to be removable for dressing. If a limb detaches during play, gently reattach it by aligning the joint and pushing firmly. If the joint appears damaged or does not reattach securely, proceed to the 'Contact Support' section.
- **Hair Tangling:** Refer to the 'Hair Care' section under 'Care and Maintenance' for instructions on detangling and maintaining the doll's hair.
- **Missing Accessories:** Carefully check all packaging materials and the play space for any small accessories that may have been overlooked during unboxing.

PRODUCT SPECIFICATIONS

Brand Name	L.O.L. Surprise!
Model Name	OMG Doll Series 4 Style 1
Model Number	572763EUC
Character	Sweets
Toy Figure Type	Doll
Manufacturer Minimum Age	48 Months
Material Type	Plastic
Item Weight	200 Grams
Item Dimensions (L x W x H)	10.15" x 2.95" x 12.25"
Number of Pieces	20
Color	Multicolor
Educational Objective	Developing fine motor skills and understanding of fashion trends

WARRANTY AND SUPPORT

For warranty information and customer support regarding your L.O.L. Surprise! OMG Sweets Fashion Doll, please refer to the documentation included with your purchase or visit the official MGA Entertainment website. You may also contact the retailer from whom the product was purchased for assistance with returns or replacements.

When contacting support, please have your model number (572763EUC) and proof of purchase readily available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question