

ALL FOR PAWS 5700

ALL FOR PAWS Lifestyle Automatic Pet Feeder Model 5700

User Manual

1. INTRODUCTION

Thank you for choosing the ALL FOR PAWS Lifestyle Automatic Pet Feeder Model 5700. This device is designed to provide scheduled meals for your pets, ensuring they receive appropriate portions at regular intervals. It features five separate compartments for food, suitable for both dry and wet food, and can also be used for dispensing medication. This manual provides essential information for safe operation, setup, programming, and maintenance of your pet feeder.

Important Safety Information:

- Read all instructions before using the appliance.
- Keep this manual for future reference.
- This appliance is for indoor use only.
- Do not immerse the main unit in water.
- Keep out of reach of children and pets when not in use or during cleaning.
- Use only the recommended battery type.
- Ensure the feeder is placed on a stable, level surface.

2. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- ALL FOR PAWS Lifestyle Automatic Pet Feeder Main Unit
- User Manual (this document)

3. PRODUCT FEATURES

- **5 Meal Compartments:** Allows for up to five scheduled meals.
- **Programmable Timer:** Set specific feeding times for each meal.

- **Durable Construction:** Made from high-quality Acrylonitrile Butadiene Styrene (ABS) material.
- **Battery Operated:** Provides flexibility in placement without needing a power outlet.
- **Versatile Use:** Suitable for dry kibble, wet food, or medication.
- **Easy to Clean:** Removable tray for convenient washing.



Image: Top-down view of the ALL FOR PAWS Lifestyle Automatic Pet Feeder, showing the five food compartments and digital display. One compartment is open, revealing pet food.

4. SETUP

4.1 Battery Installation

1. Turn the feeder upside down.
2. Locate the battery compartment cover.
3. Open the cover and insert the required batteries (typically 4x C-size, not included), ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

4.2 Initial Placement

Place the feeder on a flat, stable surface in an area easily accessible to your pet, away from direct sunlight or heat sources. Ensure there is enough space around the feeder for your pet to eat comfortably.



Image: A dog and a cat eating from the ALL FOR PAWS Lifestyle Automatic Pet Feeder, demonstrating its use in a typical home environment.

5. OPERATING INSTRUCTIONS

5.1 Setting the Current Time

1. Press the **Hr** button to set the current hour.
2. Press the **Min** button to set the current minute.
3. The display will show the current time.

5.2 Programming Meal Times

The feeder allows you to program up to 5 distinct meal times. Each time you set a meal, the feeder will rotate to the next available compartment.

1. Press the **H/S** button (Hour/Set) to enter programming mode for the first meal. The display will show '1' for meal 1.
2. Use the **Hr** and **Min** buttons to set the desired feeding time for meal 1.
3. Press **H/S** again to confirm meal 1 and move to meal 2. The display will show '2'.

4. Repeat steps 2 and 3 for meals 2 through 5.
5. After setting meal 5, press **H/S** one last time to exit programming mode. The feeder will return to displaying the current time.
6. To clear all programmed times, press and hold the **Rst** button for a few seconds until the display resets.

5.3 Filling the Food Compartments

1. Gently lift the lid of the feeder.
2. Fill each of the five compartments with the desired amount of dry kibble, wet food, or medication. Do not overfill.
3. Ensure the food does not obstruct the rotation mechanism.
4. Close the lid securely.

6. MAINTENANCE AND CLEANING

Regular cleaning is essential for hygiene and proper functioning of the feeder.

6.1 Cleaning the Feeder

1. Ensure the feeder is turned off and remove the batteries before cleaning.
2. Remove the top lid and the rotating food tray.
3. Wash the lid and food tray with warm, soapy water. Rinse thoroughly and dry completely before reassembling.
4. Wipe the main unit (the part containing the electronics) with a damp cloth. Do not immerse the main unit in water.
5. Ensure all parts are completely dry before reassembling and reinserting batteries.

6.2 Battery Replacement

When the display becomes dim or the feeder stops rotating correctly, it's time to replace the batteries. Follow the battery installation steps in Section 4.1. Always replace all batteries at the same time with new ones of the same type.

7. TROUBLESHOOTING

- **Feeder not turning on:** Check battery installation and ensure batteries are new and correctly oriented.
- **Feeder not dispensing food:**
 - Verify that meal times are correctly programmed.
 - Check if the food compartments are empty.
 - Ensure there are no obstructions preventing the tray from rotating.
 - Replace batteries if they are low.
- **Display is dim or blank:** Replace batteries.
- **Incorrect time displayed:** Reset and reprogram the current time (refer to Section 5.1).

8. SPECIFICATIONS

Model Number	5700
--------------	------

Dimensions	34 x 7.5 x 38 cm
Weight	762 g
Material	Acrylonitrile Butadiene Styrene (ABS)
Capacity	7.62 Kilograms (total food capacity)
Power Source	Batteries (not included)
Target Species	Dogs and Cats

9. WARRANTY AND SUPPORT

This product is covered by a limited warranty. For specific warranty details, please refer to the documentation provided at the time of purchase or contact ALL FOR PAWS customer support. If you encounter any issues or have questions not addressed in this manual, please contact ALL FOR PAWS customer service for assistance. Please have your product model number (5700) and purchase information ready when contacting support.