

Hoco E29

Hoco E29 Splendour Wireless Headset User Manual

Model: E29

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Hoco E29 Splendour Wireless Headset. Please read this manual thoroughly before operating the device and retain it for future reference.

2. PRODUCT OVERVIEW

The Hoco E29 Splendour Wireless Headset is a compact and lightweight audio device designed for wireless communication and music playback. It features a single earbud design with integrated controls.



Figure 1: Front view of the Hoco E29 Splendour Wireless Headset. This image displays the sleek, white design of the earbud with the 'hoco.' branding visible on its surface.



Figure 2: Rear view of the Hoco E29 Splendour Wireless Headset. This image shows the back of the earbud, including regulatory marks and the model number 'E29'.

Package Contents:

- Hoco E29 Splendour Wireless Headset
- Charging Cable (not explicitly mentioned but implied)
- User Manual (this document)

3. SETUP

3.1 Charging the Headset

1. Connect the charging cable to the headset's charging port.
2. Connect the other end of the charging cable to a DC5V power source (e.g., USB wall adapter, computer USB port).
3. The headset will indicate charging status (e.g., LED indicator).
4. A full charge takes approximately **2 hours**.
5. Once fully charged, disconnect the headset from the power source.

Note: The headset has a battery capacity of 50 mAh, providing approximately 3 hours of talk/music time and 90 hours of standby time.

3.2 Pairing with a Bluetooth Device

The Hoco E29 uses Wireless V4.2 technology for stable connection up to 10 meters.

1. Ensure the headset is fully charged.
2. **Power On:** Press and hold the multi-function button (assuming a single button for touch control) on the headset until the indicator light flashes (e.g., blue/red alternating), indicating pairing mode.
3. On your mobile device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices. The headset should appear as "Hoco E29" or similar.

5. Select "Hoco E29" from the list to initiate pairing.
6. Once paired, the indicator light on the headset will change (e.g., slow blue flash) and a voice prompt may confirm the connection.
7. The headset supports A2DP, AVRCP, Headset, and Hands-free protocols.

Note: For Apple phones and some Android phones, the battery level of the headset may be displayed on your device's screen.

4. OPERATING INSTRUCTIONS

The Hoco E29 headset features touch control for various functions.

4.1 Power On/Off

- **Power On:** Press and hold the touch control area for approximately 3 seconds until the indicator light illuminates.
- **Power Off:** Press and hold the touch control area for approximately 5 seconds until the indicator light turns off.

4.2 Call Management

- **Answer Call:** Briefly tap the touch control area once when an incoming call rings.
- **End Call:** Briefly tap the touch control area once during a call.
- **Reject Call:** Press and hold the touch control area for approximately 2 seconds when an incoming call rings.

4.3 Music Playback

- **Play/Pause:** Briefly tap the touch control area once to play or pause music.
- **Next Track:** Double-tap the touch control area (specific gesture may vary, refer to device for exact touch controls).
- **Previous Track:** Triple-tap the touch control area (specific gesture may vary, refer to device for exact touch controls).

Note: Specific touch gestures for track control and volume adjustment are not detailed in the product description. Users may need to experiment or refer to additional documentation for precise controls.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** Avoid exposing the headset to water or excessive moisture. It is not waterproof.
- **Charging:** Charge the headset regularly, even if not in use, to maintain battery health.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headset does not power on.	Low battery.	Charge the headset for at least 30 minutes.
Cannot pair with device.	Bluetooth is off on device; headset not in pairing mode; too far from device.	Ensure Bluetooth is enabled; put headset in pairing mode; keep devices within 1 meter during pairing.

Problem	Possible Cause	Solution
No sound during playback/calls.	Volume too low; headset not connected; incorrect audio output selected.	Increase volume on both headset and device; re-pair headset; check device's audio output settings.
Poor connection or audio quality.	Interference; too far from device; obstacles between devices.	Move closer to the paired device (within 10m); avoid environments with strong Wi-Fi or other Bluetooth signals.

7. SPECIFICATIONS

Feature	Detail
Model	E29
Brand	Hoco
Wireless Specification	Wireless V4.2 WT
Supported Protocols	Headset, Hands-free, A2DP, AVRCP
Transmission Range	Up to 10 meters
Transmission Frequency	2.4GHz
Charging Voltage	DC5V
Charging Time	Approximately 2 hours
Battery Capacity	50 mAh
Talk Time	Approximately 3 hours
Music Time	Approximately 3 hours
Standby Time	Approximately 90 hours
Product Net Weight	7 grams
Product Dimensions (L x W x H)	50 x 12 x 20 mm
Color	White
Noise Control	Active Noise Cancellation
Control Method	Touch
Compatible Devices	Cellphones


8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided at the point of purchase or contact your retailer. Hoco does not provide direct warranty or support details within this manual.

Related Documents - E29

	HOCO E36 Wireless Bluetooth Headset: User Manual and Features Comprehensive guide for the HOCO E36 wireless Bluetooth headset, covering product features, specifications, warnings, and step-by-step usage instructions. Includes Bluetooth V4.2, hands-free operation, and battery details.
	Hoco EW24 Wireless Headset User Manual and Specifications Comprehensive guide for the Hoco EW24 Wireless Headset, covering features, operation, controls, and product specifications. Includes safety warnings and warranty information.
	Hoco EW24 Wireless Earphones User Manual User manual for Hoco EW24 Wireless Earphones, providing setup, usage, and troubleshooting information.
	Hoco BS31 Portable Bluetooth Speaker User Manual and Specifications User manual and technical specifications for the Hoco BS31 portable Bluetooth speaker, including FCC compliance information, device features, and performance details.
	Hoco ES45 TWS Wireless Headset Instruction Manual Instruction manual for the Hoco ES45 TWS wireless headset, detailing features, usage, controls, and warnings.
	Hoco HE-068 TWS Wireless Headset User Manual User manual for the Hoco HE-068 TWS wireless headset, detailing product features, operation instructions, controls, and FCC compliance information.

Documents - Hoco – E29



[\[pdf\]](#) User Manual Specifications

RA4M2 Group User s Manual Hardware Renesas Electronics Corporation r01uh0892ej0130 ra4m2
 renesas en document man group users manual hardware |||

User s Manual RA4M2 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
 Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
 MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
 MSTP E24 -- -- -- -- -- Value after r...

lang:en score:17 filesize: 17.05 M page_count: 1689 document date: 2023-07-27

[\[pdf\]](#) User Manual Specifications

RA4M3 Group User s Manual Hardware Renesas Electronics Corporation r01uh0893ej0140 ra4m3
renesas en document man group users manual hardware |||

User s Manual RA4M3 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 -- -- -- -- -- -- -- -- Value after r...

lang:en **score:17** filesize: 17.48 M page_count: 1719 document date: 2023-07-27

[\[pdf\]](#) User Manual Specifications

RA4M3 Group User s Manual Hardware Renesas Electronics Corporation r01uh0893ej0130 ra4m3
renesas us en document man group users manual hardware ||| ||| User s Manual RA4M3 Group 32 User s
Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Renesas RA4 Series All information
contained in these materials, including products and p

User s Manual RA4M3 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 -- -- -- -- -- -- -- -- Value after r...

lang:en **score:16** filesize: 17.43 M page_count: 1714 document date: 2022-12-07

[\[pdf\]](#) User Manual Specifications Datasheet

RA4E1 Group User s Manual Hardware Renesas Electronics Corporation 23 feb 2022 — When using
products refer to the latest product information data sheets user manuals application notes General Notes
for r01uh0929ej0110 ra4e1 renesas document mah group users manual hardware language en |||

User s Manual RA4E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16
Bit field: -- MSTP MSTP E30 **E29** -- MSTP MSTP E27 E26 -- -- -- -- -- -- -- -- Value
after reset: 1 1 1 1 1...

lang:en **score:16** filesize: 14.79 M page_count: 1446 document date: 2022-02-04


[pdf] User Manual Specifications


RA8E1 Group User s Manual Hardware High performance 360 MHz Arm Cortex M85 core with HeliumTM
1 MB code flash memory Dual bank background and SWAP operation 12 KB Data 544 SRAM Parity
integration Ethernet MAC controller USB 2 Full Speed CANFD Octal SPI advanced analog Renesas
Electronics Corporation v1mouser cl Docs r01uh1129ej0100 ra8e1 v1v1mouser ra8e1mouser do
v1v1v1mouser hn v1v1v1v1mouser ra8e1gr mouser v1v1v1v1v1mouser co za v1v1v1v1v1v1mouser
ra8e1uy ||| ||| User s Manual RA8E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced
RA Family Renesas RA8 Series All information contained in these materials, including products and
product specifications, represents information on the product ||| User s Manual RA8E1 Group 32 User s
Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Renesas RA8 Series All information
contained in these materials, including products and product specifications, represents information on the
product ||| User s Manual RA8E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA
Family Renesas RA8 Series All information contained in these materials, including products and product
specifications, represents information on the product ||| User s Manual RA8E1 Group 32 User s Manual:
Hardware 32-Bit MCU Renesas Advanced RA Family Renesas RA8 Series All information contained in
these materials, including products and product specifications, represents information on the product |||
User s Manual RA8E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family
Renesas RA8 Series All information contained in these materials, including products and product
specifications, represents information on the product

User s Manual RA8E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit
field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 -- -- -- --
MSTP MSTP MSTP MSTP E21 E20 E19 E18 -- -- Valu...
lang:en score:16 filesize: 21.03 M page_count: 2095 document date: 2024-10-21

[pdf] User Manual Specifications

RA6E1 Group User s Manual Hardware Renesas Electronics Corporation r01uh0930ej0110 ra6e1
renesas us en document mah group users manual hardware language ||| ||| User s Manual RA6E1 Group
32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Renesas RA6 Series All
information contained in these materials, including products and p
User s Manual RA6E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16
Bit field: -- MSTP MSTP E30 **E29** -- MSTP MSTP MSTP MSTP E27 E26 E25 E24 -- --
-- -- -- -- -- Value after reset: 1 ...
lang:en score:16 filesize: 17.19 M page_count: 1701 document date: 2022-02-03






[\[pdf\]](#) User Manual Specifications

RA4E1 Group User s Manual Hardware Renesas Electronics Corporation r01uh0929ej0110 ra4e1
renesas eu en document mah group users manual hardware br jp kr sg |||

User s Manual RA4E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16
Bit field: -- MSTP MSTP E30 **E29** -- MSTP MSTP E27 E26 - - - - - Value
after reset: 1 1 1 1 1...

lang:en **score:16** filesize: 14.79 M page_count: 1446 document date: 2022-08-05



[\[pdf\]](#) User Manual Specifications

RA6M4 Group User s Manual Hardware REN r01uh0890ej0110 ra6m4 MAH 20200929 renesas us en
document man group user manual hardware language |||

User s Manual RA6M4 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 - - - - - V...


lang:en **score:16** filesize: 16.26 M page_count: 1896 document date: 2022-08-05

[\[pdf\]](#) User Manual Specifications

RA6M4 Group User s Manual Hardware Renesas Electronics Corporation r01uh0890ej0120 ra6m4
renesas jp ja document man group user manual hardware language en ||| ||| User s Manual RA6M4
Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Renesas RA6 Series All
information contained in these materials, including products and product specifications, represents
information on the product

User s Manual RA6M4 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 - - - - - V...

lang:en **score:16** filesize: 19.19 M page_count: 1901 document date: 2022-12-07



[pdf] User Manual Specifications

RA6E1 Group User s Manual Hardware Renesas Electronics Corporation r01uh0930ej0100 ra6e1
renesas us ja document mah group users manual hardware language en |||

User s Manual RA6E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16
Bit field: -- MSTP MSTP E30 **E29** -- MSTP MSTP MSTP MSTP E27 E26 E25 E24 -- --
-- -- -- -- -- Value after reset: 1 ...


lang:en score:16 filesize: 16.84 M page_count: 1711 document date: 2021-09-23

[pdf] User Manual Specifications

RA6M5 Group User s Manual Hardware Renesas Electronics Corporation r01uh0891ej0130 ra6m5
renesas en document man group users manual hardware |||

User s Manual RA6M5 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en score:16 filesize: 22.32 M page_count: 2276 document date: 2023-07-27




[pdf] User Manual Specifications

RA4M2 Group User s Manual Hardware Renesas Electronics Corporation REN r01uh0892ej0110 ra4m2
MAT 20210120 renesas us en document man group users manual hardware |||

User s Manual RA4M2 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 -- -- -- -- -- -- -- Value after r...

lang:en score:16 filesize: 14.85 M page_count: 1688 document date: 2022-08-05




[pdf] User Manual

RA4E1 Renesas Electronics Corporation r01uh0929jj0110 ra4e1 renesas us en document
mah group users manual hardware language ja |||


User s Manual RA4E1 32 32 MCU Renesas RA Renesas RA4 www.renesas.com
Rev.1.10 Feb 2 ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: --
MSTP MSTP E30 **E29** -- MSTP MSTP E27 E26 -- -- -- -- -- -- -- Value after reset:
1 1 1 1 1...

lang:en score:16 filesize: 16.09 M page_count: 1461 document date: 2022-02-04




[\[pdf\]](#) User Manual Specifications

RA6M5 Group User s Manual Hardware Renesas Electronics Corporation r01uh0891ej0120 ra6m5
renesas us en document man group users manual hardware ||| ||| User s Manual RA6M5 Group 32 User s
Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Renesas RA6 Series All information
contained in these materials, including products and p
User s Manual RA6M5 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...
lang:en score:16 filesize: 22.25 M page_count: 2270 document date: 2022-12-07




[\[pdf\]](#) User Manual Specifications

RA4M2 Group User s Manual Hardware Renesas Electronics Corporation REN r01uh0892ej0110 ra4m2
MAT 20210120 renesas us en document man group users manual hardware language |||
User s Manual RA4M2 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 -- -- -- -- -- -- -- Value after r...
lang:en score:16 filesize: 14.85 M page_count: 1688 document date: 2021-06-25




[\[pdf\]](#) User Manual Specifications

RA4E1 Group User s Manual Hardware Renesas Electronics Corporation 32 Bit MCU Advanced RA
Family RA4 Series r01uh0929ej0100 ra4e1 renesas us en document mah group users manual hardware
User s Manual RA4E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16
Bit field: -- MSTP MSTP E30 **E29** -- MSTP MSTP E27 E26 -- -- -- -- -- -- -- Value
after reset: 1 1 1 1 1...
lang:en score:16 filesize: 14.8 M page_count: 1451 document date: 2021-09-14




[pdf] User Manual Specifications

RA8E2 Group User s Manual Hardware High performance 480 MHz Arm Cortex M85 core with HeliumTM 1 MB code flash memory Dual bank background and SWAP operation 12 KB Data 672 SRAM or without Parity USB 2 0 Full Speed CANFD Octal SPI Graphics LCD Controller 2D Drawing Engine advanced analog Renesas Electronics Corporation r01uh1130ej0100 ra8e2 renesas en document mah group users manual hardware r 25566642 ||| ||| User s Manual RA8E2 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Renesas RA8 Series All information contained in these materials, including products and product specifications, represents information on the product User s Manual RA8E2 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 -- -- -- -- -- MSTP MSTP MSTP MSTP E21 E20 E19 E18 -- -- Valu... lang:en score:15 filesize: 22.48 M page_count: 2219 document date: 2024-10-21




[pdf] User Manual

RA6M4 Renesas Electronics Corporation r01uh0890jj0120 ra6m4 renesas jp ja document man group user s manual hardware ||| User s Manual RA6M4 32 32 MCU Renesas RA RA6 www.renesas.com Rev.1.20 Dec 2022 ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V... lang:en score:15 filesize: 20.58 M page_count: 1914 document date: 2022-12-07



[pdf] User Manual

RA6E1 Renesas Electronics Corporation r01uh0930jj0110 ra6e1 renesas us en document mah group users manual hardware language ja ||| User s Manual RA6E1 32 32 MCU Renesas RA Renesas RA6 www.renesas.com Rev.1.10 Feb 2 ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: -- MSTP MSTP E30 **E29** -- MSTP MSTP MSTP MSTP E27 E26 E25 E24 -- -- -- -- -- - Value after reset: 1 ... lang:en score:15 filesize: 18.59 M page_count: 1719 document date: 2022-02-04




[pdf] User Manual Specifications

RA6M5 Group User s Manual Hardware Renesas Electronics Corporation REN r01uh0891ej0110 ra6m5
MAT 20210331 renesas us en document man group users manual hardware language |||

User s Manual RA6M5 Group 32 User s Manual: Hardware 32-bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en score:15 filesize: 18.35 M page_count: 2273 document date: 2022-03-28




[pdf] User Manual

RA4M2 Renesas Electronics Corporation REN r01uh0892jj0110 ra4m2 MAH 20210120
renesas us en document man group users manual hardware language ja |||

User s Manual RA4M2 32 32 MCU Renesas RA RA4 www.renesas.com Rev.1.10 Jan
2021 ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP
E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 -- -- -- -- --
-- Value after r...

lang:en score:15 filesize: 16.18 M page_count: 1706 document date: 2021-06-25



[pdf] User Manual Specifications

RA8M1 Group User s Manual Hardware Renesas Electronics Corporation r01uh0994ej0110 ra8m1 ar
mouser Docs |||

User s Manual RA8M1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 MSTP E21 MSTP E20 MSTP ...

lang:en score:15 filesize: 28.21 M page_count: 2715 document date: 2023-10-18

[\[pdf\]](#) User Manual Specifications

RA4L1 Group User's Manual Hardware The group features low power 32 bit microcontrollers MCUs based on the Arm Cortex M33 CM33 core with TrustZone® delivering an ideal balance of voltage operation consumption and high performance offers down to 1.6V combined a standby current as little as 65µA multitude enabling user dynamically optimize their application requirements BGA WLCSP are under development Renesas Electronics Corporation v1mouser cl Docs r01uh1081ej0110 ra4l1 v1v1mouser ra4l1mouser sg v1v1v1mouser ra4l1eu mouser v1v1v1v1mouser ec v1v1v1v1v1mouser jp v1v1v1v1v1v1mouser ra4l1nl „Mouser Lietuva Descriptions circuits software other related information in this document provided only illustrate of v1v1v1v1v1v1v1mouser lt srsltid

AfmBOopsXgojg27dJ5vi554VZJXQ2zN2TDMAMdUnHeOpiduFit Aynilmouser ||| ||| User s Manual RA4L1

Group 32 User's Manual: Hardware 32-Bit MCU Renesas Advanced RA Family RA4 Series All

information contained in these materials, including products and product specifications, represents

information on the product at the ||| User s Manual RA4L1 Group 32 User s Manual: Hardware 32-Bit

MCU Renesas Advanced RA Family RA4 Series All information contained in these materials, including

products and product specifications, represents information on the product at the ||| User s Manual RA4L1

Group 32 User's Manual: Hardware 32-Bit MCU Renesas Advanced RA Family RA4 Series All

information contained in these materials, including products and product specifications, represents

information on the product at the ||| User s Manual RA4L1 Group 32 User s Manual: Hardware 32-Bit

MCU Renesas Advanced RA Family RA4 Series All information contained in these materials, including

products and product specifications, represents information on the product at the ||| User s Manual RA4L1

Group 32 User's Manual: Hardware 32-Bit MCU Renesas Advanced RA Family RA4 Series All

information contained in these materials, including products and product specifications, represents

information on the product at the ||| User s Manual RA4L1 Group 32 User s Manual: Hardware 32-Bit

MCU Renesas Advanced RA Family RA4 Series All information contained in these materials, including

products and product specifications, represents information on the product at the



User's Manual RA4L1 Group 32 User's Manual: Hardware 32-Bit MCU Renesas

Advanced RA Family RA4 ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:

MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 -- -- -- -- -- -- -- --

```
-- Value after reset: 1 1 ...
```

lang:en score:15 filesize: 21.89 M page count: 2086 document date: 2025-02-05



[\[pdf\]](#) User Manual

RA4M3 Renesas Electronics Corporation REN r01uh0893jj0120 ra4m3 MAH 20201202

renesas us en document man group users manual hardware language ja ||


User's Manual RA4M3 32-bit MCU Renesas RA4 www.renesas.com Rev.1.20

Dec 2020 1.... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31

MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 -- -- --

```
-- -- -- -- -- Value after r...
```

lang:en score:15 filesize: 16.35 M page count: 1730 document date: 2021-06-25




[\[pdf\]](#) User Manual

RA6M5 Renesas Electronics Corporation r01uh0891jj0130 ra6m5 renesas.jp ja document man group users manual hardware r 1493931 |||

User s Manual RA6M5 32 32 MCU Renesas RA RA6 www.renesas.com Rev.1.30 Jul 2023 ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en score:15 filesize: 23.87 M page_count: 2296 document date: 2023-07-25




[\[pdf\]](#) User Manual

RA6M4 Renesas Eletctronics Corporation REN r01uh0890jj0110 ra6m4 MAH 20201006 renesas.us en document man group user s manual hardware language ja |||

User s Manual RA6M4 32 32 MCU Renesas RA RA6 www.renesas.com Rev.1.10 Oct 2020 1. ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en score:15 filesize: 17.04 M page_count: 1909 document date: 2021-06-24




[\[pdf\]](#) User Manual Specifications

RA8D1 Group User s Manual Hardware Renesas Electronics Corporation r01uh0995ej0110 ra8d1 au mouser Docs |||

User s Manual RA8D1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 MSTP E23 MSTP E22 MSTP E21 MSTP E20 MSTP ...

lang:en score:15 filesize: 30.99 M page_count: 2995 document date: 2023-11-29




[\[pdf\]](#) User Manual Specifications

RA4T1 Group User s Manual Hardware Renesas Electronics Corporation RA4T1Usersmanual mouser sg Docs |||

User s Manual RA4T1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 - - - - - Value after reset: 1 1 ...

lang:en **score:15** filesize: 20.32 M page_count: 1639 document date: 2023-05-12



[\[pdf\]](#) User Manual

RA6M5 Renesas Electronics Corporation REN r01uh0891jj0110 RA6M5 MAH 20210331 renesas us en document man ra6m5 group users manual hardware language ja |||

User s Manual RA6M5 32 32 MCU Renesas RA RA6 www.renesas.com Rev.1.10 Mar 2021 ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 MSTP E23 MSTP E22 - - - - - V...

lang:en **score:14** filesize: 20.5 M page_count: 2296 document date: 2021-06-24




[pdf] User Manual Specifications

RA8E1 Group User s Manual Hardware High performance 360 MHz Arm Cortex M85 core with HeliumTM 1 MB code flash memory Dual bank background and SWAP operation 12 KB Data 544 SRAM Parity integration Ethernet MAC controller USB 2 0 Full Speed CANFD Octal SPI advanced analog Renesas Electronics Corporation r01uh1129ej0100 ra8e1 renesas en document mah group users manual hardware r 25566640 |||

User s Manual RA8E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 -- -- -- -- MSTP MSTP MSTP MSTP E21 E20 E19 E18 -- -- Valu...

lang:en score:14 filesize: 21.03 M page_count: 2095 document date: 2024-10-21




[pdf] User Manual Specifications

RA6M5 Group User s Manual Hardware Renesas Electronics Corporation MCU UM mouser mx Docs |||

User s Manual RA6M5 Group 32 User s Manual: Hardware 32-bit MCU Renesas Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en score:14 filesize: 22.29 M page_count: 2273 document date: 2021-03-24




[\[pdf\]](#) User Manual Specifications

RA4M3 Group User s Manual Hardware Renesas Electronics Corporation 32 Bit Microcontroller Mouser
MCU UM mouser co cr Docs |||

User s Manual RA4M3 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 -- -- -- -- -- Value after r...

lang:en **score:14** filesize: 14.83 M page_count: 1710 document date: 2020-12-02




[\[pdf\]](#) User Manual Specifications

RA6E1 Group User s Manual Hardware High performance 200 MHz Arm Cortex M33 core up to 1 MB
code flash memory with Dual bank background and SWAP operation 8 KB Data 256 SRAM Parity
integration Ethernet MAC controller USB 2 0 Full Speed SDHI Quad SPI advanced analog Renesas
Electronics Corporation r01uh0930ej0120 ra6e1 renesas en document mah group users manual
hardware |||

User s Manual RA6E1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... ition: 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16
Bit field: -- MSTP MSTP E30 **E29** -- MSTP MSTP MSTP MSTP E27 E26 E25 E24 -- --
-- -- -- -- -- Value after reset: 1 ...

lang:en **score:13** filesize: 17.23 M page_count: 1707 document date: 2024-10-11




[\[pdf\]](#) User Manual Specifications Datasheet

RA6M5 Group User s Manual Hardware Renesas Electronics Corporation renesas EK UsersManual
marutsu co jp contents shop datasheet |||

User s Manual RA6M5 Group 32 User s Manual: Hardware 32-bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en **score:13** filesize: 18.34 M page_count: 2273 document date: 2021-03-16




[pdf] User Manual Specifications

RA6M5 Group User s Manual Hardware Renesas Electronics Corporation 32 Bit Microcontroller Mouser
MCU UM ar mouser Docs |||

User s Manual RA6M5 Group 32 User s Manual: Hardware 32-bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en score:13 filesize: 18.35 M page_count: 2273 document date: 2021-03-24




[pdf] User Manual Specifications

RA6M5 Group User s Manual Hardware Renesas Electronics Corporation HAL Abstraction Layer
Electronic Component and Engineering Solution Forum TechForum | DigiKey b4hq409b

internal false reflectio renesas us en document man ra6m5 group users manual hardware r 1493931
reflection clicks 0 url digikey kr ko products detail electronics corporation R7FA6M5BH2CBG AC0
15195226 short |||

User s Manual RA6M5 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 -- -- -- -- -- V...

lang:en score:12 filesize: 22.32 M page_count: 2276 document date: 2023-07-27



[pdf] User Manual Specifications

RA4M2 Group User s Manual Hardware Renesas Electronics Corporation group RA4 Series Avnet
usermanual ra4m2 MOD AJPERES CVID oA2HFIK avnet wps wcm connect onesite 732b08d1 ba14 4180
8db4 ded1ed920613 |||

User s Manual RA4M2 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 -- -- -- -- -- Value after r...

lang:en score:12 filesize: 17.02 M page_count: 1687 document date: 2023-05-30



[pdf] User Manual Specifications

RA4T1 Group User s Manual Hardware Renesas Electronics Corporation group RA4 Series Avnet
usermanual ra4t1 MOD AJPERES CVID oA2HSPA avnet wps wcm connect onesite e16f1ef4 6200 4b51
8a35 c3a307946e3e |||

User s Manual RA4T1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit
field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 - - - - -
- - - - - Value after reset: 1 1 ...

lang:en score:12 filesize: 17.56 M page_count: 1639 document date: 2023-05-12



[pdf] User Manual Specifications

RA6T3 Group User s Manual Hardware Renesas Electronics Corporation group RA6 Series Avnet
usermanual ra6t3 MOD AJPERES CVID oA3nM7r avnet wps wcm connect onesite a3773d39 4406 40d8
a232 c03ddd2a60f3 |||

User s Manual RA6T3 Group 32 User s Manual: Hardware 32-Bit MCU Renesas
Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit
field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 - - - - -
- - - - - Value after reset: 1 1 ...

lang:en score:12 filesize: 18.15 M page_count: 1709 document date: 2023-05-12



[pdf] User Manual

RA8E1 360 MHz Arm Cortex M85 HeliumTM SWAP 1 MB 12
KB 544 KB SRAM MAC USB 2.0 CANFD Octal SPI Renesas

Electronics Corporation REN r01uh1129jj0100 ra8e1 MAH 20241023 renesas ja document mah group
users manual hardware r 25566640 |||


User s Manual RA8E1 32 32 MCU Renesas Advanced RA Renesas RA8
www.renesas.com Rev ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 - - - - - MSTP
MSTP MSTP MSTP E21 E20 E19 E18 - - - Valu...

lang:en score:12 filesize: 22.45 M page_count: 2115 document date: 2024-10-23




[pdf] User Manual Specifications

RA8D1 Group User s Manual Hardware High performance 480 MHz Arm Cortex M85 core with Helium™ up to 2 MB code flash memory Dual bank background and SWAP operation 12 KB Data 1 SRAM Parity ECC integration Ethernet MAC controller USB 0 Speed CANFD SDHI I3C Octal SPI Decryption on the fly Graphics LCD Controller 2D Drawing Engine MIPI DSI advanced analog Integrated Renesas Secure IP cryptography accelerators key management support tamper detection power analysis resist Electronics Corporation r01uh0995ej0120 ra8d1 renesas en document mah group users manual hardware ||| User s Manual RA8D1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Ren ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25 MSTP E24 MSTP E23 MSTP E22 MSTP E21 MSTP E20 MSTP ... lang:en score:12 filesize: 31.17 M page_count: 3004 document date: 2024-11-20



[pdf] User Manual Specifications

RA6E2 Group User s Manual Hardware Renesas Electronics Corporation group RA6 Series Avnet usermanual ra6e2 MOD AJPERES CVID oA3kDGm avnet wps wcm connect onesite f1d1df74 4626 410a a651 5538bac1dd81 ||| User s Manual RA6E2 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 - - - - - - - - - - - - - - - - Value after reset: 1 1 ... lang:en score:12 filesize: 19.27 M page_count: 1887 document date: 2023-02-27



[pdf] Declaration of Conformity

Hoco Technology development Shenzhen Co LTD PhoneiStore Brand Equipment Wireless headsets Model No E1 E5 E14 E15 E21 E29 E33 E36 E49 E57 E63 E64 mini E69 E70 to which this declaration HOCO BUSINESS BG EN phoneistore files actual images ||| ... lang:en score:11 filesize: 488.67 K page_count: 2 document date: 2024-01-24



[pdf] User Manual

RA8T1 480 MHz Arm Cortex M85 HeliumTM SWAP 2 MB
12 KB ECC 1 MB SRAM MAC USB 2.0 CANFD SDHI I3C Arm
TrustZone Renesas IP Renesas Electronics Corporation

r01uh1016jj0120 ra8t1 renesas ja document mah group users manual hardware r 25463106 |||

User s Manual RA8T1 32 32 MCU Renesas Advanced RA Renesas RA8

www.renesas.com Rev ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:

MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25

MSTP E24 MSTP E23 MSTP E22 MSTP E21 MSTP E20 MSTP ...

lang:en score:11 filesize: 26.3 M page_count: 2349 document date: 2024-11-21



[pdf] User Manual Specifications

RA8T1 Group User s Manual Hardware High performance 480 MHz Arm Cortex M85 core with HeliumTM up to 2 MB code flash memory Dual bank background and SWAP operation 12 KB Data 1 SRAM Parity ECC integration Ethernet MAC controller USB 0 Full Speed CANFD SDHI I3C advanced analog Integrated Renesas Secure IP cryptography accelerators key management support tamper detection power analysis resistance in concert TrustZone for integrated secure element functionality Electronics Corporation r01uh1016ej0110 ra8t1 mouser Docs |||


User s Manual RA8T1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas

Advanced RA Family Rene ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit

field: MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25


MSTP E24 MSTP E23 MSTP E22 MSTP E21 MSTP E20 MSTP ...

lang:en score:10 filesize: 24.79 M page_count: 2319 document date: 2024-01-17



[pdf] User Manual

RA8M1 480 MHz Arm Cortex M85 HeliumTM SWAP 2 MB
12 KB ECC 1 MB SRAM MAC USB 2.0 CANFD SDHI I3C SPI
Arm TrustZone Renesas IP Renesas Electronics
Corporation r01uh0994jj0120 ra8m1 renesas ja document mah group users manual hardware r 25447396
|||
User s Manual RA8M1 32 32 MCU Renesas Advanced RA Renesas RA8
www.renesas.com Rev ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 MSTP E25
MSTP E24 MSTP E23 MSTP E22 MSTP E21 MSTP E20 MSTP ...
lang:en score:10 filesize: 30.19 M page_count: 2754 document date: 2024-11-21



[pdf] User Manual Specifications

RA4L1 Group User s Manual Hardware The group features low power 32 bit microcontrollers MCUs based on the Arm Cortex M33 CM33 core with TrustZone® delivering an ideal balance of voltage operation consumption and high performance offers down to 1.6V combined a standby current as little as 65µA multitude enabling user dynamically optimize their application requirements BGA WLCSP are under development Renesas Electronics Corporation Mouser Feb 20 2025 · Descriptions circuits software other related information in this document provided only illustrate of r01uh1081ej0110 ra4l1 srsItd
AfmBOoRD7vwyxN3 x3bkM04yOtxaGvNHlbyKmr6kUqr1 M2gimhSjX mouser Docs |||
User s Manual RA4L1 Group 32 User s Manual: Hardware 32-Bit MCU Renesas Advanced RA Family RA4 ... 1 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 Bit field:
MSTP E31 MSTP E30 MSTP **E29** MSTP E28 MSTP E27 MSTP E26 -- -- -- -- -- -- -- -- -- --
-- Value after reset: 1 1 ...
lang:en score:9 filesize: 21.89 M page_count: 2086 document date: 2025-02-05