

## EasyKeys 2380

# Master Lock 2380 Replacement Keys User Manual

Provided by EasyKeys

## 1. INTRODUCTION AND PRODUCT OVERVIEW

---

This manual provides essential information for the use and care of your Master Lock 2380 Replacement Keys, supplied by EasyKeys. These keys are specifically designed to replace lost or damaged keys for Master Lock 2380 series padlocks.

**Important Note:** To ensure compatibility, it is crucial to verify the lock code from your original key or the padlock's original packaging. The lock code is typically a four-digit number stamped on the key or printed on the packaging. The keys provided are cut to this specific code.



Figure 1: Example of a Master Lock replacement key. Note the stamped code (e.g., "2001") which is vital for ordering the correct key.

### What's Included:

- 2 x Master Lock 2380 Replacement Keys

- 1 x Eco Lips Peppermint Buzz Lip Balm (complimentary item)



Figure 2: Complimentary Eco Lips Peppermint Buzz Lip Balm.

## 2. SETUP AND KEY VERIFICATION

---

The primary "setup" for replacement keys involves ensuring you have the correct key for your specific Master Lock 2380 padlock. Follow these steps:

1. **Locate Your Lock Code:** Before attempting to use the new keys, confirm the lock code. This code is typically found on the original key (stamped into the metal), on the original packaging of the padlock, or sometimes on the padlock itself (though less common for the 2380 series). *Do not rely on a code found on a different padlock, even if it looks similar.*
2. **Compare Codes:** Verify that the code stamped on your new replacement keys matches the code you identified for your padlock. If the codes do not match, the key will not operate the lock.
3. **Inspect Keys:** Before insertion, visually inspect the new keys for any signs of damage, bending, or manufacturing defects. A damaged key can harm the lock mechanism.

## 3. OPERATING THE LOCK WITH YOUR NEW KEY

---

Once you have verified that you have the correct replacement key, operating your Master Lock 2380 padlock is straightforward:

1. **Insert the Key:** Gently insert the key fully into the keyway of the padlock. Do not force the key if it does not slide in smoothly.
2. **Turn the Key:** With the key fully inserted, turn it clockwise (typically) to unlock the padlock. You should feel a distinct click as the locking mechanism disengages.
3. **Remove the Key:** Once the padlock is unlocked, you can remove the key. To relock, close the shackle and turn the key counter-clockwise (or in the opposite direction of unlocking) to secure the mechanism, then remove the key.

*Note:* If the lock feels stiff, a small amount of graphite lubricant (specifically designed for locks) can be applied to the keyway, but avoid using oil-based lubricants as they can attract dirt.

## 4. MAINTENANCE AND CARE

---

Proper care of your replacement keys will ensure their longevity and reliable operation:

- **Keep Keys Clean:** Avoid exposing keys to excessive dirt, dust, or corrosive substances. If a key becomes dirty, wipe it clean with a dry cloth.

- **Avoid Bending:** Do not use excessive force when turning the key or attempt to bend it. Bent keys can damage the lock cylinder.
- **Proper Storage:** Store keys in a dry, safe place where they are not likely to be lost or damaged. Consider keeping a spare key in a secure, separate location.
- **Lubrication (for Lock):** While not directly for the key, periodically lubricating your padlock's mechanism with a specialized lock lubricant (e.g., graphite powder) can improve key operation and prevent sticking. Do not use WD-40 or similar multi-purpose oils.

## 5. TROUBLESHOOTING

---

If you encounter issues with your Master Lock 2380 replacement keys, consider the following troubleshooting steps:

Problem	Possible Cause	Solution
Key does not insert fully into the lock.	Incorrect key code; debris in keyway; bent key.	Verify lock code matches key code. Check keyway for obstructions and clear if necessary. Inspect key for damage.
Key inserts but does not turn.	Incorrect key code; lock mechanism is stiff or corroded.	Double-check key code. Apply lock lubricant to the keyway. If the lock is severely corroded, it may need replacement.
Key feels loose or wobbly when inserted.	Worn key or lock cylinder.	If the key is new, contact EasyKeys for a replacement. If the lock cylinder is worn, the padlock may need to be replaced.
Key breaks inside the lock.	Excessive force; worn key; faulty lock.	Do not attempt to extract the key yourself if it's deeply lodged, as this can cause further damage. Contact a professional locksmith.

## 6. SPECIFICATIONS

---

Key specifications for the Master Lock 2380 Replacement Keys:

<b>Brand:</b>	EasyKeys
<b>Manufacturer:</b>	Master Lock
<b>Model Number:</b>	2380
<b>Material Type:</b>	Brass
<b>Locking Mechanism:</b>	Key Lock
<b>Item Weight:</b>	Approximately 1 ounce (for the set of keys)
<b>Size:</b>	One Size (standard key dimensions for 2380 series)
<b>ASIN:</b>	B08FJHT46N
<b>Date First Available:</b>	August 10, 2020

## 7. WARRANTY AND SUPPORT

---

For any questions regarding your Master Lock 2380 Replacement Keys, including issues with fit or function, please contact the seller, EasyKeys, directly through the platform where the purchase was made. They can provide assistance with product-specific inquiries and potential replacements. Warranty information for replacement keys is typically provided by the seller at the time of purchase. Please refer to your purchase documentation or contact EasyKeys for details regarding their return and replacement policies.

For general information about Master Lock products, you may visit the official Master Lock website. However, for issues specific to these replacement keys, EasyKeys is your primary point of contact.