

[manuals.plus](#) /› [MEEDEN](#) /› [MEEDEN AFE-6038-SHT Large Beechwood H-Frame Easel Instruction Manual](#)

MEEDEN AFE-6038-SHT

MEEDEN AFE-6038-SHT Large Beechwood H-Frame Easel Instruction Manual

Model: AFE-6038-SHT

INTRODUCTION

Thank you for choosing the MEEDEN AFE-6038-SHT Large Beechwood H-Frame Easel. This manual provides essential information for the proper assembly, operation, and maintenance of your easel. Please read these instructions carefully before use to ensure safe and effective operation.

This easel is crafted from durable beechwood, designed for stability and longevity. It features adjustable height and angle settings, a convenient storage tray, and a foldable design for space-saving storage. It is suitable for various artistic endeavors, including sketching, oil painting, and studio work.

ASSEMBLY INSTRUCTIONS


Before beginning assembly, ensure all parts are present and undamaged. Each wooden piece and hardware component is labeled for easy identification. A detailed assembly manual and necessary tools are included with your easel.

1. Unpack all components and lay them out on a clean, flat surface.
2. Identify the main H-frame sections and connect them according to the numbered labels.
3. Attach the base supports, ensuring they are securely fastened for stability.
4. Install the canvas holder and the integrated storage tray.
5. Secure all adjustment knobs and screws, ensuring they are firm but not overtightened.
6. Once assembled, gently test the easel's stability before placing a canvas.



Figure 1: Front and side view of the assembled MEEDEN H-Frame Easel.

Foldable Easel



Can be quickly folded into a flat for transportation or fit in some narrow spaces

Figure 2: Illustration of the easel's foldable design for compact storage.

OPERATING YOUR EASEL

Height and Angle Adjustment

The easel's height can be adjusted from 135 cm to 231 cm, accommodating canvases up to 198 cm (78 inches) tall. The mast features a secure ratchet control for easy height adjustments. To adjust the height, loosen the appropriate knobs, slide the mast to the desired position, and then tighten the knobs firmly. The painting angle can also be adjusted by loosening and tightening the front screw mechanism.




Figure 3: Easel dimensions and adjustability range.

Using the Storage Tray

The easel includes a built-in storage tray, approximately 4.6 cm (1.8 inches) deep and 55 cm (22 inches) wide. This tray provides convenient access to your art supplies such as brushes, paints, and other tools, allowing you to focus on your artwork without interruption.

Stable Thicker Canvas

1.8" D x 22"W storage tray can stable thicker canvas



Figure 4: Detail of the integrated storage tray for art supplies.

Canvas Placement

Place your canvas securely on the canvas holder. The H-frame design provides excellent stability for various canvas sizes. Ensure the canvas is centered and stable before beginning your work.



Figure 5: Easel in use by an artist.

MAINTENANCE

To ensure the longevity and optimal performance of your MEEDEN easel, follow these maintenance guidelines:

- **Cleaning:** Wipe the beechwood frame with a soft, dry cloth to remove dust. For stubborn marks, use a slightly damp cloth and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Hardware:** Periodically check all screws and knobs to ensure they are tight. If any hardware becomes loose, gently tighten it. The easel features galvanized, anti-rust hardware for durability.
- **Storage:** When not in use, especially for extended periods, store the easel in a dry environment. Its foldable design allows for compact storage in narrow spaces.

Practical Finish



Certified Materials

FSC covered solid German beechwood made

Quality Hardware

Long-lasting/ galvanized/ anti-rust

Practical Finish

Walnut colored for better stain resistance and is more versatile.

Figure 6: Close-up of the easel's beechwood material and hardware.

TROUBLESHOOTING

If you encounter any issues with your easel, please refer to the following common solutions:

- **Easel feels unstable:** Ensure all assembly screws and knobs are securely tightened. Check that the easel is placed on a flat, even surface. The H-frame design is inherently stable, but loose connections can affect this.
- **Difficulty adjusting height/angle:** Loosen the adjustment knobs sufficiently before attempting to move the mast or change the angle. If movement is stiff, check for any obstructions or debris in the sliding mechanisms. Do not force adjustments.
- **Missing parts during assembly:** Double-check the packaging. If parts are genuinely missing, please contact customer support immediately.

Strong Stability

Thickened German beechwood
H-frame structure firm quad base



Figure 7: The stable H-frame structure of the easel.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	MEEDEN
Model Number	AFE-6038-SHT
Material	Beechwood
Color	Dark Red
Product Dimensions (D x W x H)	61 cm x 55 cm x 231 cm (max height)
Adjustable Height Range	135 cm to 231 cm
Max Canvas Height Supported	198 cm (78 inches)
Item Weight	11.65 kg




Package Weight	11.84 kg
Package Dimensions	127 cm x 20.3 cm x 15.2 cm
Batteries Required	No
ASIN	B08FM5P5SW


WARRANTY AND CUSTOMER SUPPORT

MEEDEN is committed to providing high-quality art products and ensuring ultimate customer satisfaction. If you encounter any issues or have questions regarding your easel, please do not hesitate to contact MEEDEN customer support. We are dedicated to assisting you and resolving any concerns you may have.

For support, please refer to the contact information provided on the product packaging or the official MEEDEN website. When contacting support, please have your model number (AFE-6038-SHT) and purchase details ready.

Related Documents - AFE-6038-SHT

	<p>MEEDEN W10B Art Easel Assembly Instructions and Warranty</p> <p>Detailed assembly instructions and limited lifetime warranty information for the MEEDEN W10B Art Easel. Includes a parts list, step-by-step assembly guide, and warranty terms for original purchasers.</p>
	<p>MEEDEN WJ-7 Art Easel Assembly Instructions</p> <p>Step-by-step guide for assembling the MEEDEN WJ-7 art easel, including parts, hardware, and detailed instructions for a secure and stable setup.</p>
	<p>MEEDEN W10B Art Easel Assembly Instructions and Warranty</p> <p>Detailed assembly instructions and limited lifetime warranty information for the MEEDEN W10B Art Easel. Includes a parts list, step-by-step assembly guide, and warranty terms for original purchasers.</p>
	<p>MEEDEN WJ-7 Art Easel Assembly Instructions</p> <p>Step-by-step guide for assembling the MEEDEN WJ-7 art easel, including parts, hardware, and detailed instructions for a secure and stable setup.</p>

 ELKO EP SHT-13 Multifunction Digital Time Switch with Wi-Fi Connection User Manual	<p><u>SHT-13 Multifunction Digital Time Switch with Wi-Fi Connection ELKO EP</u></p> <p>ELKO EP SHT-13 series multifunction digital time switch. Features Wi-Fi connectivity, web server access, astronomical programs, and universal voltage supply for versatile automation solutions.</p>
华为平板 M5 用户指南	<p><u>M5</u></p> <p>M5</p> 