

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Relaxdays](#) /

› [Relaxdays Open Clothes Rack Instruction Manual \(Model 10031534\)](#)

Relaxdays 10031534

Relaxdays Open Clothes Rack Instruction Manual

Model: 10031534

[Overview](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

[Support](#)

1. PRODUCT OVERVIEW

The Relaxdays Open Clothes Rack (Model 10031534) is designed to provide a versatile and space-saving storage solution for your clothing and accessories. This freestanding unit features two clothes rails and multiple shelves, making it suitable for bedrooms, hallways, or dressing rooms. Constructed from powder-coated steel, it offers a modern industrial design.

Key Features:

- **Storage:** Ample space for shoes, clothes, bags, and other accessories.
- **Capacity:** Equipped with two clothes rails and various shelves for organized storage.
- **Versatility:** Ideal as an additional storage unit in various living spaces.
- **Design:** Freestanding black powder-coated steel frame with a modern industrial aesthetic.
- **Portability:** Lightweight and easily adjustable for relocation.



Image 1.1: The Relaxdays Open Clothes Rack, fully assembled and in use, showcasing its storage capabilities in a contemporary room.

2. SETUP AND ASSEMBLY

This clothes rack requires assembly. Please ensure all components are present before beginning. Refer to the included assembly material and instructions for detailed steps. The following provides a general guide.

2.1. Unpacking and Component Check

Carefully unpack all parts and lay them out on a clean, flat surface. Verify that all components listed in the packaging are present and undamaged. The main components include vertical poles, wire shelves, and clothes rails.

2.2. Assembly Steps

- 1. Assemble Vertical Poles:** Connect the pole segments if necessary to form the full height vertical supports. Ensure they are securely joined.
- 2. Attach Shelf Clips:** For each shelf, attach the plastic clips to the vertical poles at the desired height. Ensure all clips for a single shelf are at the same level to ensure stability.

3. **Install Shelves:** Carefully slide the wire shelves over the vertical poles, resting them onto the attached clips. Press down firmly to secure the shelves in place.
4. **Install Clothes Rails:** Attach the clothes rails to the designated points on the vertical poles or shelves. Ensure they are firmly secured to support the weight of clothing.




Image 2.1: Detail of how a wire shelf connects to a vertical pole, typically using plastic clips.



Image 2.2: Detail showing the connection point for a clothes rail, indicating how it attaches to the main structure.

Once assembled, gently shake the rack to ensure all connections are secure and the unit is stable. Adjust any loose parts as needed.

3. OPERATING INSTRUCTIONS

The Relaxdays Open Clothes Rack is designed for straightforward use. Follow these guidelines for optimal performance and longevity.

3.1. Loading the Rack

- **Clothes Rails:** Hang garments such as shirts, jackets, dresses, and trousers on the clothes rails using hangers. Distribute weight evenly across the rails to prevent imbalance.
- **Shelves:** Utilize the various shelves for folded clothing, shoes, bags, and other accessories. Place heavier items on lower shelves for better stability.
- **Weight Capacity:** Do not exceed the maximum load capacity of 20 kg (approximately 44 lbs) for the entire unit. Overloading can compromise stability and structural integrity.



Image 3.1: The clothes rack positioned in a hallway, demonstrating its use for hanging clothes and storing shoes and accessories on shelves.

3.2. Placement

Place the clothes rack on a flat, level surface to ensure maximum stability. Avoid placing it in high-traffic areas where it might be easily bumped or in direct sunlight for prolonged periods, which could affect material integrity over time.

4. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your Relaxdays Open Clothes Rack.

- **Cleaning:** Wipe down the steel frame and shelves with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by drying with a clean cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the powder-coated finish.
- **Inspection:** Periodically check all connections and joints to ensure they remain tight and secure. Re-tighten any loose screws or clips as necessary.
- **Weight Distribution:** Always ensure weight is distributed evenly to prevent stress on specific parts of the rack.

5. TROUBLESHOOTING

If you encounter issues with your clothes rack, refer to the following common problems and solutions.

5.1. Instability or Wobbling

- **Check Connections:** Ensure all pole segments, shelf clips, and rail attachments are fully engaged and tightened.
- **Level Surface:** Verify that the rack is placed on a flat and level surface. Uneven flooring can cause wobbling.
- **Weight Distribution:** Confirm that the weight of items on the rack is evenly distributed. Remove any excessive weight.
- **Overloading:** Ensure the total weight on the rack does not exceed the maximum capacity of 20 kg.

5.2. Difficulty Assembling

- **Review Instructions:** Double-check the assembly instructions provided with the product.
- **Component Orientation:** Ensure all parts are oriented correctly before attempting to connect them.
- **Damaged Parts:** If a part appears damaged or does not fit, do not force it. Contact customer support for assistance.

6. PRODUCT SPECIFICATIONS

Model Number:	10031534
Brand:	Relaxdays
Color:	Black
Material:	Powder-coated Steel (100% Steel)
Product Dimensions (H x W x D):	180 x 120 x 45 cm (approx. 70.87"H x 47.24"W x 17.72"D)
Item Weight:	5.88 kg (approx. 12.94 lbs)
Maximum Load Capacity:	20 kg (approx. 44 lbs)
Number of Shelves:	2 (plus bottom base)
Installation Type:	Free Standing
Assembly Required:	Yes



Image 6.1: Dimensional diagram of the clothes rack, illustrating its height, width, and depth.

7. WARRANTY AND SUPPORT

7.1. Warranty Information

Specific warranty details for the Relaxdays Open Clothes Rack are typically provided with the product packaging or can be obtained directly from the manufacturer. Please retain your proof of purchase for any warranty claims.

7.2. Customer Support

For further assistance, missing parts, or inquiries not covered in this manual, please contact Relaxdays customer support. Refer to the contact information provided in your product packaging or visit the official Relaxdays website.

