



Manuals.plus /

› **Remington /**

› Remington Balder Pro Electric Razor XR7000A User Manual

Remington XR7000A

Remington Balder Pro Electric Razor XR7000A User Manual

Model: XR7000A | Brand: Remington

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your Remington Balder Pro Electric Razor for Head XR7000A. Designed for a close and comfortable head shave, this cordless, rechargeable shaver features flexible blades and dual track heads for efficient grooming. Please read this manual thoroughly before first use and retain it for future reference.



Image: Remington Balder Pro Electric Razor XR7000A, a black and silver electric shaver with five rotary heads.

SAFETY INFORMATION

For your safety and to ensure proper operation, observe the following precautions:

- **Keep Away From Children:** This appliance is not intended for use by children.
- Do not immerse the charging adapter in water or other liquids.
- Always unplug the shaver from the power outlet immediately after charging and before cleaning.
- Do not use the shaver if it is damaged or malfunctioning.
- Use only with the provided charging cord.
- This shaver is designed for wet or dry use, but ensure the charging port is dry before connecting the charger.

WHAT'S INCLUDED

Your Remington Balder Pro Electric Razor package includes the following components:

- Remington Balder Pro Shaver
- Protective Head Guard
- Cleaning Brush
- Oil Bottle
- Charge Cord (USB compatible)
- Travel Pouch



Image: All components included with the Remington Balder Pro Electric Razor: the shaver, a travel pouch, charge cord, headguard, brush, and lubricant bottle.

SETUP

Charging the Shaver

Before first use, fully charge the shaver for 4 hours. Subsequent charges may take less time.

1. Ensure the shaver is turned off.
2. Connect the charging cord to the shaver's charging port.
3. Plug the other end of the charging cord into a suitable USB power adapter or port.
4. The LED battery fuel gauge will indicate charging status.
5. A full charge provides up to 50 minutes of cordless use.



Image: The Remington Balder Pro shaver plugged in, showing the battery light indicator and highlighting its Li-ion rechargeable battery and 50-minute runtime.

OPERATING INSTRUCTIONS

Shaving Your Head

The Remington Balder Pro is designed for efficient and comfortable head shaving, whether wet or dry.

- **Wet Shave:** Apply shaving gel or foam to your head. The shaver is 100% waterproof, allowing for use in the shower.
- **Dry Shave:** Ensure your head is clean and dry for a quick shave.

WHAT'S INCLUDED:



Image: A man demonstrating wet shaving his head with the Remington Balder Pro, emphasizing its 100% waterproof design.

Shaving Technique

For optimal results and to minimize irritation:

1. Turn on the shaver.
2. Gently press the shaver heads against your scalp. The 360-degree pivoting neck and flexing heads will adapt to your head's contours.
3. Move the shaver in small, circular motions over your entire scalp.
4. Avoid applying excessive pressure, as this can cause irritation.
5. The five Dual Track heads are designed for a fast and smooth shave, often completing a shave in under 90 seconds.

PRECISION

5 Dual Track Heads



Image: A detailed view of the Remington Balder Pro's five dual track heads, highlighting their precision design.

Using the Pop-Up Trimmer

The integrated pop-up trimmer is ideal for detailing sideburns, necklines, or small areas.

1. Locate the pop-up trimmer switch on the shaver body.
2. Slide the switch upwards to engage the trimmer.
3. Use the trimmer to precisely shape or trim hair in desired areas.
4. Slide the switch downwards to retract the trimmer when finished.



Image: A man using the pop-up trimmer feature of the Remington Balder Pro shaver to refine his sideburns.

MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the life of your shaver.

Cleaning After Each Use

The shaver features a mess-free hair capture system. For best results, clean after each use:

1. Turn off the shaver.
2. Gently twist and remove the shaver head assembly from the body.
3. Tap out any accumulated hair from the hair chamber.
4. Rinse the shaver head assembly under warm running water. The heads and cutters are assembled as one piece; do not twist the hair pocket at the neck.
5. You may use the provided cleaning brush to remove stubborn hair particles.
6. Rinse the shaver body (if needed) and allow both parts to air dry completely before reattaching the head.



Image: A hand holding the Remington Balder Pro shaver head under running water for cleaning.

Lubrication

To maintain optimal cutting performance, lubricate the cutting heads regularly.

1. After cleaning and drying, apply a small drop of the provided oil to each of the five rotary cutters.
2. Turn on the shaver for a few seconds to distribute the oil evenly.



**#1 BRAND
OF HEAD
SHAVERS
IN THE U.S.***

**GO
BEST
STUFF
2025**

**MEN'S JOURNAL
GROOMING AWARDS
2025**

*Source: Circana, LLC, Retail Tracking Service, US, Personal Care Appliances, Men's Electric Shavers, Head Shaving Ability, 12 ME Apr 2025 -Men's Journal Grooming Awards 2024

Image: A close-up showing a drop of oil being applied to one of the rotary blades of the Remington Balder Pro shaver.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver not turning on or running weakly.	Low battery or not fully charged.	Charge the shaver for 4 hours initially, or until the battery indicator shows full.
Shaver makes a "chugging" noise.	Hair buildup or lack of lubrication in cutting heads.	Clean the cutting heads thoroughly and apply a drop of oil to each cutter.
Irritation after shaving.	Applying too much pressure or using on hair that is too long.	Use gentle, circular motions. For best results, shave frequently to keep hair short.

SPECIFICATIONS

Feature	Detail
Model Number	XR7000A
Brand	Remington
Power Source	Battery Powered (Lithium-ion)
Run Time	Up to 50 minutes cordless
Charging Time	4 hours (initial charge)
Shaving Heads	5 Dual Track Heads
Waterproof	Yes (100% waterproof for wet/dry use)
Special Features	Cordless, Pop-Up Trimmer, Pivoting Head
Dimensions	3.74 x 2.63 x 3.34 inches
Weight	7.94 ounces
UPC	074590554175

WARRANTY AND SUPPORT

Warranty Information

The Remington Balder Pro Electric Razor XR7000A comes with a **5-year limited warranty**. Please refer to the official warranty documentation included with your product for full terms and conditions.

Additional Support

For further assistance, detailed instructions, or to view the complete user manual, you can access the official PDF document:

[Download Official User Manual \(PDF\)](#)

You may also visit the official Remington website or contact their customer support for any product-related inquiries.