

## Girmi FR03

# Girmi FR03 Electric Blender User Manual

Model: FR03

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read these instructions carefully before using the appliance and keep them for future reference. Incorrect use can lead to electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the blending cup while blending to prevent injury and damage to the appliance.
- Ensure the lid is securely in place before operating the blender.
- Do not blend hot liquids, as pressure buildup can cause the lid to eject and result in burns.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate the blender with an empty cup.
- Avoid contact with moving parts. The blades are sharp; handle with extreme care.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

## 2. PRODUCT OVERVIEW

---

The Girmi FR03 Electric Blender is designed for quick and efficient blending of various ingredients. It features a compact design and powerful motor for everyday use.



Image 1: Girmi FR03 Electric Blender with blending cup, motor base, and ingredients.

### Components:

- **Motor Base:** Contains the 170W motor and control button.
- **Blending Cup:** 400 ml capacity, made of durable plastic, with measurement markings.
- **Blade Assembly:** Features 4 stainless steel blades for efficient blending.
- **Lid:** Securely seals the blending cup during operation.




Image 2: Close-up view of the blending cup showing the 400 ml maximum fill line and measurement markings.




Image 3: Detailed view of the four stainless steel blades within the blending cup.

### 3. SETUP

---

Before first use, ensure all packaging materials are removed and clean the parts as described in the 'Maintenance and Cleaning' section.

#### **Assembly Steps:**

1. Place the motor base on a stable, flat, and dry surface.
2. Ensure the blending cup is clean and dry.
3. Add your desired ingredients to the blending cup. Do not exceed the MAX 400 ml mark.
4. Securely place the lid onto the blending cup.
5. Align the blending cup with the motor base and twist clockwise until it locks into place. Ensure it is firmly seated.



Image 4: All components of the Girmi FR03 blender: motor base, blending cup with blades, and lid.

## 4. OPERATING INSTRUCTIONS

---

The Girmi FR03 blender features a simple PULSE operation for controlled blending.

### Blending Process:

1. After assembling the blender with ingredients and the lid securely in place, plug the power cord into a suitable AC 230V - 50/60Hz electrical outlet.
2. To operate, press and hold the button on the front of the motor base. The blender will operate as long as the button is held down.
3. Release the button to stop blending. This is the 'PULSE' function, allowing you to control the blending consistency.
4. Blend in short bursts (e.g., 10-20 seconds) to achieve desired consistency and prevent overheating. Allow the motor to rest between bursts.
5. Once blending is complete, unplug the appliance from the power outlet.

- Carefully twist the blending cup counter-clockwise to unlock it from the motor base.
- Remove the lid and pour out your blended contents.

### Tips for Best Results:

- Cut larger ingredients into smaller pieces before blending.
- Add liquids first, then softer ingredients, and finally harder ingredients or ice.
- Do not overload the blending cup beyond the MAX 400 ml line.
- If ingredients stick to the sides, turn off the blender, unplug it, remove the cup, and gently shake or use a spatula to push ingredients towards the blades. Never use utensils while the blender is running.

## 5. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the life of your blender.

### Cleaning Steps:

1. Always unplug the blender from the power outlet before cleaning.
2. Disassemble the blending cup from the motor base and remove the lid.
3. **Blending Cup and Lid:** Wash these parts in warm, soapy water. Rinse thoroughly and dry immediately. These parts may also be suitable for the top rack of a dishwasher, but hand washing is recommended for longevity.
4. **Blade Assembly:** Exercise extreme caution when cleaning the blades as they are very sharp. Use a brush to clean around the blades to avoid direct contact with your hands. Rinse thoroughly.
5. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid. Do not use abrasive cleaners or scouring pads.
6. Ensure all parts are completely dry before reassembling or storing the blender.

### Storage:

Store the blender in a dry place, away from direct sunlight and out of reach of children. The power cord can be wrapped around the base for tidy storage (cord wrap feature).

## 6. TROUBLESHOOTING

---

If you encounter issues with your Girmi FR03 blender, refer to the following common problems and solutions:

| Problem                                | Possible Cause  | Solution  |
|--|---|---|
| Blender does not turn on.              | Not plugged in; power outlet not working; cup not correctly assembled; motor overheating. | Check power cord connection; test outlet with another appliance; ensure cup is locked onto base; unplug and let cool for 15-30 minutes. |
| Ingredients are not blending smoothly. | Too little liquid; too many ingredients; ingredients too large; blades jammed.            | Add more liquid; reduce ingredient quantity; cut ingredients into smaller pieces; unplug, remove cup, and dislodge jammed items.        |

| Problem                                   | Possible Cause   | Solution  |
|---|--|---|
| Loud noise or vibration during operation. | Cup not properly seated; foreign object in cup; motor base on an uneven surface. | Ensure cup is securely locked; unplug and check for foreign objects; place blender on a stable, flat surface. |
| Leakage from the blending cup.            | Lid not properly secured; cup overfilled.  | Ensure lid is firmly in place; do not fill past the MAX line.   |

If the problem persists after trying these solutions, please contact customer support.

## 7. SPECIFICATIONS

---

- **Model:** FR03
- **Power:** 170 W
- **Voltage:** AC 230 V - 50/60 Hz
- **Blending Cup Capacity:** 400 ml
- **Blades:** 4, Stainless Steel
- **Material:** Stainless steel (blades), Plastic (cup, base housing)
- **Dimensions (approx.):** 10 cm (W) x 29 cm (H) x 10 cm (D)
- **Special Feature:** Cord wrap

## 8. WARRANTY AND SUPPORT

---

Girmi products are manufactured to high-quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. For warranty claims, technical support, or service inquiries, please refer to the contact information provided with your purchase documentation or visit the official Girmi website. Please retain your proof of purchase for any warranty claims.